

## TwisTorr 305 FS Remote Controller

Models X3506-64130, X3506-64131

Manuale di istruzioni Bedienungshandbuch Notice de mode d'emploi Manual de istrucciones 用户手册 ユーザーマニュアル User Manual

87-901-059-01 01/2020



### Notices

© Agilent Technologies, Inc. 2020

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Agilent Technologies, Inc. as governed by United States and international copyright laws.

#### **Manual Part Number**

Publication Number: 87-901-059-01

#### Edition

Edition 01/2020 Printed in ITALY

Agilent Technologies Italia S.p.A. Vacuum Products Division Via F.Ili Varian, 54 10040 Leinì (TO) ITALY

#### Warranty

The material contained in this document is provided "as is," and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Agilent disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Agilent shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Agilent and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.

#### **Technology Licenses**

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

#### **Restricted Rights Legend**

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause. Use, duplication or disclosure of Software is subject to Agilent Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

#### **Trademarks**

Windows and MS Windows are U.S. registered trademarks of Microsoft Corporation.

#### **Safety Notices**

#### CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

#### WARNING

A WARNING notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

### **TwisTorr 305 FS Remote Controller**



**TwisTorr 305 FS Remote Controller** 

Page intentionally left blank

### Contents

1	Istruzioni per l'uso	11
	Informazioni Generali	12
	Immagazzinamento	13
	Preparazione per l'installazione	14
	Installazione	15
	Uso	16
	Procedure di uso	19
	Manutenzione	19
	Smaltimento	20
	Messaggi di errore	21
2	Gebrauchsanleitung	23
	Allgemeines	24
	Lagerung	25
	Vor der Installation	26
	Vor der Installation Installation	26 27
	Vor der Installation Installation Gebrauch	26 27 28
	Vor der Installation Installation Gebrauch Bedienung	26 27 28 31
	Vor der Installation Installation Gebrauch Bedienung Wartung	26 27 28 31 31
	Vor der Installation Installation Gebrauch Bedienung Wartung Entsorgung	26 27 28 31 31 32

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

3	Mode d'emploi	35
	Indications generales	36
	Emmagasinage	37
	Preparation pour l'installation	38
	Installation	39
	Utilisation	40
	Procedures d'utilisation	43
	Entretien	43
	Mise au rebut	44
	Messages d'erreur	45
4	Manual de istrucciones	47
	Información general	48

Información general	48
Almacenamiento	49
Preparación para la instalación	50
Instalación	51
Uso	52
Procedimientos de uso	55
Mantenimiento	55
Eliminación	56
Mensajes de error	57

5	使用说明	59
	一般信息	60
	存储	61
	安装准备	62
	安装	63
	使用	64
	使用流程	67
	维护	67
	处置方式	68
	错误消息	69
6	使用方法	71
	概要情報	72
	保管	73
	取り付けの準備	74
	取り付け	75
	使用	76
	使用手順	79
	メンテナンス	79
	廃棄	80
	エラーメッセージ	81

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

7/190

7	Instructions for Use	83
	General Information	84
	Storage	85
	Preparation for Installation	86
	Installation	87
	Use	88
	Use Procedure	91
	Maintenance	91
	Disposal	92
	Error Messages	93
8	Technical Information	95
	TwisTorr 305 FS Remote Controller Description	97
	Controller Specifications	99
	Controller Outline	100
	Controller Connection	101
	R1 – R2 Output Diagrams	108
	Programmable Analog Output Diagrams	110
	J2 – Serial Connector	116
	Vacuum Link App	116
	Letter Protocol Description	119
	Examples	129

How to Use by Front Panel	137
Use	143
Programming	150
How to Use by Remote I/0	164
How to Use in Serial Mode	164
Profibus Option	166
Error Messages	180
Orderable Parts	183

Page intentionally left blank



Informazioni Generali	
Immagazzinamento	13
Preparazione per l'installazione	14
Installazione	15
Uso	
Comandi, Indicatori e Connettori	17
Descrizione pannello frontale	17
Procedure di uso	19
Accensione del Controller	19
Avvio della Pompa	19
Arresto della Pompa	19
Manutenzione	19
Smaltimento	
Messaggi di errore	

Traduzione delle istruzioni originali



Informazioni Generali

### Informazioni Generali

Questa apparecchiatura è destinata ad uso professionale. L'utilizzatore deve leggere attentamente il presente manuale di istruzioni ed ogni altra informazione addizionale fornita dalla Agilent prima dell'utilizzo dell'apparecchiatura. La Agilent si ritiene sollevata da eventuali responsabilità dovute all'inosservanza totale o parziale delle istruzioni, ad uso improprio da parte di personale non addestrato, ad interventi non autorizzati o ad uso contrario alle normative nazionali specifiche. I controller della serie TwisTorr 305 FS Remote sono dei convertitori di frequenza, controllati da un microprocessore, realizzati con componenti a stato solido e con capacità di autodiagnostica e autoprotezione.

Caratteristiche del controller:

- Operatività frontale / remota / seriale
- Pilotaggio a 24 Vdc della ventola di raffreddamento pompa
- Pilotaggio vent valve
- Lettura velocità pompa in seguito al commando di arresto (lettura velocità di arresto)
- Lettura della pressione
- Interfaccia Profibus (opzionale)
- Impostazione automatica tensione di ingresso.

Nei paragrafi seguenti sono riportate tutte le informazioni necessarie a garantire la sicurezza dell'operatore durante l'utilizzo dell'apparecchiatura. Informazioni dettagliate sono fornite nell'appendice "Technical Information". Questo manuale utilizza le seguenti convenzioni:



I messaggi di avvertenza attirano l'attenzione dell'operatore su una procedura o una pratica specifica che, se non eseguita in modo corretto, potrebbe provocare gravi lesioni personali.



I messaggi di attenzione sono visualizzati prima di procedure che, se non osservate, potrebbero causare danni all'apparecchiatura.

NOTA Le note contengono informazioni importanti estrapolate dal testo.

### Immagazzinamento

Durante il trasporto e l'immagazzinamento dei controller devono essere soddisfatte le seguenti condizioni ambientali:

- temperatura: da -20 °C a +70 °C
- umidità relativa: 0 95 % (non condensante)

Preparazione per l'installazione

### Preparazione per l'installazione

Il controller viene fornito in un imballo protettivo speciale; se si presentano segni di danni, che potrebbero essersi verificati durante il trasporto, contattare l'ufficio vendite locale.

Durante l'operazione di disimballaggio, prestare particolare attenzione a non lasciar cadere il controller e a non sottoporlo ad urti.

Non disperdere l'imballo nell'ambiente. Il materiale è completamente riciclabile e risponde alla direttiva CEE 85/399 per la tutela dell'ambiente.



Figura 1 Imballo dei controller

### Installazione

## AVVERTENZA!

Il controller è progettato solo per uso interno e deve essere alimentato mediante un cavo di alimentazione a tre fili (vedere tabella delle parti ordinabili) con una spina di tipo approvato a livello internazionale ai fini della sicurezza dell'utente. Utilizzare sempre questo cavo di alimentazione ed inserire la spina in una presa con un adeguato collegamento di terra onde evitare scariche elettriche e per rispettare le specifiche CE. All'interno del controller si sviluppano alte tensioni che possono recare gravi danni o la morte. Prima di eseguire qualsiasi operazione di installazione o manutenzione del controller scollegarlo dalla presa di alimentazione.

#### NOTA

Il controller può essere installato su di un tavolo o all'interno di un apposito rack. In ogni caso occorre che l'aria di raffreddamento possa circolare liberamente intorno all'apparato. Non installare né utilizzare il controller in ambienti esposti ad agenti atmosferici (pioggia, gelo, neve), polveri, gas aggressivi, in ambienti esplosivi o con elevato rischio di incendio.

Durante il funzionamento è necessario che siano rispettate le seguenti condizioni ambientali:

- temperatura: da 5 °C a +45 °C;
- umidità relativa: 0 95 % (non condensante).

Per gli altri collegamenti e l'installazione degli accessori opzionali, vedere la sezione "Technical Information".

### 1 Istruzioni per l'uso

Uso

### Uso

In questo paragrafo sono riportate le principali procedure operative. Per ulteriori dettagli e per procedure che coinvolgono collegamenti o particolari opzionali, fare riferimento al paragrafo "Use" dell'appendice "Technical Information".

Prima di usare il controller effettuare tutti i collegamenti elettrici e pneumatici e fare riferimento al manuale della pompa collegata.



Per evitare danni alle persone ed all'apparato, nel caso in cui la pompa sia appoggiata su di un tavolo assicurarsi che sia stabile. Non fare funzionare mai la pompa se la flangia di ingresso non è collegata al sistema o non è chiusa con la flangia di chiusura.

#### NOTA

Il connettore di richiusura J1 deve essere lasciato collegato con il suo ponticello se non viene effettuato alcun collegamento esterno. La pompa di pre-vuoto e la pompa TwisTorr 305 FS possono essere accese contemporaneamente.

### Comandi, Indicatori e Connettori

Di seguito sono illustrati il pannello di comando del Controller ed i pannelli di interconnessione. Per maggiori dettagli fare riferimento alla sezione "Technical Information".

### **Descrizione pannello frontale**



Figura 2 Pannello frontale del Controller TwisTorr 305 FS Remote

1	Pulsante per richiamare sul display i parametri cycle number, cycle time e pump life.
2	Pulsante per la selezione del modo LOW SPEED. È attivo solo quando è selezionato il modo di comando dal pannello frontale. Premendolo una volta, la pompa ruota a velocità "stand-by". Premendolo ancora si disattiva il modo LOW SPEED.
3	Pulsante per richiamare sul display i parametri pump current, pump temperature, pump power e rotational speed. È sempre attivo indipendentemente dal modo di funzionamento scelto. Premendo assieme i pulsanti 3 e 1 per almeno 2 secondi viene attivato un programma con il quale è possibile programmare alcuni parametri operativi.
4	Pulsante per inviare i comandi di START, STOP/RESET. È attivo solo quando è selezionato il modo di comando dal pannello frontale. Premendolo una volta si attiva la fase di avvio; premendolo nuovamente si arresta la pompa. Se la pompa si è fermata automaticamente a causa di un guasto, occorre premere questo pulsante una prima volta per eseguire il reset del controller ed una seconda volta per riavviare la pompa.
5	Display alfanumerico a cristalli liquidi: matrice di punti, 2 linee x 16 caratteri.

#### 1 Istruzioni per l'uso

Uso





1	Connettore di ingresso dei segnali logici (il connettore di accoppiamento viene fornito con l'apposito ponticello di richiusura).
2	Connettore segnali logici in uscita e monitoraggio frequenza pompa più uscita analogica programmabile.
3	Connettore di uscita alimentazione (24 Vdc per la ventola di raffreddamento pompa, vent valve e calibro).
4	Modulo di ingresso alimentazione controller che comprende i fusibili, la presa di alimentazione ed il filtro ENC.
5	Switch a rotazione per impostare l'indirizzo del Profibus.
6	Profibus (opzionale).
7	Connettore seriale per controllo da remoto.
8	Pompa.

### Procedure di uso

### Accensione del Controller

Per accendere il controller è sufficiente inserire il cavo di alimentazione nella presa di rete.

### Avvio della Pompa

Per avviare la pompa occorre abilitare l'ingresso di interlock e premere il pulsante START del pannello frontale.

### Arresto della Pompa

Per arrestare la pompa occorre premere il pulsante STOP del pannello frontale.

### Manutenzione

I controller della serie TwisTorr 305 FS Remote non richiedono alcuna manutenzione. Qualsiasi intervento deve essere eseguito da personale autorizzato. In caso di guasto è possibile usufruire del servizio di riparazione Agilent o del "Agilent advanced exchange service", che permette di ottenere un controller rigenerato in sostituzione di quello guasto.



Prima di effettuare qualsiasi intervento sul controller scollegare il cavo di alimentazione.

Qualora un controller dovesse essere rottamato, procedere alla sua eliminazione nel rispetto delle normative nazionali specifiche.

### 1 Istruzioni per l'uso

**Smaltimento** 

### **Smaltimento**

Significato del logo "WEEE" presente sulle etichette. Il simbolo qui sotto riportato è applicato in ottemperanza alla direttiva CE denominata "WEEE". Questo simbolo (valido solo per i paesi della Comunità Europea) indica che il prodotto sul quale è applicato, NON deve essere smaltito insieme ai comuni rifiuti domestici o industriali, ma deve essere avviato ad un sistema di raccolta differenziata. Si invita pertanto l'utente finale a contattare il fornitore del dispositivo, sia esso la casa madre o un rivenditore, per avviare il processo di raccolta e smaltimento, dopo opportuna verifica dei termini e condizioni contrattuali di vendita.



Per maggiori informazioni riferirsi a:

http://www.agilent.com/environment/product/index.shtml

### Messaggi di errore

In alcuni casi di guasto la circuiteria di autodiagnosi del controller presenta alcuni messaggi di errore elencati nella tabella seguente.

#### Tab. 1

MESSAGGIO	DESCRIZIONE	AZIONE CORRETTIVA
RUN UP TIME	La pompa non è riuscita a raggiungere una velocità> 700 Hz, entro il tempo previsto (Tempo di avvio, che è configurabile).	Verificare l'impostazione del tempo di avvio: deve essere impostato in base al processo del cliente. Controllare il carico di gas che scorre all'interno della pompa e regolarlo di conseguenza. Verificare che il rotore della pompa possa ruotare liberamente. Riavviare la pompa.
CHECK CONNECTION TO PUMP	Malfunzionamento nel collegamento tra pompa e controller. Oppure La pompa ha una temperatura inferiore a 0 °C.	Verificare che il cavo di collegamento tra pompa e controller sia ben fissato da entrambe le estremità e non sia interrotto. Premere due volte il pulsante START per riavviare la pompa.
WAITING INTERLOCK	È attivo il segnale di interlock presente sul connettore P1 a causa dell'interruzione del corto circuito tra il pin 3 ed il pin 8 del connettore J1, o a causa dell'apertura del segnale di interlock esterno.	Ripristinare il corto circuito tra il pin 3 ed il pin8 del connettore P1, o chiudere il segnale di interlock esterno.
PUMP OVERTEMP.	La temperatura del corpo pompa ha superato il limite superiore di temperatura consentito, che è in funzione del tipo di gas selezionato (Ar: 50°C; N2: 55°C; He: 60°C).	Attendere che la temperatura ritorni al di sotto della soglia. Premere due volte il pulsante START per riavviare la pompa.
CONTROLLER OVERTEMP.	La temperatura dell'ambiente del controller ha superato i 70 °C. Oppure. La temperatura del radiatore del controller è superiore a 60 °C.	Attendere che la temperatura ritorni al di sotto della soglia. Premere due volte il pulsante START per riavviare la pompa.

#### 1 Istruzioni per l'uso

Messaggi di errore

MESSAGGI0	DESCRIZIONE	AZIONE CORRETTIVA
TOO HIGH LOAD	La corrente assorbita dalla pompa è maggiore di quella programmata.	Verificare che il rotore della pompa abbia la possibilità di ruotare liberamente. Premere due volte il pulsante START per riavviare la pompa.
SHORT CIRCUIT	Durante il funzionamento normale (dopo la fase di avvio) la connessione di uscita è in corto circuito.	Verificare i collegamenti tra pompa e controller. Premere due volte il pulsante START per riavviare la pompa.
SYSTEM OVERRIDE	La pompa è stata fermata da un segnale di emergenza proveniente da un contatto remoto.	Staccare il cavo di alimentazione del controller e correggere la causa dell'emergenza. Ricollegare il cavo di alimentazione e premere due volte il pulsante START per riavviare la pompa.
OVERVOLTAGE	Si è verificato un guasto nella sezione di alimentazione del controller, o il controller ha ricevuto un segnale spurio.	Premere due volte il pulsante START per riavviare la pompa. Se il messaggio si ripresenta rivolgersi in Agilent per la manutenzione.
RUN UP TIME	Tempo di Run Up scaduto.	Verificare la corretta impostazione del tempo di Run Up in funzione dell'applicazione. Verificare il carico di gas applicato alla pompa.

#### **TwisTorr 305 FS Remote Controller User Manual**



Lagerung25Vor der Installation26Installation27Gebrauch28Steuerungen, Anzeigen und Verbinder des Controllers28Fronttafel der Controller29Bedienung31Einschalten des Controllers31Pumpenstart31Pumpenstopp31Wartung31Entsorgung32Fehlermeldungen33	Allgemeines	24
Vor der Installation26Installation27Gebrauch28Steuerungen, Anzeigen und Verbinder des Controllers28Fronttafel der Controller29Bedienung31Einschalten des Controllers31Pumpenstart31Pumpenstopp31Wartung31Entsorgung32Fehlermeldungen33	Lagerung	25
Installation27Gebrauch28Steuerungen, Anzeigen und Verbinder des Controllers28Fronttafel der Controller29Bedienung31Einschalten des Controllers31Pumpenstart31Pumpenstopp31Wartung31Entsorgung32Fehlermeldungen33	Vor der Installation	26
Gebrauch26Steuerungen, Anzeigen und Verbinder des Controllers26Fronttafel der Controller29Bedienung31Einschalten des Controllers31Pumpenstart31Pumpenstopp31Wartung31Entsorgung32Fehlermeldungen33	Installation	27
Steuerungen, Anzeigen und Verbinder des Controllers 26   Fronttafel der Controller 29   Bedienung 31   Einschalten des Controllers 31   Pumpenstart 31   Pumpenstopp 31   Wartung 31   Entsorgung 32   Fehlermeldungen 33	Gebrauch	28
Fronttafel der Controller29Bedienung31Einschalten des Controllers31Pumpenstart31Pumpenstopp31Wartung31Entsorgung32Fehlermeldungen33	Steuerungen, Anzeigen und Verbinder des Controllers	28
Bedienung31Einschalten des Controllers31Pumpenstart31Pumpenstopp31Wartung31Entsorgung32Fehlermeldungen33	Fronttafel der Controller	29
Einschalten des Controllers31Pumpenstart31Pumpenstopp31Wartung31Entsorgung32Fehlermeldungen33	Bedienung	31
Pumpenstart31Pumpenstopp31Wartung31Entsorgung32Fehlermeldungen33	Einschalten des Controllers	31
Pumpenstopp31Wartung31Entsorgung32Fehlermeldungen33	Pumpenstart	31
Wartung31Entsorgung32Fehlermeldungen33	Pumpenstopp	31
Entsorgung 32 Fehlermeldungen 33	Wartung	31
Fehlermeldungen 33	Entsorgung	32
	Fehlermeldungen	33

Übersetzung der Originalanleitungen



#### 2 Gebrauchsanleitung

Allgemeines

### Allgemeines

Dieser Apparat ist für Fachbetriebe bestimmt. Vor Gebrauch sollte der Benutzer dieses Handbuch sowie alle weiteren mitgelieferten Zusatzdokumentationen genau lesen. Bei Nichtbeachtung - auch teilweise - der enthaltenen Hinweise, unsachgemäßem Gebrauch durch ungeschultes Personal, nicht autorisierten Eingriffen und Mißachtung der einheimischen, hier zur Geltung kommenden Bestimmungen übernimmt die Firma Agilent keinerlei Haftung.

Die Controller der Serie TwisTorr 305 FS Remote sind mikroprozessorgesteuerte Frequenzwandler. Sie sind mit Festkörperbauteilen gefertigt und verfügen über ein Selbstdiagnose- und ein Selbstschutzsystem.

Controllereigenschaften:

- Konsol-, Fern- und serielle Operationen
- 24V= Kühlventilator-Treiber
- Vent Valve Treiber
- Auslesen der Pumpgeschwindigkeit nach Stoppbefehl (Lesen der Stoppgeschwindigkeit)
- Auslesen des Drucks
- Profibus-Schnittstelle (Option)
- automatische Einstellung der Eingangsspannung

In den folgenden Abschnitten sind alle erforderlichen Informationen für die Sicherheit des Bedieners bei der Anwendung des Geräts aufgeführt. Detaillierte technische Informationen sind im Anhang "Technical Information" enthalten.



In dieser Gebrauchsanleitung werden Sicherheitshinweise folgendermaßen hervorgehoben:



Die Warnhinweise lenken die Aufmerksamkeit des Bedieners auf eine bestimmte Prozedur oder Praktik, die bei unkorrekter Ausführung schwere Verletzungen hervorrufen können.

VORSICHT!

Die Vorsichtshinweise vor bestimmten Prozeduren machen den Bediener darauf aufmerksam, daß bei Nichteinhaltung Schäden an der Anlage entstehen können.

HINWEIS Die Hinweise enthalten wichtige Informationen, die aus dem Text hervorgehoben werden.

### Lagerung

Beim Transport und bei der Lagerung der Controller müssen folgende klimatische Verhältnisse eingehalten werden:

- Temperatur: von -20 °C bis +70 °C
- Relative Luftfeuchtigkeit: 0 95 % (nicht kondensierend)

### 2 Gebrauchsanleitung

Vor der Installation

### Vor der Installation

Der Controller wird mit einer speziellen Schutzverpackung geliefert. Eventuelle Transportschäden müssen der zuständigen örtlichen Verkaufsstelle gemeldet werden.

Beim Auspacken vorsichtig vorgehen, damit der Controller nicht fällt oder Stößen ausgesetzt wird.

Das Verpackungsmaterial muß korrekt entsorgt werden. Es ist vollständig recyclebar und entspricht der EG-Richtlinie 85/399 für Umweltschutz.



Abbildung 1 Verpackung der Controller

### Installation

#### WARNUNG!



Zum Schutz des Bedieners darf der Controller nur im Gebäude zum Einsatz kommen und nicht außerhalb. Er muss mit einem dreiadrigen Netzkabel (siehe Tabelle bestellbares Zubehör) und dem (international zugelassenen) Stecker angeschlossen werden. Es sollte immer dieses Netzkabel benutzt werden, das an eine korrekt geerdete Steckdose anzuschließen ist, um den CE Richtlinien zu entsprechen und Stromschläge zu vermeiden. Im Inneren des Controllers entstehen hohe Spannungen, die schwere Schäden verursachen und zum Teil lebensgefährlich sein können. Vor jedem Montage- bzw. Wartungseingriff muß deshalb der Netzstecker gezogen werden.

#### HINWEIS

Der Controller kann auf einen Tisch oder ein Gestell montiert werden. In beiden Fällen muß auf die ungehinderte Zirkulation der Kühlluft im Bereich des Geräts geachtet werden. Der Controller darf nicht in Umgebungen installiert u/o benutzt werden, die Witterungseinflüssen (Regen, Frost, Schnee), Staub und aggressiven Gasen ausgesetzt sind und in denen Explosions- und erhöhte Brandgefahr besteht.

Beim Betrieb müssen folgende Umgebungsbedingungen eingehalten werden:

- Temperatur: von +5 °C bis +45 °C
- Relative Luftfeuchtigkeit: 0 95 % (nicht kondensierend).

### 2 Gebrauchsanleitung

Gebrauch

### Gebrauch

In diesem Kapitel sind die wichtigsten Betriebsvorgänge aufgeführt. Für weitere Hinweise bezüglich Anschlüsse und Montage des bestellbaren Zubehörs siehe Kapitel "Use" im Anhang zu "Technical Information".

Vor Benutzung des Controllers sämtliche elektrischen und pneumatischen Anschlüsse ausführen, und die Betriebsanleitung der angeschlossenen Pumpe durchlesen.

## WARNUNG!



Steht die Pumpe auf einem Tisch, muß auf den stabilen Stand geachtet werden, da sonst die Gefahr von Personen- und Geräteschäden besteht. Die Pumpe nie einschalten, wenn der Eingangsflansch nicht am System angeschlossen bzw. nicht mit dem Schließflansch abgedeckt ist.

#### **HINWEIS**

Der Wiederverschließ-Verbinder J1 muß mit seiner Brücke angeschlossen bleiben, wenn kein externer Anschluß erfolgt. Die Vorvakuumpumpe und die TwisTorr 305 FS Pumpe können gleichzeitig eingeschaltet werden.

# Steuerungen, Anzeigen und Verbinder des Controllers

Der folgende Abschnitt beschreibt die vordere und hintere Konsole des Controllers. Fur weitere Einzelheiten siehe "Technical Information".

### Fronttafel der Controller



Abbildung 2 Fronttafel der Controller TwisTorr 305 FS Remote

1	Taste für die Anzeige der Parameter "cycle number", "cycle time" und "pump life".
2	Taste für die Einstellung des Modus LOW SPEED. Sie ist nur aktiv, wenn der Steuermodus auf Fronttafel eingestellt ist. Bei einmaligem Drücken läuft die Pumpe in Bereitschafts- Geschwindigkeit. Bei nochmaligem Drücken wird der Modus LOW SPEED deaktiviert.
3	Taste für die Anzeige der Parameter "pump current", "pump temperature", "pump power" und "rational speed". Sie ist immer aktiv, unabhängig vom gewählten Betriebsmodus. Bei gemeinsamer, mindestens 2 Sekunden langer Betätigung der Tasten 3 und 1 wird ein Programm aktiviert, mit dem einige Betriebsparamter programmiert werden können.
4	START-, STOP/RESET-Taste. Sie ist nur aktiv, wenn der Steuermodus auf der Fronttafel eingestellt ist. Bei einmaligem Drücken wird die Startphase aktiviert. Bei nochmaligem Drücken stoppt die Pumpe. Bei automatischem Pumpenstopp durch Störung muß diese Taste ein erstes Mal zur Controller-Rücksetzung und dann ein zweites Mal zum Neustarten der Pumpe gedrückt werden.
5	Alphanumerisches Flüssigkristall-Display: Punkt-matrix, 2 Zeilen mit 16 Stellen.

#### 2 Gebrauchsanleitung

Gebrauch



#### Abbildung 3 Rücktafel der Controller TwisTorr 305 FS Remote

1	Eingangsverbinder der logischen Signale (der Kupplungsverbinder wird mit einer Wiederverschließbrücke geliefert).
2	Stecker für logische Signale und Pumpenmonitor plus programmierbarer Analogausgang.
3	Stromausgangsstecker (24 V= für Pumpenkühlventilator, Vent Valve und Messinstrument).
4	Netzeingangsmodul des Controllers bestehend aus Netzsicherungen, Netzstecker und EMC Filter.
5	Drehschalter zum Setzen der Profibus Adresse.
6	Profibus (Option).
7	Serieller Stecker zur Fernsteuerung.
8	Pumpenstecker.

### Bedienung

### **Einschalten des Controllers**

Zum Einschalten des Controllers genügt es, das Netzkabel an die Steckdose anzuschließen.

### **Pumpenstart**

Zum Starten der Pumpe den Verrieglungseingang bestätigen und die START Taste of der vorderen Konsole des Controllers drücken.

### Pumpenstopp

Zum Stoppen der Pumpe muß die STOP-Taste an der Fronttafel gedrückt werden.

### Wartung

Die Controller der Serie TwisTorr 305 FS Remote sind wartungsfrei. Eventuell erforderliche Eingriffe müssen von dazu befugtem Fachpersonal ausgeführt werden. Bei einem Defekt kann der Agilent-Reparaturdienst bzw. der "Agilent advanced exchange service" in Anspruch genommen werden, der für die Erneuerung defekter Controller sorgt.



Vor jedem Eingriff am Controller muß der Netzstecker gezogen werden.



Ein Controller muß unter Einhaltung der einschlägigen landesüblichen Vorschriften erfolgen.

#### 2 Gebrauchsanleitung

Entsorgung

### Entsorgung

**Bedeutung des "WEEE" Logos auf den Etiketten.** Das folgende Symbol ist in Übereinstimmung mit der EU-Richtlinie WEEE (Waste Electrical and Electronic Equipment) angebracht. Dieses Symbol (**nur in den EU-Ländern gültig**) zeigt an, dass das betreffende Produkt nicht zusammen mit Haushaltsmüll entsorgt werden darf sondern einem speziellen Sammelsystem zugeführt werden muss. Der Endabnehmer sollte daher den Lieferanten des Geräts - d.h. die Muttergesellschaft oder den Wiederverkäufer - kontaktieren, um den Entsorgungsprozess zu starten, nachdem er die Verkaufsbedingungen geprüft hat.



Weitere Informationen finden Sie unter:

http://www.agilent.com/environment/product/index.shtml

### Fehlermeldungen

In einigen Störungsfällen zeigt das Selbstdiagnosesystem des Controllers die in der nachstehenden Tabelle zusammengefaßten Meldungen an.

#### Tab. 1

MELDUNG	BESCHREIBUNG	BEHEBUNG
RUN UP TIME	Die Pumpe konnte innerhalb des erwarteten Wertes (konfigurierbare Anlaufzeit) keinen Drehzahlwert > 700 Hz erreichen.	Prüfen Sie, ob die Anlaufzeit eingestellt ist: Sie sollte entsprechend dem Kundenprozess eingestellt sein. Überprüfen Sie die in der Pumpe strömende Gaslast und stellen Sie sie entsprechend ein. Überprüfen Sie, ob sich der Pumpenrotor frei drehen kann. Starten Sie die Pumpe neu.
CHECK CONNECTION TO PUMP	Fehlfunktion der Pumpen- Controller Verbindung. Oder Die Temperatur der Pumpe ist unter 0 °C.	Sicherstellen, daß das Verbindungskabel zwischen Pumpe und Controller an beiden Seiten korrekt befestigt ist und keine Unterbrechung vorliegt. Die Pumpe durch zweimalige Betätigung der START- Taste neustarten.
WAITING INTERLOCK	Das Interlock-Signal auf dem Verbinder P1 ist wegen der Kurzschluß-unterbrechung zwischen Pin 3 und Pin 8 des Verbinders K1 oder wegen der Öffnung des externen Interlock- Signals aktiv.	Den Kurzschluß zwischen Pin 3 und Pin 8 des Verbinders P1 rücksetzen oder das externe Interlock- Signal schließen.
PUMP OVERTEMP.	Die Temperatur des Pumpenkörpers hat die maximal zulässige Obergrenze überschritten, abhängig von der gewählten Gasart (Ar: 50°C; N2: 55°C; He: 60°C).	Warten bis die Temperatur unter den Schwellenwert gesunken ist. Die Pumpe durch zweimalige Betätigung der START- Taste neustarten.
CONTROLLER OVERTEMP.	Die Temperatur des Controllers hat 70 °C überschritten. Oder Die Temperatur des Kontrollerkühlkörpers ist über 60 °C.	Warten bis die Temperatur unter den Schwellenwert gesunken ist. Die Pumpe durch zweimalige Betätigung der START- Taste neustarten.

#### 2 Gebrauchsanleitung

Fehlermeldungen

MELDUNG	BESCHREIBUNG	BEHEBUNG
TOO HIGH Load	Die Pumpen ist stromaufnahme größer als die vorgesehene.	Sicherstellen, daß der Pumpenrotor ungehindert drehen kann. Die Pumpe durch zweimalige Betätigung der START- Taste neustarten.
SHORT CIRCUIT	Während des Normalbetriebs (nach der Startphase) erfolgt ein Kurzschluß der Ausgangsverbindung.	Die Verbindung zwischen Pumpe und Controller prüfen. Die Pumpe durch zweimalige Betätigung der START-Taste neustarten.
SYSTEM OVERRIDE	Die Pumpe wurde durch ein von einem entfernten Kontakt kommendes Notsignal gestoppt.	Das Netzkabel des Controllers ausstecken und die Störungsursache beheben. Das Netzkabel wieder anschließen und die Pumpe durch zweimalige Betätigung der START- Taste neustarten.
OVERVOLTAGE	Defekt im Versorgungsbereich des Controllers bzw. der Controller hat ein falsches Signal erhalten.	Die Pumpe durch zweimalige Betätigung der START-Taste neustar-ten. Erscheint die Meldung wieder sollte der Agilent- Wartungs-dienst gerufen werden.
RUN UP TIME	Anlaufzeitüberschreitung.	Prüfen Sie die Einrichtung der Anlaufzeit. Sie muss entsprechend dem Kundenprozess angepasst werden. Prüfen Sie die Menge der Gaslast, die in der Pumpe fließt.



Indications generales		
Emmagasinage		
Preparation pour l'installation		
Installation		
Utilisation		
Commandes, Indicateurs et Connecteurs	41	
Description du Tableau avant	41	
Procedures d'utilisation	43	
Allumage du Contrôleur	43	
Mise en marche de la Pompe	43	
Arrêt de la Pompe	43	
Entretien		
Mise au rebut		
Messages d'erreur		

Traduction de la mode d'emploi originale



#### 3 Mode d'emploi

**Indications** generales

### **Indications generales**

Cet appareillage a été conçu en vue d'une utilisation professionnelle. Il est conseillé à l'utilisateur de lire attentivement cette notice d'instructions ainsi que toute autre indication supplémentaire fournie par Agilent, avant l'utilisation de l'appareil. Agilent décline par conséquent toute responsabilité en cas d'inobservation totale ou partielle des instructions données, d'utilisation incorrecte de la part d'un personnel non formé, d'opérations non autorisées ou d'un emploi contraire aux réglementations nationales spécifiques. Les contrôleurs de la série TwisTorr 305 FS Remote sont des convertisseurs de fréquence, contrôlés par un microprocesseur, réalisés avec des éléments à l'état solide et ayant des capacités d'autodiagnostic et d'autoprotection.

Caractéristiques du contrôleur:

- Caractère opérationnel de front / à distance / sériel
- Pilotage à 24 Vdc du ventilateur de refroidissement pompe
- Pilotage vent valve
- Lecture vitesse pompe suite à la commande d'arrêt (lecture vitesse d'arrêt)
- Lecture de la pression
- Interface Profibus (facultatif)
- Attribution automatique tension d'entrée.

Les paragraphes suivants donnent toutes les indications nécessaires à garantir la sécurité de l'opérateur pendant l'utilisation de l'appareillage. Des renseignements plus détaillés se trouvent dans l'appendice "Technical Information".
Cette notice utilise les signes conventionnels suivants:



Les messages d'avertissement attirent l'attention de l'opérateur sur une procédure ou une manoeuvre spéciale qui, si elle n'est pas effectuée correctement, risque de provoquer de graves lésions..

#### **ATTENTION!**

Les messages d'attention apparaissent avant certaines procédures qui, si elles ne sont pas observées, pourraient endommager sérieusement l'appareillage.

NOTE Les notes contiennent des renseignements importants, isolés du texte.

### Emmagasinage

Pendant le transport et l'emmagasinage des contrôleurs, il faudra veiller à respecter les conditions environnementales suivantes:

- température: de 20 °C à + 70 °C
- humidité relative: de 0% à 95 % (non condensante).

**Preparation pour l'installation** 

### Preparation pour l'installation

Le contrôleur est fourni dans un emballage de protec-tion spécial; si l'on constate des marques de dommages pouvant s'être produits pendant le transport, contacter aussitôt le bureau de vente local.

Pendant l'opération d'ouverture de l'emballage, veiller tout particulièrement à ne pas laisser tomber le contrôleur et à ne lui faire subir aucun choc. Ne pas jeter l'emballage dans la nature. Le matériel est entièrement recyclable et il est conforme aux directives CEE 85/399 en matière de protection de l'environnement.



Figure 1 Emballage du Contrôleur

### Installation

#### AVERTISSEMENT!



Pour la sécurité de l'utilisateur, le contrôleur ne doit être utilisé qu'en intérieur et doit être branché au moyen d'un câble d'alimentation à 3 fils (cf. tableau des pièces de rechange qui peuvent être commandées) avec une fiche du type approuvé au niveau international. Afin d'éviter toute décharge électrique et satisfaire aux conditions requises CE, il faut toujours utiliser ce câble d'alimentation, en introduisant la fiche dans une prise électrique pourvue d'un branchement approprié à la terre. A l'intérieur du contrôleur se développent de hautes tensions qui peuvent causer de graves dommages et même la mort. Avant d'effectuer toute opération d'installation ou d'entretien du contrôleur, le débrancher de la prise d'alimentation.

#### NOTE

Le contrôleur peut être installé sur une table ou à l'intérieur d'un rack prévu à cet effet. Il est en tout cas nécessaire que l'air de refroidissement puisse circuler librement à l'intérieur de l'appareil. Ne pas installer et/ou utiliser le contrôleur dans des milieux exposés à des agents atmosphériques (pluie, gel, neige), à des poussières, à des gaz de combat ainsi que dans des milieux explosifs ou à risque élevé d'incendie.

Pendant le fonctionnement, il est nécessaire de respecter les conditions environnementales suivantes :

- température: de +5 °C à +45 °C
- humidité relative: de 0 % à 95 % (non condensante).

Pour les autres connexions et pour l'installation des accessoires en option, voir la section "Technical Information".

### Utilisation

Dans ce paragraphe, on indique les principales procédures opérationnelles. Pour tous autres détails et pour les procédures concernant des connexions ou des éléments en option, se reporter au paragraphe "Use" de l'appendice "Technical Information".

Avant d'utiliser le contrôleur, effectuer toutes les connexions électriques et pneumatiques et se référer à la notice de la pompe connectée.

#### AVERTISSEMENT!



Pour éviter tous dommages aux personnes et à l'appareil, si la pompe est placée sur un plateau d'appui s'assurer que ce dernier est stable. Ne jamais faire fonctionner la pompe si la bride d'entrée n'est pas connectée au système ou n'est pas fermée à l'aide de la bride de fermeture.

#### NOTE

Laisser le connecteur de réenclenchement J1 connecté à sa barrette s'il n'est procédé à aucune connexion extérieure. La pompe à pré-vide et la pompe TwisTorr 305 FS peuvent être mises en marche simultanément.

### **Commandes, Indicateurs et Connecteurs**

On présente ci-dessous le tableau de commande du Contrôleur ainsi que les tableaux d'interconnexion. Pour de plus amples détails, se reporter à la section "Technical Information".

### **Description du Tableau avant**



Figure 2 Tableau avant du Contröleurs TwisTorr 305 FS Remote

1	Interrupteur rappelant sur l'afficheur les paramètres de cycle number, cycle time et pump life.
2	Interrupteur de sélection du mode LOW SPEED. Il n'est actif que lorsque le mode de commande est sélectionné depuis le tableau frontal. En le pressant une fois, la pompe tourne à vitesse "stand-by". En le pressant une deuxième fois, on désactive le mode LOW SPEED.
3	Interrupteur rappelant sur l'afficheur les paramètres de pump current, pump temperature, pump power et rotational speed. Il est toujours actif, indépendamment du mode de fonctionnement choisi. En pressant simultanément les interrupteurs 3 et 1 pendant 2 secondes au moins, on active un programme avec lequel il est possible de programmer certains paramètres opérationnels.
4	Interrupteur envoyant les commandes de START, STOP/RESET. Il n'est actif que lorsque le mode de commande est sélectionné depuis le tableau frontal. Une première pression de l'interrupteur active la phase de mise en marche; une deuxième pression provoque l'arrêt de la pompe. Si la pompe s'est arrêtée automatiquement à cause d'une panne, il faut presser cet interrupteur une première fois pour effectuer la mise à zéro du contrôleur et une deuxième fois pour remettre la pompe en marche.
5	Ecran alphanumérique à cristaux liquides: matrice de points, 2 lignes x 16 caractères.

#### TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

#### 3 Mode d'emploi

Utilisation



#### Figure 3 Tableau arrière du Contrôleur TwisTorr 305 FS Remote

1	Connecteur d'entrée des signaux logiques (le connecteur d'enclenchement est doté de la barrette de réenclenchement spéciale).
2	Connecteur signaux logiques en sortie et monitorage fréquence pompe plus sortie analogique programmables.
3	Connecteur de sortie alimentation (24 Vdc pour le ventilateur de refroidissement pompe, vent valve et calibre).
4	Module d'entrée alimentation contrôleur qui comprend les fusibles, la prise d'alimentation et le filtre ENC.
5	Interrupteur à rotation pour établir l'adresse du Profibus.
6	Profibus (facultatif).
7	Connecteur sériel pour contrôle à distance
8	Connecteur pompe.

### Procedures d'utilisation

### Allumage du Contrôleur

Pour allumer le contrôleur, il suffit d'introduire le câble d'alimentation dans la prise du réseau

### Mise en marche de la Pompe

Pour faire démarrer la pompe il faut habiliter l'entrée de interlock et appuyer sur la touche START du panneau avant.

### Arrêt de la Pompe

Pour arrêter la pompe, presser l'interrupteur STOP du tableau frontal.

### **Entretien**

Les contrôleurs de la série TwisTorr 305 FS Remote n'exigent aucun entretien. Toute opération doit être effectuée par un personnel agréé.

En cas de panne, il est possible de s'adresser au Service de réparation Agilent ou bien au "Agilent advance exchange service" qui permet d'obtenir un contrôleur régénéré à la place du contrôleur détragué.



AVERTISSEMENT Avant d'effectuer toute opération sur le contrôleur, débrancher le câble d'alimentation.

> En cas de mise au rebut d'un contrôleur, procéder à son élimination conformément aux réglementations nationales en la matière.

3 Mode d'emploi Mise au rebut

### Mise au rebut

Signification du logo "WEEE" figurant sur les étiquettes. Le symbole cidessous est appliqué conformément à la directive CE nommée "WEEE". Ce symbole (unique-ment valide pour les pays de la Communauté européenne) indique que le produit sur lequel il est appliqué NE doit PAS être mis au rebut avec les ordures ména-gères ou les déchets industriels ordinaires, mais passer par un système de collecte sélective. Après avoir vérifié les termes et conditions du contrat de vente, l'utilisateur final est donc prié de contacter le fournisseur du dispositif, maison mère ou revendeur, pour mettre en œuvre le processus de collecte et mise au rebut.



Pour en savoir plus, consulter : http://www.agilent.com/environment/product/index.shtml

### Messages d'erreur

Dans certains cas de panne, l'ensemble de circuits d'autodiagnostic du contrôleur présente certains mes-sages d'erreur indiqués dans le tableau ci-dessous.

#### Tab. 1

MESSAGE	DESCRIPTION	INTERVENTION
RUN UP TIME	La pompe n'a pas pu atteindre une valeur de vitesse > 700 Hz, dans les limites de la valeur attendue (temps de démarrage, qui est configurable).	Vérifiez la configuration du temps de démarrage : elle doit être définie en fonction du processus client. Vérifiez la charge de gaz à l'intérieur de la pompe et spécifiez-la en conséquence. Vérifiez que le rotor de la pompe peut tourner librement. Redémarrez la pompe.
CHECK CONNECTION TO PUMP	Dysfonctionnement de la connexion entre la pompe et le contrôleur. Ou bien La pompe a une température inférieure à a 0 °C.	S'assurer que le câble de connexion entre la pompe et le contrôleur et le contrôleur est bien fixé aux deux extrémités et qu'il n'est pas coupé. Presser deux fois l'interrupteur START pour réactiver la pompe.
WAITING INTERLOCK	Le signal d'interlock situé sur le connecteur P1 est actif à cause de la coupure du court-circuit entre le pin 3 et le pin 8 du connecteur J1 ou à cause de l'ouverture du signal d'interlock extérieur.	Rétablir le court-circuit entre le pin 3 et le pin 8 du connecteur P1 ou fermer le signal d'interlock extérieur.
PUMP OVERTEMP.	La température du corps de la pompe a dépassé la limite supérieure maximale autorisée, selon le type de gaz sélectionné (Ar : 50 °C ; N2 : 55 °C ; He : 60 °C).	Attendre que la température retourne au-dessous du seuil. Presser deux fois l'interrupteur START pour remettre la pompe en marche.
CONTROLLER OVERTEMP.	La température du contrôleur a dépassé 70 °C. Ou bien La température du radiateur du contrôleur est supérieure à 60 °C.	Attendre que la température retourne au-dessous du seuil. Presser deux fois l'interrupteur START pour remettre la pompe en marche.

#### 3 Mode d'emploi

Messages d'erreur

MESSAGE	DESCRIPTION	INTERVENTION
TOO HIGH Load	Pendant le fonctionnement normal (après la phase de mise en marche), le courant absorbé par la pompe est plus grand que celui qui a été programmé.	S'assurer que le rotor de la pompe a la possibilité de tourner librement. Presser deux fois l'interrupteur START pour remettre la pompe en marche.
SHORT CIRCUIT	Pendant le fonctionnement normal (après la phase de mise en marche), la connexion de sortie est en court-circuit.	Vérifier les connexions entre la pompe et le contrôleur. Presser deux fois l'interrupteur START pour remettre la pompe en marche.
SYSTEM OVERRIDE	La pompe a été arrêtée par un signal d'alerte provenant d'un contact éloigné.	Débrancher le câble d'alimentation du contrôleur et corriger la cause de l'alerte. Reconnecter le câble d'alimentation et presser deux fois l'interrupteur START pour remettre la pompe en marche.
OVERVOLTAGE	Il s'est produit une panne de la section d'alimentation du contrôleur, ou bien le contrôleur a reçu un faux signal.	Presser deux fois l'interrupteur START pour remettre la pompe en marche. Si le message se présente à nouveau, s'adresser à Agilent pour l'entretien.
RUN UP TIME	Interruption du démarrage.	Vérifiez la configuration du temps de démarrage. Elle doit être ajustée en fonction du processus du client. Vérifiez la quantité de charge de gaz qui s'écoule à l'intérieur de la pompe.



4

### Manual de istrucciones

Información general	
Almacenamiento	
Preparación para la instalación	50
Instalación	51
Uso	52
Mandos, Indicadores y Conectores	53
Descripción del panel frontal	53
Procedimientos de uso	
Encendido del controler	
Puesta en marcha de la Bomba	
Parada de la Bomba	55
Mantenimiento	
Eliminación	
Mensajes de error	

Traducción de las instrucciones originales



#### 4 Manual de istrucciones

Información general

### Información general

Este equipo se ha concebido para un uso profesional. El usuario deberá leer atentamente el presente manual de instrucciones y cualquier otra información suplementaria facilitada por Agilent antes de utilizar el equipo. Agilent se considera libre de cualquier responsabilidad debida al incumplimiento total o parcial de las instrucciones, al uso poco apropiado por parte de personal sin formación, a las operaciones no autorizadas o al uso que no cumpla con las normas nacionales específicas. Los controlers de la serie TwisTorr 305 FS Remote son convertidores de frecuencia, controlados por un microprocesador, realizados con componentes en estado sólido y con capacidad de autodiagnosis y autoprotección.

Características del controler:

- Operatividad frontal / remoto / serial
- Pilotaje de 24 Vdc del ventilador de refrigeración bomba
- Pilotaje vent valve
- Lectura velocidad bomba después de activación mando de parada (lectura velocidad de parada)
- Lectura de la presión
- Interfaz Profibus (opcional)
- Configuración automática tensión de entrada.

En los apartados siguientes se facilita toda la información necesaria para garantizar la seguridad del operador durante el uso del equipo. Una información más detallada se facilita en el Suplemento "Technical Information". Este manual utiliza los símbolos convencionales siguientes:



Los mensajes de advertencia atraen la atención del operador sobre un procedimiento o una operación específica que, al no realizarse correctamente, podría provocar graves lesiones personales.

#### ¡ATENCIÓN!

Los mensajes de atención se visualizan antes de procedimientos que, al no respetarse, podrían provocar daños al equipo.

NOTA Las notas contienen información importante extraída del texto.

### Almacenamiento

Durante el transporte y el almacenamiento de los controlers se deberá cumplir con las condiciones ambientales siguientes:

- temperatura: de -20 °C a +70 °C
- humedad relativa: 0 95 % (no condensadora)

#### 4 Manual de istrucciones

Preparación para la instalación

### Preparación para la instalación

El controler se suministra en un embalaje de protección especial; si se observan señales de daños, que podrían haberse producido durante el transporte, ponerse en contacto con la oficina de venta más cercana.

Durante la operación de desembalaje, prestar una atención especial a no dejar caer el controler y evitarle golpes. No dispersar el embalaje en el medio ambiente. El material es totalmente reciclable y cumple con la directiva CEE 85/399 para la preservación del medio ambiente.



Figura 1 Embalaje de los Controlers

### Instalación

#### ADVERTENCIA!



El controlador está diseñado sólo para su uso en interiores y para mantener la seguridad del usuario debe ser alimentado mediante un cable de 3 conductores (v. tabla de las piezas de recambio solicitables) con un tipo de clavija aprobado a nivel internacional. Para evitar el riesgo de descargas eléctricas y cumplir con los requisitos CE, utilizar siempre este cable de alimentación, conectando la clavija a una toma eléctrica dotada con una adecuada conexión a tierra. Dentro del controlador se desarrollan altas tensiones que pueden causar graves daños o la muerte. Antes de efectuar cualquier operación de instalación o mantenimiento del controlador, desconectarlo del enchufe de alimentación.

#### NOTA

El controler puede instalarse en una mesa o dentro de un rack específico. En cualquier caso, es necesario que el aire de refrigeración pueda circular libremente alrededor del aparato. No instalar y/o utilizar el controler en ambientes expuestos a agentes atmosféricos (lluvia, hielo y nieve), polvos, gases agresivos, en ambientes explosivos o con alto riesgo de incendio.

Durante el funcionamiento es necesario que se respeten las condiciones ambientales siguientes:

- temperatura: de +5 °C a +45 °C
- humedad relativa: 0 95 % (no condensadora).

Para otras conexiones y la instalación de los accesorios opcionales, véase la sección "Technical Information".

#### 4 Manual de istrucciones

Uso

### Uso

En este apartado se citan los procedimientos operativos principales. Para más detalles y para procedimientos que impliquen conexiones u opcionales especiales, les remitimos al apartado "Use" del anexo "Technical Informations".

Antes de usar el controler efectuar todas las conexiones eléctricas y neumáticas y consultar el manual de la bomba conectada.





Para evitar lesiones a las personas y al aparato, si la bomba está apoyada sobre una mesa cerciorarse que es estable. No poner en marcha nunca la bomba si la brida de entrada no está conectada al sistema o no está cerrada con la brida de cierre.

#### NOTA

El conector di cierre J1 ha de dejarse conectado con su conector puente si no se efectúa ninguna conexión exterior. La bomba pre-vacío y la bomba TwisTorr 305 FS pueden encenderse simultáneamente.

### Mandos, Indicadores y Conectores

A continuación se ilustran el panel de mando del controler y los paneles de interconexión. Para más detalles consultar la sección "Technical Information".

### Descripción del panel frontal



Figura 2 Panel frontal del Controller TwisTorr 305 FS Remote

1	Pulsador para que aparezcan en el display los parámetros cycle number, cycle time y pump life
2	Pulsador para la selección del modo LOW SPEED. Está activado sólo cuando está seleccionado el modo de mando del panel frontal. Apretando una vez, la bomba gira a velocidad "stand-by". Apretándolo una vez más se desactiva el modo LOW SPEED.
3	Pulsador para que aparezcan en el display los parámetros pump current, pump temperature, pump power y rotational speed. Está siempre activado independientemente del modo de funcionamiento elegido. Apretando juntos los pulsadores 3 y 1 durante 2 segundos por lo menos, se activa un programa con el cual se pueden programar algunos parámetros operativos.
4	Pulsador para enviar los mandos de START, STOP/RESET. Está activo sólo cuando se selecciona el modo de mando del panel frontal. Apretándolo una vez se activa la fase de puesta en marcha; apretándolo otra vez se para la bomba. Si la bomba se ha parado automáticamente a causa de una avería, hay que apretar este pulsador primero una vez para efectuar el reset del controler y la segunda vez para volver a poner en marcha la bomba.
5	Display alfanumérico de cristales líquidos: matriz de puntos, 2 líneas x 16 caracteres.

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

#### 4 Manual de istrucciones

Uso



#### Figura 3Panel trasero del controler TwisTorr 305 FS Remote

1	Conector de entrada de las señales lógicas (el conector de acoplamiento se suministra con el conector puente específico de cierre).
2	Conector señales lógicas en salida y monitoreo frecuencia bomba y salida analógica programable.
3	Conector de salida alimentación (24 Vdc para el ventilador de refrigeración bomba, vent valve y calibre).
4	Módulo de entrada alimentación controler con fusibles, toma de alimentación y filtro ENC.
5	Conmutador de rotación para configurar la dirección del Profibus.
6	Profibus (opcional).
7	Conector serial para control remoto.
8	Conector bomba.

### Procedimientos de uso

### Encendido del controler

Para encender el controler es suficiente introducir el cable de alimentación en la toma de red.

### Puesta en marcha de la Bomha

Para activar la bomba es necesario habilitar la entrada de interlock y pulsar el botón START situado en el panel frontal.

### Parada de la Bomba

Para detener la bomba hay que apretar el pulsador STOP del panel frontal.

### **Mantenimiento**

Los controlers de la serie TwisTorr 305 FS Remote no necesitan ningún mantenimiento. Cualquier operación ha de ser efectuada por personal autorizado. En caso de avería es posible utilizar el servicio de reparación Agilent o del "Agilent advance exchange service", que permite obtener un controler regenerado en vez del averiado.



ADVERTENCIA! Antes de efectuar cualquier operación en el controler desenchufar el cable de alimentación.

> En caso de que un controler se tenga que desguazar, efectuar su eliminación respetando las normas nacionales específicas.

#### 4 Manual de istrucciones

Eliminación

### Eliminación

Significado del logotipo "WEEE" presente en las etiquetas. El símbolo que se indica a continuación, es aplicado en observancia de la directiva CE denominada "WEEE". Este símbolo (válido sólo para los países miembros de la Comunidad Europea) indica que el producto sobre el cual ha sido aplicado, NO debe ser eliminado junto con los residuos comunes sean éstos domésticos o industriales, y que, por el contrario, deberá ser sometido a un procedimiento de recogida diferenciada. Por lo tanto, se invita al usuario final, a ponerse en contacto con el proveedor del dispositivo, tanto si éste es la casa fabricante o un distribuidor, para poder proveer a la recogida y eliminación del producto, después de haber efectuado una verificación de los términos y condiciones contractuales de venta.



Para obtener más información, consulte: http://www.agilent.com/environment/product/index.shtml

### Mensajes de error

En algunos casos de avería los circuitos de autodiagnosis del controler presenta algunos mensajes de error detallados en la tabla siguiente.

#### Tab. 1

MENSAJE	DESCRIPCIÓN	ACCIÓN CORRECTIVA
RUN UP TIME	La bomba no ha podido alcanzar un valor de velocidad >700 Hz, dentro del valor esperado (Tiempo puesta en funcionamiento, que es configurable).	Compruebe la configuración del tiempo de puesta en funcionamiento: debería establecerse según el proceso del cliente. Compruebe la carga de gas que fluye dentro de la bomba y ajuste de manera adecuada. Compruebe que el rotor de la bomba pueda girar libremente. Reinicie la bomba.
CHECK CONNECTION TO PUMP	Mal funcionamiento en la conexión entre la bomba y el Controler. O bien La bomba tiene una temperatura inferior a 0 °C.	Comprobar que el cable de conexión entra en la bomba y el controler está bien fijado por ambos extremos y no está interrumpido. Apretar dos veces el pulsador START para volver a poner en marcha la bomba.
WAITING INTERLOCK	Está activa la señal de interlock presente en el conector P1 a causa de la interrupción del cortocircuito entre el pin 3 y el pin 8 del conector J1, o a causa de la apertura de la señal de interlock externo.	Eliminar el cortocircuito entre el pin 3 y el pin 8 del conector P1, o cerrar la señal de interlock exterior.
PUMP OVERTEMP.	La temperatura del cuerpo de la bomba ha excedido el límite máximo permitido, que depende del tipo de gas seleccionado (Ar: 50°C; N2: 55°C; He: 60°C)	Esperar a que la temperatura vuelva por debajo del umbral. Apretar dos veces el pulsador START para volver a poner en marcha la bomba.
CONTROLLER OVERTEMP.	La temperatura del controler ha superado los 70 °C. O bien La temperatura del radiador del controler es superior a 60 °C.	Esperar a que la temperatura vuelva por debajo del umbral. Apretar dos veces el pulsador START para volver a poner en marcha la bomba.

#### 4 Manual de istrucciones

Mensajes de error

MENSAJE	DESCRIPCIÓN	ACCIÓN CORRECTIVA
TOO HIGH Load	La corriente absorbida por la bomba es superior a la programada.	Comprobar que el rotor de la bomba tiene la posibilidad de girar libremente. Apretar dos veces el pulsador START para volver a poner en marcha la bomba.
SHORT CIRCUIT	Durante el funcionamiento normal (tras la fase de puesta en marcha) la conexión de salida está en cortocircuito.	Comprobar las conexiones entre la bomba y el controler. Apretar dos veces el pulsador START para volver a poner en marcha la bomba.
SYSTEM OVERRIDE	La bomba ha sido parada por una señal de emergencia procedente de un contacto remoto.	Desenchufar el cable de alimentación del controler y corregir la causa de la emergencia. Volver a conectar el cable de alimentación y apretar dos veces el pulsador START para volver a poner en marcha la bomba.
OVERVOLTAGE	Se ha producido una avería en la sección de alimentación del controler o el controler ha recibido una señal espurio.	Apretar dos veces el pulsador START para volver a poner en marcha la bomba. Si el mensaje se vuelve a presentar dirigirse a Agilent para el mantenimiento.
RUN UP TIME	Tiempo de arranque agotado.	Controlar la configuración del tiempo de arranque. Debe ajustarse según el proceso del cliente. Comprobar la cantidad de carga de gas que fluye dentro de la bomba.



原始说明的翻译



### 5 使用说明

一般信息

### 一般信息

本设备供专业人员使用。在操作设备之前,用户应阅读本说明书和安捷伦提供的任何其他信息。安捷伦对因不遵守这些指示、未经培训的人员不当使用、未经授权干扰设备或任何违反特定国家标准规定的行为而发生的任何事件概不负责。

TwisTorr 305 FS 遥控器是微处理器控制的固态变频器,具有自诊断和 自我保护功能。

控制器功能:

前部/远程/串行操作

24Vdc 泵风扇冷却驱动器

通风阀驱动

停止后泵速度读数 (停止速度读数)

压力读数

输入电压自动设置。

profibus接口(可选)

以下各段包含使用设备时确保操作员安全的所有必要信息。 附录"技术 信息"中提供了详细信息。



本手册使用以下标准协议:



运输和存储控制器时,应满足以下环境要求:

- 温度: -20 °C 至 + 70 °C
- 相对湿度: 0-95% (无冷凝)

### 5 使用说明 安装准备

### 安装准备

控制器具有特殊的保护性包装。如果这个包装在运输过程中出现损坏的迹象,请联系当地的销售办事处。打开控制器包装时,请确保不要 摔落控制器或使其受到任何形式的撞击。请勿以未经授权的方式处置 包装材料。该材料是100%可回收的,并且符合EEC指令85/399。



图1 控制器包装

安装



该控制器仅供室内使用,必须使用 3 线电源线供电(参见可订购部件 表)和插头(得到国际认可),以确保用户的安全。将此电源线和插头 与正确接地的电源插座一起使用,以避免电击并满足 CE 要求。 控制器 中产生的高压会导致严重的人身伤害甚至死亡。 维修本机之前,请断 开输入电源线的连接。

注意

TwisTorr 305 FS 遥控器可以用作台式装置或机架模块,但必须放置在 适当的位置,以使自由的空气可以流过孔。请勿在暴露于大气物质 (雨、雪、冰)、灰尘、腐蚀性气体或爆炸性环境或高火灾风险的环境 中安装或使用控制器。

在操作过程中,必须遵守以下环境条件:

- 温度:从+5°C至+45°C;
- 相对湿度: 0-95% (无冷凝)。

有关上述和其他连接的详细信息以及安装选项的详细信息,请参阅附录 "技术信息"。



使用

## 使用

本段描述了基本的操作程序。 附录"技术信息"的"使用"段落中提供了涉及可选连接或选件的详细信息和操作过程。

在操作TwisTor 305 FS 遥控器之前,请进行所有真空歧管和电气连接,并参考TwisTorr 305 FS 泵说明书。



注意

如果未进行外部连接,则输入信号 J1 连接器应保持在包括运输链接在内的位置。前级泵和 TwisTorr 305 FS 泵可以同时打开。

### 控件、指示器和连接器

以下段落说明了控制器控制面板和互连面板。有关更多详细信息,可参考附录的"技术信息"。

### 前面板说明



#### 图 2 控制器TwisTor 305 FS 远程前面板

1	键盘按钮可在显示屏上调出循环次数、循环时间和泵寿命。
2	用于选择低速模式的键盘按钮。仅当选择了前面板操作时,它才会处于活动状态。按 下一次,泵以"备用"速度运行。要取消选择模式,请再次按下按钮。
3	键盘按钮可调用显示屏上的泵电流、泵温、泵功率和转速。无论选择何种操作模式, 它始终处于活动状态。如果将按钮3和1按下至少2秒钟,,则可以将控制器置于一 个例程中,以便对一些操作参数进行编程。
4	用于选择"开始"、"停止"/"重置"模式的键盘按钮。仅当选择了前面板操作时,它才会处于活动状态。在开始阶段开始后按;如果再次按下,则会停止泵。如果 泵因故障自动停止, 则必须按下此按钮一次以重置控制器,而后再次按下按钮以重新启动泵。
5	LCD 背光字母数字显示: 点阵 2 行 x16 个字符。

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

65/190

#### 5 使用说明

使用



#### 图 3 控制器TwisTor 305 FS 远程后面板

1	逻辑输入信号连接器(连接链路提供的配对连接器)。
2	逻辑输出信号连接器和泵频率监视器加上可编程模拟输出。
3	功率输出连接器(24 Vdc 用于泵冷却风扇、排气阀和仪表)。
4	控制器电源输入模块由电源保险丝、电源插座和 EMC 滤波器组成。
5	用于 Profibus 地址设置的旋转开关。
6	Profibus(可选)。
7	远程控制串行连接器。
8	泵电缆(5 米长)。



### 使用流程

### 控制器启动

如要启动控制器,请将电源线与合适的电源连接。

### 启动泵

如要启动泵,请确认互锁输入,然后按控制器前面板上的"开始"按钮。

### 停止泵

如要关闭泵,请按控制器前面板上的"停止"按钮。

### 维护

TwisTorr 305 FS 远程系列控制器不需要任何维护。在控制器上执行的 任何工作必须由授权人员执行。

发生故障时,可以使用安捷伦维修服务。通过安捷伦提前更换控制器。

#### 警告! 在对控制器执行任何工作之前,请断开控制器与电源的连接。



如果要报废泵,则必须按照特定的国家标准进行处理。

### 5 使用说明

处置方式

### 处置方式

#### 标签中"WEEE"徽标的含义

以下符号根据 EC WEEE (废弃电气和电子设备)指令进行应用。 该符 号(**仅在欧洲共同体国家有效**)表示其适用的产品不得与普通家庭或工 业废物一起处理,而必须送往差别化废物收集系统。 因此,请最终用 户在检查合同销售条款和条件后,联系设备的供应商(无论是母公司还 是零售商)以启动收集和处置流程。



有关详细信息,请参阅:

http://www.agilent.com/environment/product/index.shtml



### 错误消息

对于特定类型的故障,控制器将自行诊断错误,并显示下表中描述的消息。

表 1

消息	描述	修复操作
运行 时 间	泵无法在期望值(运行时间,可 配置)内达到〉700 Hz 的速度 值。	检查运行时间设置:应根据客 户流程相应设置。检查泵内流 动气体负载并相应地进行调 整。检查泵转子是否可以自由 旋转。重新启动泵。
检查与泵 的连接	泵和控制器之间的连接错误。 或 泵的温度低于0 °C	检查控制器和泵之间的连接。 按下"开始"按钮两次以启动 泵。
等待互锁	P1 连接器的互锁信号是通过中断 J1 连接器的引脚 3 和 8 之间的链 接来激活的,或者是因为外部互 锁信号已打开。	重置 P1 连接器引脚 3 和引脚 8 之间的短路,或关闭外部互 锁信号。
泵温度过 高	泵体的温度已超过允许的最大上 限,具体取决于所选气体的类型 (Ar:50°C;№: 55°C;He: 60°C)	等待温度降至阈值以下。按下" 开始"按钮两次以启动泵。
控制器温 度过高	控制器环境温度超过 70°C。 或 控制器的散热器温度高于 60°C。	等待温度降至阈值以下。按下" 开始"按钮两次以启动泵。

#### 5 使用说明

错误消息

消息	描述	修复操作
过高 负载	泵抽取的电流高于编程电流。	检查泵转子是否可自由旋转。 按下"开始"按钮两次以启动 泵。
短路	启动阶段后,输出连接短路。	检查泵和控制器之间的连接和 短路。 按下"开始"按钮两次 以启动泵。
系统 覆盖	通过远程触点提供的紧急停止信 号来停止泵。	拆下控制器电源线并检查紧急 情况。然后重新连接电源线, 然后按"开始"按钮两次以启 动泵。
电压	控制器电源电路有故障,或控制 器收到尖峰信号。	按下"开始"按钮两次以启动 泵。如果消息仍然存在,请致 电安捷伦服务。
运行时间	超时	检查运行时间的设置。 必须根 据客户流程对其进行调整。 检 查泵内流动的气体负荷量



使用方法

概要情報	72
保管	73
取り付けの準備	74
取り付け	
使用	76
コントロール、指示器、コネクター	77
フロントパネル説明	77
使用手順	
コントローラーの起動	79
ポンプの開始	79
ポンプの停止Pump Shutdown	79
メンテナンス	
廃棄	80
エラーメッセージ	81

説明書原文の翻訳



Agilent Technologies

# 使用方法 概要情報

### 概要情報

この装置は技術者による使用を対象としています。使用者は、この取扱 説明書とAgilentにより提供される他の追加情報もあわせて、装置を操作 する前に全てお読みください。Agilentは、部分的であってもこれらの取 扱説明に従わない場合や、訓練されていない人による不適切な使用、装 置への認められていない干渉、または特定の国家規格の規定に相いれな いいかなる行動によって生じたいかなる事態にも責任を負いません。

TwisTorr 305 FS リモートコントローラーは、マイクロ・プロセッサーに より制御され、ソリッドステートの自己診断機能と自己防護機能がつい た周波数変換器です。

コントローラーの特徴:

- フロント/リモート/直列操作
- 24Vdc ポンプ用ファン冷却ドライブ
- 通気弁ドライブ
- 停止コマンド後のポンプ速度の計測(停止速度の計測)
- 圧力計測
- 入力電力の自動設定
- Profibus インターフェース (オプション)

次の章は、装置を使用中に操作者の安全を保証するために必要な全ての 情報を含みます。詳細情報は、「技術的情報」の追記に記載されていま す。


この説明書は下記の規格プロトコルを使用しています:



「注」は、テキストからの重要な情報を含みます。

### 保管

- コントローラーを輸送、保存する時は、下記の環境仕様を超過してはいけません:
- 温度範囲: -20 °C から + 70 °C まで
- 相対湿度範囲: 0 から 95 %まで(結露なし)

#### 6 使用方法

取り付けの準備

### 取り付けの準備

コントローラーは、特殊な保護梱包で提供されます。もしこの梱包に 移送の間に生じた可能性のある破損が見受けられる場合、現地販売事 務所に問い合わせてください。コントローラーの梱包を開ける際に は、落とさない、またはいかなる形での衝撃を与えないようにしてく ださい。不適切な方法で梱包材料を破棄しないでください。梱包材料 は100%リサイクルが可能で、EEC指令85/399に従っています。



図1 コントローラーの梱包

#### 取り付け



コントローラーは、屋内のみの使用が対象で、使用者の安全のために 3本のワイヤー電源コード(注文可能な部品を参照)とプラグ(国際 的に認可されたもの)で電源が供給されなければいけません。電気シ ョックを避け、また CE 要件を満たすために、この電源コードとプラ グを適切に設置された電源ソケットと合わせて使用してください。

コントローラー内で発達した高電圧は、重大な損傷や死亡を引き起こ す可能性があります。ユニットを点検する前に、入力電源ケープルの 接続を断ってください。

注 TwisTorr 305 FS リモートコントローラーは、ベンチユニットまたはラッ クモジュールとして使用できますが、穴を通して自由に通気が取れるよ うに所定の位置に設置されなければいけません。大気物質(雨、氷、 雪)、ちり・ホコリ、侵略的ガスなどが露出する環境、または爆発の 可能性がある環境、または燃えやすい環境下では、取り付けまたは使 用しないでください。

操作中、下記の環境状況は遵守されなければいけません:

- 温度: +5 °C から+45 °Cまで;
- 相対湿度: 0-95% (結露なし)

上記についてと他の接続に関して、またオプションの取り付けについて の詳細な情報は、「技術的情報」の追記をご覧ください。



## 使用

この章は、基本操作手順を説明しています。オプション的な接続、またはオプションについての詳細な情報と操作手順は、「技術的情報」 の追記の「使用」の章に記載されています。

TwisTorr 305 FSリモートコントローラーを操作する前に、全ての真空マニホールドと電気接続を作成し、TwisTorr 305 FS ポンプの説明書をお読みください。



人体への損傷や装置への損害を避けるために、もしポンプがテーブルの上に置かれている場合には安定していることを確かめてください。 もしポンプ吸入口がシステムに接続されていない、または抜け落ちている場合には、TwisTorr 305 FS ポンプを決して操作しないでください。

注

入力信号 J1 コネクターは、もし外部接続が作成された場合には移送リ ンクを含む位置に置かれるようにしてください。プレポンプと TwisTorr 305 FS ポンプは同時にオンに切り替えられなければなりません。



### コントロール、指示器、コネクター

次の章は、コントローラーのコントロールパネルと相互接続パネルを 図解しています。詳細情報は、「技術的情報」の追記に記載されてい ます。

### フロントパネル説明



図2 コントローラー TwisTorr 305 FS リモートフロントパネル

1	サイクル数、サイクル時間、ポンプの寿命をディスプレイ上に表示させるキーボードプッシュボタン。
2	低速モードの選択用キーボードプッシュボタン。フロントパネル操作が選択された時のみアクティ ブになります。1回押すとポンプは「待機」速度で作動します。モードの選択を解除するには、プ ッシュボタンを再度押してください。
3	ポンプの電流、ポンプの温度、ポンプの電源と回転速度をディスプレイ上に表示させるキーボード プッシュボタン。選択された操作モードに関わらず、これは常にアクティブです。プッシュボタン 3と1は、最低でも2秒間一緒に押された場合に、コントローラーはいくつかの操作パラメーター をプログラム可能なルーチン下におかれます。
4	「開始、停止/リセット」モードの選択用キーボードプッシュボタン。フロントパネル操作が選択 された場合のみアクティブになります。1回押すと起動フェーズが開始します;もし再度押すとポ ンプを停止します。もしポンプが障害・故障により自動的に停止された場合、コントローラーをリ セットするには1回、ポンプをリスタートするには2回このプッシュボタンを押してください。
5	LCD バックライトの英数字ディスプレイ:ドットマトリックス 2 列 x 16 文字。

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

77/190

#### 6 使用方法

使用



図3 コントローラーTwisTorr 305 FS リモートリアパネル

1	ロジック入力信号コネクター(リンクと共に供給される組み合わせコネクター)。
2	ロジック出力信号コネクターとポンプ周波数モニター、また プログラム可能なアナ ログ出力。
3	電力出力コネクター(ポンプ冷却ファン、通気弁と計器用の24 Vdc)
4	主要ヒューズ、主要ソケットと EMC フィルターから構成されるコントローラー電力 エントリーモジュール。
5	Profibus のアドレス設定用回転スイッチ。
6	Profibus (オプション)。
7	リモートコントロールシリアルコネクター。
8	ポンプケーブル(長さ 5m)。



#### 使用手順

#### コントローラーの起動

コントローラーを起動するには、電源ケーブルを適切な電源プラグに 接続してください。

#### ポンプの開始

ポンプを開始するには、インターロック入力を確認して、コントロー ラーフロントパネル上の「開始」のプッシュボタンを押してくださ い。

### ポンプの停止 Pump Shutdown

ポンプを停止するには、コントローラーフロントパネル上の「停止」 のプッシュボタンを押してください。

#### メンテナンス

TwisTorr 305 FS リモートシリーズコントローラーは、いかなるメンテナ ンスも必要としません。コントローラーになされるいかなる作業も、認 可された者により遂行されなければなりません。

障害・故障が起こった際には、Agilentの修理サービスを利用すること もできます。コントローラーの代替品は、Agilentを通したアドバンス エクスチェンジのサービスを基に利用可能です。



コントローラー上にいかなる作業を遂行する前に、供給源から接続を 断ってください。

もしポンプを廃棄する場合には、特定の国の規定に基づき廃棄されな ければなりません。





#### ラベル上に表示された「WEEE」ロゴの意味

下記の記号はEC WEEE指令(電気電子廃棄物指令)に従い適用された ものです。この記号(欧州諸共同体でのみ有効)は、製品は通常の家 庭ゴミまたは産業廃棄物と一緒に廃棄されてはいけないこと、また分 化された廃棄物収集システムへ送られなければいけないことを示しま す。従って、エンドユーザーは、販売の契約条件を確認した後に、収 集と廃棄工程を始めるために、親会社かもしくは小売業者であろう と、機器の供給者へ問い合わせることが推奨されます。



さらなる情報は下記をご確認ください:

http://www.agilent.com/environment/product/index.shtml

## エラーメッセージ

あるタイプの機能不全に対し、コントローラーはエラーを自己診断 し、下記に説明されるメッセージが表示されます。

タブ.1

メッセー ジ	説明	修理動作
起動時間	ポンプは、期待値内で>700 Hz の速度値に達することができま せんでした(起動時間は設定可 能です)。	起動時間の設定の確認:カスタマー手 順に従って設定することが推奨されま す。ポンプ内に流入されるガス量を確 認し、それに従って調節してくださ い。 ポンプのローターが障害なく回転でき るか確認してください。 ポンプをリスタートしてください。
ポンプへ の接続を 確認	ポンプとコントローラー間の誤 った接続。 または ポンプの温度が <b>0℃</b> 以下。	コントローラーとポンプ間の接続を確 認してください。 ポンプを開始するには、「開始」のプ ッシュボタンを2回押してください。
インター ロックを 待機	P1 コネクターのインターロッ ク信号は、J1 コネクターのピ ン3と8の間のリンクの中断に より、もしくは外部のインター ロック信号が開いていることに よりアクティベートされます。	J1 コネクターのピン3と8の間の短絡 をリセットするか、または外部のイン ターロック信号を閉じてください。
ポンプの 過剰温度	選択されたガスのタイプにより ますが、ポンプ本体の温度が許 容される最大温度を超えていま す。 (Ar: 50°C; N2: 55°C; He: 60°C)	温度が閾値以下になるまでお待ちくだ さい。 ポンプを開始するには、「開始」のプ ッシュボタンを2回押してください。
コントロ ーラーの 過剰温度	コントローラーの環境温度が 70℃を超えています。 または コントローラーのラジエーター 温度が 60℃以上です。	温度が閾値以下になるまでお待ちくだ さい。 ポンプを開始するには、「開始」のプ ッシュボタンを2回押してください。

#### 6 使用方法

エラーメッセージ

メッセー ジ	説明	修理動作
過剰負荷	ポンプにより引き出された電流量 がプログラムされたものよりも高 くなっています。	ポンプのローターが障害なく 回転できるか確認してくださ い。ポンプを開始するには、 「開始」のプッシュボタンを 2回押してください。
短絡	起動フェーズの後、出力接続がシ ョートしました。	接続を確認してください。
システム オーバー ライド	ポンプは、リモートコンタクト経 由で提供された緊急停止信号によ り停止されました。	コントローラーの電源ケーブ ルを抜き、緊急状態を確認し てください。それから電源ケ ーブルを再接続し、ポンプを 開始するには、「開始」のプ ッシュボタンを2回押してく ださい。
過電圧	コントローラーの電源供給回路が 故障しているか、またはコントロ ーラーがスパイクを受けました。	ポンプを開始するには、「開 始」のプッシュボタンを2回 押してください。 もしメッセージが消えない場 合、Agilent に問い合せてくだ さい。
起動時間	起動時間切れ	起動時間の設定の確認。カス タマー手順に従って調整して ください。ポンプ内に流入さ れるガス量を確認してくださ い。



General Information	84
Storage	85
Preparation for Installation	86
Installation	87
Use	88
Controls, Indicators and Connectors	89
Front Panel Description	89
Use Procedure	91
Controller Startup	91
Starting the Pump	91
Pump Shutdown	91
Maintenance	91
Disposal	92
Error Messages	93

**Original Instructions** 



**General Information** 

### **General Information**

This equipment is destined for use by professionals. The user should read this instruction manual and any other additional information supplied by Agilent before operating the equipment. Agilent will not be held responsible for any events occurring due to non-compliance, even partial, with these instructions, improper use by untrained persons, non-authorised interference with the equipment or any action contrary to that provided for by specific national standards.

The TwisTorr 305 FS Remote Controllers are micro-processor-controlled, solid-state, frequency converter with self-diagnostic and self-protection features.

**Controller features:** 

- Front / Remote / Serial Operation
- 24Vdc pump fan cooling drive
- Vent valve drive
- Pump speed reading after stop command (stop speed reading)
- Pressure reading
- Input voltage auto setting.
- Profibus interface (optional)

The following paragraphs contain all the information necessary to guarantee the safety of the operator when using the equipment. Detailed information is supplied in the appendix "Technical Information".



This manual uses the following standard protocol:

WARNING!	The warning messages are for attracting the attention of the operator to a particular procedure or practice which, if not followed correctly, could lead to serious injury.
CAUTION!	The caution messages are displayed before procedures which, if not followed, could cause damage to the equipment.

**NOTE** The notes contain important information taken from the text.

### Storage

When transporting and storing the controllers, the following environmental requirements should be satisfied:

- temperature: from -20 °C to + 70 °C
- relative humidity: 0 95 % (without condensation)

#### 7 Instructions for Use

**Preparation for Installation** 

### **Preparation for Installation**

The controller is supplied in a special protective packing. If this shows signs of damage which may have occurred during transport, contact your local sales office. When unpacking the controller ensure that it is not dropped or subjected to any form of impact. Do not dispose of the packing materials in an unauthorized manner. The material is 100 % recyclable and complies with EEC Directive 85/399.



Figure 1 Controller packing

#### Installation



The controller is designed for indoor use only and must be powered with 3wire power cord (see orderable parts table) and plug (internationally approved) for user's safety. Use this power cord and plug in conjunction with a properly grounded power socket to avoid electrical shock and to satisfy CE requirements. High voltage developed in the controller can cause severe injury or death. Before servicing the unit, disconnect the input power cable.

NOTE

TwisTorr 305 FS Remote Controller can be used as a bench unit or a rack module, but it must be positioned so that free air can flow through the holes. Do not install or use the controller in an environment exposed to atmospheric agents (rain, snow, ice), dust, aggressive gases, or in explosive environments or those with a high fire risk.

During operation, the following environmental conditions must be respected:

- temperature: from +5 °C to +45 °C;
- relative humidity: 0 95 % (without condensation).

See the appendix "Technical Information" for detailed Information about the above mentioned and the other connections, and about the options installation.

#### 7 Instructions for Use

Use

### Use

This paragraph describes the fundamental operating procedures. Detailed information and operating procedures that envolve optional connection or option are supplied in the paragraph "USE" of the appendix "Technical Information".

Make all vacuum manifold and electrical connections and refer to TwisTorr 305 FS pump instruction manual before operating the TwisTorr 305 FS Remote Controller.

#### WARNING!



To avoid injury to personnel and damage to the equipment, if the pump is laying on a table make sure it is steady. Never operate the TwisTorr 305 FS pump if the pump inlet is not connected to the system or blanked off.

#### NOTE

The input signal J1 connector should be left in position including the shipping links if no external connections are made. The forepump and TwisTorr 305 FS pump can be switched on at the same time.

### **Controls, Indicators and Connectors**

The following paragraph illustrates the Controller control panel and interconnection panel. More details are contained in the appendix "Technical Information".

#### 5 LS ACULMTECHNOLOGIES 1 VACULMTECHNOLOGIES 1 VACULMTECHNOLOGIES 1 VACULMTECHNOLOGIES 1 VACULMTECHNOLOGIES NORA 2 VACULMTECHNOLOGIES NORA 1 VACULATION 1 VACU

## **Front Panel Description**

Figure 2 Controller TwisTorr 305 FS Remote Front Panel

1	Keyboard push-button to recall on the display the cycle number, cycle time and pump life.
2	Keyboard push-button for LOW SPEED mode selection. It is active only when the front panel operation has been selected. Pressed once, the pump runs at "stand-by" speed. To unselect the mode, press the push-button again.
3	Keyboard push-button to recall on the display the pump current, pump temperature, pump power and rotational speed. It is always active regardless of the operating mode selected. Push-buttons 3 and 1, if pressed together for at least 2 seconds, put the controller in a routine where it is possible to program some operation parameters.
4	Keyboard push-button for START, STOP/RESET mode selection. It is active only when the front panel operation has been selected. By pressing once the starting phase begins; if pressed again it stops the pump. If the pump has been stopped automatically by a fault, this push-button must be pressed once to reset the controller and a second time to restart the pump.
5	LCD back-lighted alphanumeric display: dot matrix 2 lines x 16 characters.

#### TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

#### 7 Instructions for Use

Use



Figure 3Controller TwisTorr 305 FS Remote Rear panel

1	Logic input signals connectors (mating connector supplied with link).
2	Logic output signals connector and pump frequency monitor plus programmable analog output.
3	Power output connector (24 Vdc for pump cooling fan, Vent Valve and Gauge).
4	Controller power entry module consisting of mains fuses, mains socket and EMC filter.
5	Rotary switches for Profibus address setting.
6	Profibus (Optional).
7	Remote control serial connector.
8	Pump cable (5m long).

### **Use Procedure**

### **Controller Startup**

To startup the controller plug the power cable into a suitable power source.

### **Starting the Pump**

To start the pump, confirm the interlock input and press the START pushbutton on the controller front panel.

### **Pump Shutdown**

To shutdown the pump press the STOP push-button on the controller front panel.

#### Maintenance

The TwisTorr 305 FS Remote series controller does not require any maintenance. Any work performed on the controller must be carried out by authorized personnel.

When a fault has occurred it is possible to use the Agilent repair service. Replacement controllers are available on an advance exchange basis through Agilent.



Before carrying out any work on the controller, disconnect it from the supply.



If a pump is to be scrapped, it must be disposed off in accordance with the specific national standards.

#### 7 Instructions for Use

Disposal

### Disposal

#### Meaning of the "WEEE" logo found in labels

The following symbol is applied in accordance with the EC WEEE (Waste Electrical and Electronic Equipment) Directive. This symbol **(valid only in countries of the European Community)** indicates that the product it applies to must NOT be disposed of together with ordinary domestic or industrial waste but must be sent to a differentiated waste collection system. The end user is therefore invited to contact the supplier of the device, whether the Parent Company or a retailer, to initiate the collection and disposal process after checking the contractual terms and conditions of sale.



For more information refer to: <u>http://www.agilent.com/environment/product/index.shtml</u>

## **Error Messages**

For a certain type of failure, the controller will self-diagnose the error and the messages described in the following table are displayed.

#### Tab. 1

MESSAGE	DESCRIPTION	REPAIR ACTION
RUN UP TIME	The pump has not been able to reach a speed value >700 Hz, within the expected value (Run Up Time, which is configurable).	Check for the Run UP Time set-up: it should be set accordingly to the customer process. Check for the gas load flowing inside the pump and adjust it accordingly. Check that the pump rotor can rotate freely. Restart the pump.
CHECK CONNECTION TO PUMP	Wrong connection between the pump and the controller. Or The pump's temperature is below 0 °C.	Check connection between controller and pump. Press the START push- button twice to start the pump.
WAITING INTERLOCK	The interlock signal of P1 connector is activated by an interruption of the link between pin 3 and 8 of J1 connector, or because the external interlock signal is open.	Reset the short circuit between pin 3 and pin 8 of P1 connector, or close the external interlock signal.
PUMP OVERTEMP.	The temperature of the pump body has exceeded the maximum upper limit allowed, dependent on the type of gas selected (Ar: 50°C; N2: 55°C; He: 60°C)	Wait until the temperature decrease below threshold value. Press the START push- button twice to start the pump.
CONTROLLER OVERTEMP.	The controller environment temperature exceeds 70 °C. Or The controller's radiator temperature is above 60 °C.	Wait until the temperature decrease below threshold value. Press the START push- button twice to start the pump.

#### 7 Instructions for Use

**Error Messages** 

MESSAGE	DESCRIPTION	REPAIR ACTION
TOO HIGH Load	The current drawn by the pump is higher than programmed.	Check that the pump rotor is free to rotate. Press the START push-button twice to start the pump.
SHORT CIRCUIT	After the starting phase the output connection is shorted.	Check connections and shortages between pump and controller. Press the START push-button twice to start the pump.
SYSTEM OVERRIDE	The pump is stopped by an emergency stop signal provided via a remote contact.	Remove the controller power cable and check the emergency condition. Then reconnect the power cable and press the START push- button twice to start the pump.
OVERVOLTAGE	Controller power supply circuitry is faulty, or the Controller received a spike.	Press the START push- button twice to start the pump. Should the message still be present, call the Agilent service.
RUN UP TIME	Run Up Time out.	Check for the Run Up Time set-up. It has to be adjusted accordingly to the customer process. Check the amount of the gas load which is flowing inside the pump.

#### TwisTorr 305 FS Remote Controller User Manual



# Technical Information

TwisTorr 305 FS Remote Controller Description	97
Controller Specifications	99
Controller Outline	100
Controller Connection	101
J6 – Fan	101
J7 – Vent	102
P1 – Input	103
J1 – Output	104
R1 – R2 Output Diagrams	108
Programmable Analog Output Diagrams	110
Pump Connector	111
J5 – Gauge Connector	111
Stop Speed Reading and Active Stop	115
J2 – Serial Connector	116
Vacuum Link App	116
Connector Examples	117
Serial Communication Descriptions	118
Letter Protocol Description	119
Window Protocol	126
Description	126
Communication Protocol	126
Examples	129
Window Meanings	132
How to Use by Front Panel	137
Use	143
General	143
Startup	144
Programming	150
Configuration Menu	150



Agilent Technologies

**Error Messages** 

Mode Menu	152
Pump Setting Menu	153
Input/Output Menu	156
Setpoint R1 and Setpoint R2 Submenus	159
Gauge Menu	161
Serial Menu	163
How to Use by Remote I/0	164
How to Use in Serial Mode	164
Profibus Option	166
General	166
Installation	166
Configuration	167
Software Operation and State Machine	167
Message Mapping	169
Parameter Buffer	170
Output Buffer	173
Input Buffer	174
Diagnostic Management	176
Diagnostic Buffer	178
Error Messages	180
Orderable Parts	183

### **TwisTorr 305 FS Remote Controller Description**

The controller is available in two models (see orderable parts table):

- with RS 232-485 option
- with Profibus option

The controller is a solid-state frequency converter with the following features:

- Drives the pumps of the TwisTorr 305 FS family.
- Powers the pump cooling fan
- Drives the vent valve.
- Provides and acquires the pressure of the wide range gauge.
- Remote I/O is compatible with the previous version (ref. TwisTorr 305 FS Remote Controller). Serial protocol is in most of the cases compatible with the previous version (ref. TwisTorr 305 FS Remote Controller) but, due to the additional features that have been implemented on this unit, some serial windows have been revised in the data format/content. Please check the chapter "Windows Meanings" in order to get further details about the serial windows specifications.
- Navigator default serial compatible with the previous RS 232 and 485 version.
- Speed reading after stop command.

See the following diagram for the connections and orderable parts.

TwisTorr 305 FS Remote Controller Description



Figure 4 TwisTorr 305 FS Remote Controller – Connections

### **Controller Specifications**

#### Tab. 2

Input:	
Voltage	100, 240 Vac (voltage fluctuation +/- 10%)
Frequency	50 to 60 Hz
Power	450 VA
Fuse	2 x T4 A (slow blow) 250 V
Output:	
Voltage	75 Vac
Frequency	1010 Hz
Power	150 W
Environment storage	-20 °C to +70 °C
	0 – 95 %
Operating	+5 - +45 °C
	0 – 90 %
Applied norr.	EN 61010 -1
	EN 61326-1
	EN 50581
	EMC Directive 2014/30/EU
	RoHS Directive 2011/65/EU
Weight:	1.7 Kg (3.2 lbs)
Pollution Degree	2
Installation Category	
Acoustic noise (IS07779)	LpA < 70 dB(A), normal operation, operator position

#### NOTE

The Controller must be positioned in a way that the mains cable can be easily disconnected from the controller mains power inlet (the controller is not equipped with a mains switch).

#### **Controller Outline**

### **Controller Outline**

The outline dimensions for the TwisTorr 305 FS Remote Controllers are shown in the following figure.

NOTE

TwisTorr 305 FS Remote Controller can be used as a bench unit or as a rack module, but it must be positioned so that free air can flow through the holes.



Figure 5 Controller outline

### **Controller Connection**

### J6 – Fan

The 24 Vdc, 150 mA maximum output voltage is present after START pushbutton is pressed and will remain present until a fault condition is displayed on front panel display or the turbopump is stopped.

This is a dedicated output for the optional TwisTor 305 pump cooling fan (see orderable parts table).

If you already have fan installed, use the available adapter cable to connect to the pump.



Figure 6 Fan Connector

**Controller Connection** 

### J7 – Vent





This is dedicated 24 Vdc connector to control the optional vent valve (see orderable parts table). The vent valve can be driven by controller automatically or by serial line.

If you already have a vent valve installed 110 Vac powered, this valve must be replaced by a new model (see orderable parts table).



Figure 8 Vent Valve diagram in "Auto" mode

### P1 – Input



Figure 9 P1 input connector

All the logic input to the controller **must** be connected at J1 mating connector. With the provided P1 mating connector (shipped with pin 3 and pin 8 shorted) make the connections with AWG 24, (0.24 mm2) or smaller wire to the pins indicated in the figure to obtain the desired capability. The following table describes the signals available on the connector.

Tab. 🕻	3
--------	---

Pins	Name	Description	Electrical	Note
1-com	Start/Stop	Contact closed = Start Contact open = Stop	Optically isolated Vlow, max = 10v Imax = 5mA Imin (on) = 2mA	Active only in Remote Mode operation
2-com	Low Speed	Contact closed = Low Speed Contact open = High Speed	Optically isolated Vlow, max = 10v Imax = 5Ma Imin (on) = 2mA	Active only in Remote Mode operation
3-com	Interlock	Contact closed = Active Contact open = Inactive If active allows the pump running, if inactive stops the pump.	Optically isolated Vlow, max = 10v Imax = 5mA Imin (on) = 2mA	Active in all modes
4-com	System Override	Contact closed Contact open If the contact is open, it allows the pump running; if the contact is closed, it stops the pump and all the others connected devices (Fan, Vent).	Optically isolated Vlow, max = 10v Imax = 5mA Imin (on) = 2mA	Active in all modes

**Controller Connection** 

Pins	Name	Description	Electrical	Note
5-com	Soft Start	Contact closed= Active Contact open= Inactive If active before the start command	Optically isolated Vlow, max = 10v Imax = 5mA	Active only in Remote Mode operation, and
		activates the spft start procedure. To be used only at first pump run- up.	Imin (on) = 2mA	in STOP status.

The following figure shows a typical contact logic input connection and the related simplified circuit of the controller.



Figure 10 Typical logic input connection

### J1 – Output



Figure 11 Logic output connector

All the logic output from the controller must be connected at P2 mating connector. The following table describes the signals available on the connector.

The following figure shows a typical logic output connection (relay coil) but any other device may be connected e.g. a LED, a computer, etc., and the related simplified circuit of the controller.



Figure 12 Digital Output Connection Example



Figure 13Analog Output Connection Example

**Controller Connection** 

#### Tab. 4

Pins	Name	Description	Electrical	Note
15-8	Fault	0V = no fail 24V = fail	Optically isolated Vmax (=open) = 24v Vlow, max = 1,5v Imax = 60mA Pin-8 negative Pin-15 positive	Connect a 10kohm resistor between the 2 pins before measuring voltage A STOP command (by front Panel or serial or Start/stop input) reset the FAIL status.
13-6	Start	Configurable output. Default setting (win.177 = 0): 24V pump in RAMP state, 0V = other state. If win.177 = 1: 0V = pump in stop or FAIL status, 24V = other state	Optically isolated Vmax (=open) = 24v Vlow, max = 1,5v Imax = 60mA Pin-6 negative Pin-13 positive	Connect a 10kohm resistor between the 2 pins before measuring voltage
12-5	Low Speed	24V = low speed active 0V = low speed not active	Optically isolated Vmax (=open) = 24v Vlow, max = 1,5v Imax = 60mA Pin-5 negative Pin-12 positive	Connect a 10kohm resistor between the 2 pins before measuring voltage
11-4	R1	Programmable Set Point Out can be related to: Frequency, Power, Time Status or Pressure.See following figures for more details. All the setting can be done by: front panel or serial line (win.101 to 105 and 162).	Optically isolated Vmax (=open) = 24v Vlow, max = 1,5v Imax = 60mA Pin-5 negative Pin-12 positive	Connect a 10kohm resistor between the 2 pins before measuring voltage
14-7	R2	Programmable Set Point Out Can be related to: Frequency, Power, Time Status or Pressure. See following figures for more details. All the setting can be done by: front panel or serial line (win.171 to 176).	Optically isolated Vmax (=open) = 24v Vlow, max = 1,5v Imax = 60mA Pin-7 negative Pin-14 positive	Connect a 10kohm resistor between the 2 pins before measuring voltage

**Controller Connection** 

Pins	Name	Description	Electrical	Note
2-1	Programmable Analog Output	Programmable analog output. Can be related to : frequency, power, pump temperature (linear) or pressure read by the external gauge. The setting can be done by: front panel or serial line (win.111). OV = 0Hz, 0W, 0°C 10V = 1010Hz, 150W, 100°C See following chart for more details	Optically isolated Rload, min = 10kohm Ripple Vpp,max = 200mV Precision = 5% Resolution = 40mV Pin-1negative Pin-2 positive	Connect a 100kohm resistor between the 2 pins before measuring voltage
9-1	Frequency Analog Output	Analog output proportional to frequency (linear). OV = OHz 10V = 1010Hz	Optically isolated Rload, min = 10kohm Ripple Vpp,max = 200mV Precision = 1% Resolution = 40mV Pin-1negative Pin-9 positive	

When the analog output is set to provide pressure signal, the voltage level is proportional to pressure level and it is generated by control unit elaborating the independent input by the active gauge.

R1 – R2 Output Diagrams

### **R1 – R2 Output Diagrams**



Figure 14 Diagram 1 – R1 or R2 related to frequency



**Figure 15** Diagram 2 – R1 or R2 related to power

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01
**R1 – R2 Output Diagrams** 







**Figure 17** Diagram 4 – R1 or R2 related to Normal status



**Figure 18** Diagram 5 – R1 or R2 related to pressure reading (if gauge connected)

**Programmable Analog Output Diagrams** 

## **Programmable Analog Output Diagrams**



**Figure 19** Diagram 1 – Programmable analog output related to frequency (freq.max = 1010Hz)



Figure 20 Diagram 2 – Programmable analog output related to power



Figure 21 Diagram 3 – Programmable analog output related to pump temperature

## **Pump Connector**

A five-meter long cable is available to connect the controller to the pump. The following figure shows the controller output connector configuration where pins:

- A-F = pump temperature sensor
- B-C-D = 75 Vac 3-phase output to pump motor stator
- **E** = EARTH PROTECTION





## J5 – Gauge Connector

This connector is available to connect the Agilent active gauges.





TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

111/190

**Programmable Analog Output Diagrams** 

#### NOTE

The maximum power provided by controller to drive a gauge is 5W, if your gauge require more power you need an external power supply.

The controller recognizes automatically the gauge connected by reading the signal "identification" in the connector.

Gauge model	Name showed in the display
FRG 700/702	FRGa
IMG 500	IMG
PVG 500/502	PVGa
CDG 500 T1000	CDG3
CDG 500 T0100	CDG2
CDG 500 T0010	CDG1
CDG 500 T0001	CDGO

Following a table with the gauge supported:

The controller give the error "gauge error" if the gauge connected is not supported.

There are some gauges (for example the CDG family gauge) that have the same identification. In this case the controller recognizes the family of the gauge but the user should select the right gauge by front panel.

The pressure can be read by display, by serial line (win. 224) and by Remote I/O (Programmable Analog Out), but the controller doesn't replicate the signal from the gauge.

If the Programmable Analog Output is related to the pressure read by an external gauge, the controller doesn't replicate exactly the signal coming from the gauge; the controller converts the gauge signal in the range from 0 to 10V.

The conversion formula is the following:

$$V_{out} = \frac{V_g - V_{g_{min}}}{V_{g_{max}} - V_{g_{min}}} \times 10$$

Where:

 $V_g\,$  is the gauge output voltage;

 $V_{out}$  is the Analog Output voltage;

 $V_{g\_min} \div V_{g\_max}$  is the gauge voltage measuring range. These values can be drawn from the gauge technical specifications or from the following table.

ID	Gauge Model	Pressure range [mbar]	Vg-min ÷ Vg-max [V]
1	CT-100	1.33E-2 to 1.01E3	1.11 ÷ 8.25
2	FRG-700/702	5E-9 to 1E3	1.82 ÷ 8.6
3	IMG-500	2E-9 to 1E-2	1.8 ÷ 8.5
4	PVG-500/502	5E-4 to 1E3	1.9 ÷ 10
6	PCG-750/752	5E-5 to 1.5E3	0.61 ÷ 10.23
9	CDG-500 T1000	2.66E+1 to 1.33E3	0.2 ÷ 10
10	CDG-500 T0100	2.66E+0 to 1.33E2	0.2 ÷ 10
11	CDG-500 T0010	2.66E-1 to 1.33E1	0.2 ÷ 10
12	CDG-500 T0001	2.66E-2 to 1.33	0.2 ÷ 10

**Programmable Analog Output Diagrams** 

When in programmable analog signal you read a voltage below the voltage range (in above table) it means "Error Over range", if you read a voltage below the voltage range it means "Error Under range" (in these cases you can read the manual of the gauge for further details).

With the serial communication you can use the following windows:

Win 224	Pressure reading with the format X.X E XX
Win 257	Gauge status (read only): 0 $\rightarrow$ when a gauge is not connected
	1 $ ightarrow$ when a gauge is connected
	2 → when the pressure read is under range or when the gauge gives an internal error
	3 → when the pressure read is under range or when the gauge gives an internal error
	4 → when the "identification" is present but not known by the controller
Win 267	Gauge power (read/write): If you need to turn off the gauge at certain condition you can use this window 0 → gauge off 1 → gauge on (default) 2 → gauge normally off. It turns on when the set point 1 is activated. If the set point 1 type (win 101) is selected as "pressure" the gauge is always on. 3 → gauge normally off. It turns on when the set point 1 is activated. If the set point 2 type (win 171) is selected as "pressure" the gauge is always on. 4 → gauge normally off. It turns on when the set point 1 is activated. If the set point 3 type (win 101) is selected as "pressure" the gauge is always on.

The windows from 136 to 140 manage an additional set point (set point 3) dedicated to turn ON or OFF the gauge (win 267=4)

# **Pump Driving**

Typical pump driving chart start and normal operation.





## **Stop Speed Reading and Active Stop**

This function can be activated by Front Panel or serial line (Win 107, 167).

Active Stop brakes the pump using the motor. The Stop Speed reading reads the pump speed after a stop command.





TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

115/190

J2 – Serial Connector

## J2 – Serial Connector

This connector provides the connection for RS – 232 and RS – 485 serial line.

J2 Pin-out:





Т	a	b.	5
	u	υ.	•••

PIN N.	SIGNAL NAME
1	+5 V (OUT) (Reserved)
2	TX (RS232
3	RX (RS232
4	NC
5	GND
6	A + (RS485)
7	NC
8	B – (RS485)
9	RESERVED

## Vacuum Link App

The Remote Controller can communicate with a smartphone connecting the accessory RS232 Serial to B/T Adapter (X3514-68003) to the serial port.

This accessory is a dongle to convert the serial communication to bluetooth communication.

In order to establish the communication between the controller and a smartphone, the Vacuum Link app must be installed first from Google Play or Apple Store. The app is available for both Android and iOS. Once installed, you can establish the connection. Using this app you will be able to read and write all controller parameters.



## **Connector Examples**







Figure 28 RS – 485 Connection

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

117/190

Vacuum Link App

The communication port mating connector is supplied with the RS 232 PCB (AMP/Cannon or equivalent 15-pin "D" type male connector). For example, the Transmit data signal from controller (pin 2) must be connected to the host computer's receive data line (pin 2) and vice versa. Consult the host computer's instruction manual for its serial port connections.

### NOTE

Agilent cannot guarantee compliance with FCC regulations for radiated emissions unless all external wiring is shielded, with the shield being terminated to the metal shroud on the 0-subconnector. The cable should be secured to the connector with screws.

## **Serial Communication Descriptions**

This unit can comunicate by two different protocol:

- protocol (old system) "letter"
- "Window" protocol (new system)

These two protocols can be used as well with 232 or 485 media.

NOTE Please use "Window" protocol for new development.

## **Letter Protocol Description**

The default protocol is "Window"

**Communication format:** 

- 8 data bit
- no parity
- 1 stop bit
- The baud rate is programmable via front panel from 600 to 9600 baud. The controller is factory-set for 9600 baud operation.

Communication protocol:

Host = Master

Controller = Slave

The communication is performed in the following way:

Host





**Request** is an ASCII character identifying the action that must be performed by the controller or the requested information.

Allowed ASCII characters:

- "A" = START
- "B" = STOP
- "C" = Low Speed ON
- "D" = Low Speed OFF
- "E" = Request for operational parameters
- "F" = Pump times zeroing
- "G" = Parameters reading

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

**Letter Protocol Description** 

- "H" = Parameters writing
- "I" = Request for operating status
- "J" = Request for numerical reading
- "K" = Request for counters reading.

CRC corresponds to the sum (with inverted sign) of all the preceding bytes.

e.g., the START command "A" in ASCII code = 41 inverted it will be: FF + 1 - 41 = BF.

CHARACTER	ASCII	CONVERTED ASCII FOR CRC CALCULATION
"A"	41h	-
CRC	-	BFh
"B"	42h	-
CRC	-	BEh
"C"	43h	-
CRC	-	BDh
"D"	44h	-
CRC	-	BCh
"E"	45h	-
CRC	-	BBh
"F"	46h	-
CRC	-	BAh
"G"	47h	-
CRC	-	89h
"H"	48h	-
"  "	49h	-
CRC	-	B7h
"J"	4Ah	-
CRC	-	B6h
"К"	4Bh	-

#### Tab. 6

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

Letter Protocol Description

CHARACTER	ASCII	CONVERTED ASCII FOR CRC CALCULATION
CRC	-	B5h
"ACK"	06h	-
CRC	-	FAh
"NACK"	15h	-
CRC	-	EBh

**Answer** = after a request from the host, the Controller will answer in one of the following ways:

- ACK
- NACK
- Message

When the Request is "A, "B", "C", "D", "F" the Controller will Answer the ACK or NACK.

**Letter Protocol Description** 

When the Request is "E, the **Answer** will contain the complete set of the following parameters:

BYTES	MEANING	
1 MSB LSB		
X X X	0 = STOP 1 = WAITING INTERLOCK 2 = STARTING 3 = NORMAL OPERATION 4, 5 = HIGH LOAD 6 = FAILURE 7 = APPROACHING LOW SPEED	
2÷5	Cycle Time	
6÷9	Pump Life	
10÷11	Pump Temperature	
12	Current*	
13	Voltage*	
14÷17	Frequency	
18÷19	Cycle #	
20	R1 Status	
21	R2 Status	
22	CRC	

Tab. 7

\*The values for current and voltage are given as numbers, scaled from 0 to 255, where 0 corresponds to 0 V and 255 to the full scale voltage (130 V) or current (2,5 A).

When the **Request** is "G", the **Answer** will contain a string of 11 characters with the following parameters:

Tab.	8
------	---

BYTES	MEANING	
1-2	Pump cycles number (integer coded in 2 bytes)	
3	Speed threshold	
4-7	Run up time in seconds (long coded in 4 bytes)	
8	Deat time (0 = NO 1 = YES)	
9	Reserved	
10	Soft Start mode (0 = NO 1=YES)	
11	CRC	

When the configuration parameters have to be changed, send a **Request** string with "H" characters of the following type:

"H" + .... data .... + CRC

**Letter Protocol Description** 

The following parameters can be changed:

### Tab. 9

BYTES	MEANING
1	Speed threshold
2-5	Run up time in seconds (long coded in 4 bytes)
6	Deat time (0 = NO 1 = YES)
7	Reserved
8	Soft Start mode (0 = YES 1 = NO)
9	CRC

When the **Request** is "I" (Status readings), the **Answer** will contain a string of 2 characters with the following parameters:



BYTES	MEANING	
1 MSB LSB		
	0 = STOP 1 = WAITING INTERLOCK 2 = STARTING 3 = NORMAL OPERATION 4, 6 = FAILURE 	
	-R2 status 0 = OFF 1 = ON	
	— R1 status 0 = OFF 1 = ON	
2	CRC	

When the **Request** is "J" (Numerical readings), the **Answer** will contain a string of 5 characters with the following parameters:

### Tab. 11

BYTES	MEANING
1	Current (0-255 scaled)
2	Voltage (0-255 scaled)
3	Rotational speed KRPM
4	Pump temperature °C (0-254 temperature reading, 255 = fail)
5	CRC

When the **Request** is "K" (Counters readings), the **Answer** will contain a string of 11 characters with the following parameters:

Tab.	12
------	----

BYTES	MEANING
1-4	Cycle time
5-8	Pump life
9-10	Cycle number
11	CRC

On request a sample program in QBasic language is available by Agilent.

## **Window Protocol**

## Description

### **Communication Format**

- 8 data bit
- no parity
- 1 stop bit
- baud rate: 600/1200/2400/4800/9600 programmable

## **Communication Protocol**

The communication protocol is a MASTER/SLAVE type where:

- Host = MASTER
- Controller = SLAVE

The communication is performed in the following way:

- 1 the host (MASTER) send a MESSAGE + CRC to the controller (SLAVE);
- 2 the controller answer with an ANSWER + CRC to the host.

The MESSAGE is a string with the following format:

<STX>+<ADDR>+<WIN>+<COM>+<DATA>+<ETX>+<CRC>

Where:

**NOTE** When a data is indicated between two quotes ('...') it means that the indicated data is the corresponding ASCII character.

### Technical Information 8 Letter Protocol Description

 $\langle STX \rangle$  (Start of transmission) = 0x02

<ADDR> (Unit address) = 0x80 (for RS 232)

<ADDR> (Unit address) = 0x80 + device number (0 to 31) (for RS 485)

<WIN> (Window) = a string of 3 numeric character indicating the window number (from '000' to '999'); for the meaning of each window see the relevant paragraph.

<COM> (Command) = 0x30 to read the window, 0x31 to write into the window

<DATA> = an alphanumeric ASCII string with the data to be written into the window. In case of a reading command this field is not present. The field length is variable according to the data type as per the following table:

### Tab. 13

Data Type	Field Length	Valid Characters
Logic (L)	1	'0' = OFF '1' = ON
Numeric (N)	6	'-', '.', 'O' '9' right justified with 'O'
Alphanumeric (A)	10	from blank to '_' (ASCII)

<ETX> (End of transmission) = 0x03

<CRC> = XOR of all characters subsequent to <STX> and including the <ETX> terminator. The value is hexadecimal coded and indicated by two ASCII character.

The addressed SLAVE will respond with an ANSWER whose structure depends from the MESSAGE type. When the MESSAGE is a reading command, the SLAVE will respond transmitting a string with the same structure of the MESSAGE.

NOTE Using the RS 485 interface, the message structure remains identical to the one used for the RS 232 interface, the only difference being that the value assigned to the ADDRESS <ADDR>

The controller can answers with the following response types:

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

Letter Protocol Description

### Tab. 14

Response Type	Response Length	Response Value	Description
Logic	1 byte	-	after a read instruction of a logic window
Numeric	6 bytes	-	after a read instruction of a numeric window
Alphanumeric	10 bytes	-	after a read instruction of an alphanumeric window
ACK	1 byte	(0×6)	the command execution has been successfully completed
NACK	1 byte	(0x15)	the command execution has been failed
Unknown Window	1 byte	(0x32)	the specified window in the command is not a valid window
Data Type Error	1 byte	(0x33)	the data type specified in the command (Logic, Numeric or Alphanumeric) is not accorded with the specified Window
Out of Range	1 byte	(0x34)	the value expressed during a write command is out of the range value of the specified window
Win Disabled	1 byte	(0x35)	the specified window is Read Only or temporarily disabled (for example you can't write the Soft Start when the Pump is running)

## **Examples**

## Command: START

Source: PC Destination: Controller

02	80	30	30	30	31	31	03	42	33
STX	ADDR	W	WINDOW			ON	ETX	CF	RC

Source: Controller Destination: PC

02	80	0 06		38	35
STX	ADDR	ACK	ETX	CRC	;

### **Command: STOP**

Source: PC Destination: Controller

02	80	30	30	30	31	30	03	42	32
STX	ADDR	WIN	IDOM	1	WR	OFF	ETX	CRC	;

Source: Controller Destination: PC

02	80	06	03	38	35
STX	ADDR	ACK	ETX	CRC	;

Examples

### Command: SOFT-START (ON)

Source: PC

Destination: Controller

02	80	31	30	30	31	31	03	42	32
STX	ADDR	W	WINDOW			ON	ETX	CF	RC

Source: Controller Destination: PC

02	80	06	03	38	35
STX	ADDR	ACK	ETX	CRC	,

### Command: SOFT-START (OFF)

Source: PC Destination: Controller

02	80	31	30	30	31	30	03	42	33
STX	ADDR	WINDOW			WR	OFF	ETX	CI	RC

Source: Controller Destination: PC

02	80	06	03	38	35
STX	ADDR	ACK	ETX	CRC	

### **Command: READ PUMP STATUS**

Source: PC Destination: Controller (with address = 3)

02	83	32	30	35	30	03	38	37
STX	ADDR	WINDOV		W	RD	ETX	C	RC

Source: Controller (with address = 3 in stop status) Destination: PC

02	83	3	3	3	3	3	3	3	3	3	03	3	3
		2	0	5	0	0	0	0	0	0		8	7
ST	ADD	W	INDO	W		DA	TA (8	STATI	JS)		ET	CI	RC
Х	R										Х		

### **Command: REAL SERIAL TYPE**

Source: PC

Destination: Controller (with address = 3 in 485 mode)

02	83	35	30	34	30	03	38	31
STX	ADDR	W	INDO	W	RD	ETX	CF	RC

Source: Controller Destination: PC

02	83	35	30	34	30	31	03	42	30
STX	ADDR	W	INDO	W	RD	DATA	ETX	CI	RC

### 8 Technical Information Examples

Window Meanings

### Tab. 15

WIN#	READ/ WRITE	TYPE	MEANING	ADMITTED VALUES	FACTORY SET
0	R/W	L	Start/Stop (in remote/ Front mode the window is a read only)	Start = 1 Stop = 0	0
1	R/W	L	Low Speed Activation	No = 0 Yes = 1	0
8	R/W	A/L	Serial/Remote/Front/FieldBus Contr.Configuration	0 = Serial 1 = Remote 2 = Front 3 = Profibus	1
100	R/W	L	Enable/Disable Soft Start (write only in Stop condition)	Enable = 1 Disable = 0	"1" at the first START, then "0"
101	R/W	N	R1 Set Point type	0 = Freqency 1 = Power 2 = Time 3 = Normal 4 = Pressure (available only if the gauge is connected)	3
102	R/W	N	R1 Set Point value (expressed in Hz/W/s/mbar)	0,999999	867
103	R/W	N	R1 Set Point delay: time between the pump start and the set point check (seconds)	0,999999	0
104	R/W	L	R1 Set Point signal activation type: the signal can be "high level active" or "low level active"; "high level active" indicates the output is ON when the signal is above the threshold	0 = high level active 1 = low level active	0
105	R/W	Ν	R1 Set point hysteresis (in % of R1 value)	0,100	2
107	R/W	L	Active Stop (write only in stop) Enable/disable the stop with active braking.	Enable = 1 Disable = 0	0
108	R/W	N	Serial comm. baud rate	0 = 600 bit/s 1 = 1200 bit/s 2 = 2400 bit/s 3 = 4800 bit/s 4 = 9600 bit/s	4
109	W	L	Pump life/Cycle time/Cycle number reset	To reset write '1'	
110	R/W	L	Interlock type. The interlock can be checked at start (impulse) or continuously	Impulse = 0 Continuous = 1	0

**Examples** 

WIN#	READ/ WRITE	TYPE	MEANING	ADMITTED VALUES	FACTORY SET
111	R/W	N	Analog output type: output voltage signal proportional to frequency, power, temperature or pressure	0 = frequency 1 = power 2 = Temperature 3 = Pressure	1
117	R/W	N	Low Speed frequency value (Hz)	from 700 to 1010 Hz	700
120	R/W	N	Rotational frequency setting (Hz)	from low speed frequency (win 117) to 1010 Hz	1010
122	R/W	L	Set vent valve (on/off) (write if Win125 = 1)	On = 1 Off = 0	1
123			Reserved to Agilent Service		
124			Reserved to Agilent Service		
125	R/W	A/L	Set the vent valve operation	0 = Automatic 1 = On command 2 = Auto pump speed	0
126	R/W	N	Vent valve opening delay (1unit = 0.2s)	0,65535 (from 0 to 13107s)	15
130			Reserved to Agilent Service		
136	R/W	N	Gauge Set Point Type	0 = Freqency 1 = Power 2 = Time 3 = Normal	3
137	R/W	N	Gauge Set Point Value (Hz/W/s/mbar)	0,999999	867
138	R/W	N	Gauge Set Point delay: time (s) between the pump start and the set point check (seconds)	0,999999	0
139	R/W	L	Gauge Set Point Signal Activation Type the signal can be "high level active" or "low level active"; "high level active" indicates the output is ON when the signal is above the threshold	0 = high level active 1 = low level active	0
140	R/W	Ν	Gauge Set point hysteresis (in % of gauge set point value)	0,100	2
143	R/W	N	External fan configuration	0 = Always On 1 = Controlled by Serial	0
144	R/W	L	External fan activation	On = 1 Off = 0	0
147	R/W	N	Vent valve opening time (1unit = 0.2s; 0 = infinite) (Ref. to "vent connector" paragraph)	0,65535 (from 0 to 13107s)	0
155	R	N	Actual maximum power limit (W) (It reads the maximun power deliverable to the pump)		

133/190

**Examples** 

WIN#	READ/ WRITE	TYPE	MEANING	ADMITTED VALUES	FACTORY Set
157	R/W	N	Gas load type (it sets the gas type to be used with the pump)	0 = Ar 1 = N2 2 = He	0
162	R	A	R1 Set Point Pressure Threshold Data format: X.X EsXX (with X = 0 to 9; s = + or -) Threshold value is meaningful if win101 = 4		
163	R/W	N	Unit of measure for pressure	0 = mbar 1 = Pascal 2 = Torr	0
167	R/W	L	Stop Speed Reading Enables/Disables the reading of the pump speed after a stop command	Enable = 1 Disable = 0	0
171	R/W	N	R2 Set Point Type	0 = Freqency 1 = Power 2 = Time 3 = Normal 4 = Pressure (available only if the gauge is connected)	3
172	R/W	Ν	R2 Set Point value (expressed in Hz/W/s/mbar)	0,999999	867
173	R/W	N	R2 Set Point delay: time between the pump start and the set point check (seconds)	0,999999	0
174	R/W	L	R2 Set Point signal activation type: the signal can be "high level active" or "low level active"; "high level active" indicates the output is ON when the signal is above the threshold	0 = high level active 1 = low level active	0
175	R/W	N	R2 Set point hysteresis (in % of R2 value)	0,100	2
176	R	A	R2 Set Point Pressure Threshold Data format: X.X EsXX (with X = 0 to 9; s = + or -) Threshold value is meaningful if win101 = 4		
177	R/W	L	Start Output Config.	0 = Starting (Output ON only with pump Status = Starting) 1 = Running (Output ON when the pump is running)	0

**Examples** 

WIN#	READ/ WRITE	TYPE	MEANING	ADMITTED VALUES	FACTORY SET
181	R/W	N	Gauge Gas Type	0 = Not configured 1 = Nitrogen 2 = Argon 3 = Hydrogen 4 = Other	0
182	R/W	Ν	Correction Factor for Custom Gauge	10,999	
200	R	N	Pump current (mA dc); it reads the actual value of the bus current supplied by controller to electric motor		
201	R	Ν	Pump voltage (Vdc); it reads the actual value of the peak 3ph.voltage supplied by controller to the electric motor		
202	R	N	Pump power (W); it reads the actual value of power supplied by controller to electric motor		
203	R	Ν	Driving frequency (Hz)		
204	R	N	Pump temperature (°C)		
205	R	N	Pump status	0 = Stop 1 = Interlock 2 = Ramp 3 = Autotuning 4 = Braking 5 = Normal 6 = Fail	
206	R	N	Error code (2×)	(bit description) 7 = Too High Load 6 = Short Circuit 5 = Over Voltage 4 = Override 3 = Run Up time 2 = Controller Over Temp 1 = Pump Over Temp 0 = No connection to pump	
211	R	N	Controller heatsink temperature (°C)		
216	R	Ν	Controller cooling air temperature (°C)		
224	R	N	Pressure reading Format = X.X E XX		
226	R	Ν	Rotation Frequency (rpm)		
257	R	Ν	Gauge Status	4 = RidUnknown 3 = GaugeOverRange 2 = GaugeUnderRange 1 = GaugeConnected 0 = NoGaugeConnected	

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

**Examples** 

WIN#	READ/ WRITE	TYPE	MEANING	ADMITTED VALUES	FACTORY SET
267	R/W	N	Gauge Power Mode	4 = Power On Set Point 3 3 = Power On Set Point 2 2 = Power On Set Point 1 1 = Power On Always 0 = No Power	
300	R	N	Cycle time in minutes; it indicates the time of the last cycle (from the last start to the current time, if the pump is running)	0,999999	
301	R	N	Cycle number; it indicates the number of cycles start/stop during the whole pump life.	0,9999	
302	R	Ν	Pump life in hours		
320			Reserved to Agilent Service		
			Reserved to Agilent Service		
399			Reserved to Agilent Service		
400	R	А	Program Listing CRC		
402	R	А	Parameter Listing CRC		
404	R	А	Parameter Listing Struct.CRC		
500			Reserved to Agilent Service		
503	R/W	N	RS485 address	0,31	
504	R/W	L	Serial type selection	0 = RS232 1 = RS485	0
724	R/W	Ν	Run Up time (minutes)	0,30	15
725	R/W	L	Run Up time control	On = 1 Off = 0	1



Figure 29 Window N. 206 Bit Description

## How to Use by Front Panel



### Figure 30

### Start Stop and Reset Fail button

Press once for the START command and again for the STOP command. In the case of controller's failure, press once to reset the fail condition.

NOTE

The front panel START/STOP function is available only if the controller is set to "FRONT mode". If it is set to "REMOTE mode", when the key is pressed an error message is shown indicating "COMMAND LOCKED IN REMOTE", if it is set to "SERIAL" mode, the "COMMAND LOCKED IN SERIAL MODE" error message is displayed. The "Reset Fail" function is always available regardless of controller mode.

### Low Speed

 $\ensuremath{\mathsf{Press}}$  once to activate the LOW SPEED command; press again to deactivate.

NOTE The front panel LOW SPEED function is available only if the controller is set to "FRONT"; otherwise an error message is returned. If it is set to "REMOTE" mode, the COMMAND LOCKED IN REMOTE error message is displayed while if it is in "SERIAL" mode the "COMMAND LOCKED IN SERIAL MODE" error message is returned.

How to Use by Front Panel

### Counters

Pressing the first time on the display, the following information is displayed:

		C	Y	C	L	Ε		Х	Х	Х	X		
	Т		М	Ε			Х	Х	Х	Х	Х	m	

Where:

	CYCLE	XXXX	Number of start/stop cycle
--	-------	------	----------------------------

TIME XXXXXm Time of last cycle (minutes)

Pressing a second time, the following is displayed:

	Р	U	М	Р		L	Ι	F	Ε		
		Х	Х	Х	Х	Х	Х	h			

#### PUMP LIFE

XXXXXX total operating time (hours) of the pump

Pressing a third time, the following message Is displayed:

М	Ν	:	Х	Х	Х	Х	Х	Х	Х	х	Х	Х	
S	Ν	:	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	

MN Model Number of the controller

#### SN Serial Number

On pressing the key again, the main screen page is redisplayed.

### Measures

Pressing once, the following is obtained:

Р	=	Х	Х	X	w					Х	Х	х	Х	Н	z
					Т	=	Х	Х	0	C					

Where:

**P** = **XXX W** is the current power supplied to the pump

**T** = **XX** °**C** is the current temperature of the pump

**XXXX Hz** is the current frequency of rotation of the pump. This value is set by default to 1010 Hz but can be modified by the user according to needs, proceeding as described in the "PROGRAMMING" paragraph. The unit of measurement (HZ / Krpm, default = Hz) is selected by the user from the INPUT/OUTPUT->SPED menu.

If the SOFT-START function (PUMP SETTING menu  $\rightarrow$  SOFTSTART is active and the pump is ramping, indication of the speed of rotation is replaced with a bar-graph that indicates the soft-start step in course and the total number of steps to be performed. On completion of the soft-start ramp, the bar-graph is replaced with indication of the frequency of rotation of the pump

Pressing twice, the following is obtained:

Ν	0	R	М	Α	L				Х	Х	Х	X	Η	z
	I	=	X		X	Χ	Α	۷	=	Χ	Х	Х	V	

Where:

**NORMAL**: indicates the operating regime of the pump

XXXHz: see description "Pressing once" Measures key

**I=X.XXA**: indicates the current absorbed by the pump

**V= XXX V**: indicates the pump driving voltage

Pressing 3 times, the following is obtained:

Р	=	X	X	X	W					X	X	X	X	H	z
		X		X	X	Ε	-	Y	Y	m	В	а	R		

How to Use by Front Panel

Х		X	Ε	-	Y	Y	m	В	а	r		Ζ	Ζ	Ζ	Ζ
	Р	Ш	Х	Х	Х	W			Х	Х	Х	Х	H	z	

Where:

**P= XXXW**: indicates the current power supplied to the pump

XXXHz: see description "Pressing once" Measures key

**X.XE-YYmBar:** indicates the pressure currently measured by the gauge.

**ZZZZ**: indicates the kind of gauge (see table of gauge supported in the gauge chapter)

Other possible indications:

Ρ	=	X	X	X	W				Χ	Χ	X	X	Η	z
		G	Α	U	G	Ε	Ε	R	R	0	R			

Where:

GAUGE\_ERROR: gauge not connected or broken

Р	=	X	Χ	X	W				X	X	X	X	Η	z
	Ρ	R	Ε	S	S	U	R	Ε	U	Ν	D	Ε	R	

Where:

**PRESS UNDER:** indicates that the pressure read is below the minimum measurement threshold set (5 E-9 mBar)

Р	=	X	Χ	X	W				X	X	X	X	Η	z
	Ρ	R	E	S	S	U	R	Ε	0	۷	E	R		

Where:

**PRESS OVER**: indicates that the pressure measured is above the maximum measurement threshold set (1000 mBar)

The unit of measurement of the pressure can be selected (GAUGE menu $\rightarrow$ Unit) from "mBar", "Pa", "torr"

Pressing 4 times returns to the following screen page:

Ν	0	R	М	Α	L					Х	X	X	X	Η	z
	X	X	X	Χ	X	Χ	X	X	Х	X	X	X	X	X	

Where:

NORMAL: indicates the operating regime of the pump

XXXHz: see description "Pressing once" Measures key

The operating mode of the controller is shown at the bottom in the center. This may be:

**FRONT**: front mode (the controller accepts START/STOP and LOW SPEED commands from the front panel)

**REMOTE**: remote mode (the controller accepts START/STOP and LOW SPEED commands via the rear connector)

**RS232**: the controller accepts commands from the serial port according to the RS232 standard.

**RS485** [XX]: the controller accepts commands from the serial port in RS485 mode with address XX (XX from 0 to 31)

**PROFIBUS** [**YYY**]: the controller accepts commands from the PROFIBUS port with address YYYY

How to Use by Front Panel

Black rectangles as shown below may be displayed at any time in the first and last box of the bottom line of the display (opposite the LS / AG / R1 / R2 captions). The meaning of these rectangles is as follows:

- $\textbf{LS} \rightarrow \textbf{the controller}$  is at LOW SPEED
- $\textbf{AG} \rightarrow$  the Gauge is connected to the controller
- **R1**  $\rightarrow$  relay (set point) R1 is active
- $\mathbf{R2} \rightarrow \text{relay}$  (set point) R2 is active







## Use

## General

Make all vacuum manifold and electrical connections and refer to TwisTorr 305 FS pump instruction manual before to operating the TwisTorr 305 FS Remote Controller.



To avoid injury to personnel and damage to the equipment, if the pump is laying on a table make sure it is steady. Never operate the TwisTorr 305 FS pump if the pump inlet is not connected to the system or blanked off.

NOTEThe input signal P1 connector should be left in position including the shipping<br/>links if no external connections are made.<br/>The forepump and the TwisTorr 305 FS pump can be switched on at the same<br/>time.

Use

## Startup

• Plug the controller power cable into a suitable power source. The display lights up for approx. 2 seconds and shows:

		Α	U	Т	0	Т	Ε	S	Т		
					0	K					

• After 2 seconds, the display shows the following screen page:

S	T	0	Ρ						•	•	•	Η	z
				F	R	0	Ν	Т					

NOTE

If the pump is not connected, the display will be as follows:

C	Η	Ε	C	K	C	0	Ν	Ν	Ε	C	Τ	I	0	Ν
			Т	0	Ρ	U	Μ	Р						

• Pressing the START button, the pump is started and the display shows the following screen page.

S	Т	Α	R	Т	I	Ν	G			Х	X.	Х	Х	H	z
					F	R	0	Ν	Т						




This screen page will be visible throughout the acceleration phase the pump. The increasing value of the rotation frequency will be displayed in the boxes marked X; the user may decide to express this value in Hz (default) or in KRMP.

Once operating speed has been reached, the following screen page is displayed:

Ν	0	R	М	Α	L					9.	6	3	Н	z
					F	R	0	Ν	Т					

If the LOW SPEED key is pressed, the above screen page changes to:





TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

Use

The following screen page is displayed on reaching the pre-established speed:

Ν	0	R	М	Α	L					9	0	0	Н	z
					F	R	0	Ν	Т					

The rotation value set in both NORMAL and LOW SPEED mode can be modified by the user as described in the Programming section of this manual.

Press the MEASURES push button: the display shows:





Where:

**P** = is the DC power drawn by the pump (range 0 to 999 Watt)

 $\mathbf{H}\mathbf{z}=\mathbf{i}\mathbf{s}$  the rotational speed of the pump as a function of the controller output frequency

 $^{\circ}$ C = is the temperature of the outer ring of the upper bearing (range 00 to 99  $^{\circ}$ C)

 Pressing MEASURES key twice, the following screen page is displayed:

Ν	0	R	М	Α	L					9	6	3	H	z
	-	Ш	1	•	2	0	Α	۷	Ш		4	2	۷	

Use

Where:

I is the current supplied by the controller to the pump at that precise moment.

 ${\bf V}$  is the voltage at which the controller is powering the pump at that moment

 Pressing the MEASURES key three times, with the GAUGE connected and functioning, the following screen page is displayed:



#### Figure 35

Where:

mBar shows the pressure value measured

XXXX shows the kind of gauge connected



The following messages may be displayed instead of the pressure:

**GAUGE ERROR:** indicates that the GAUGE is not identified

**PRESSURE UNDER**: indicates that a pressure below the minimum threshold set has been measured

**PRESSURE OVER:** indicates that a pressure exceeding the maximum threshold set has been measured

Pressing the COUNTERS key, the following is obtained:



### Figure 36

Where:

CYCLE XXXX Number of start/stop cycles TIME XXXXXmTime of last cycle (minutes) Pressing again:

	Р	U	М	Р		L	I	F	Ε		
		Х	Х	Х	Х	Х	Х	h			

Where:

PUMP LIFE

XXXXXX

total operating time (hours) of the pump

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01



# Programming

## **Configuration Menu**

To access the configuration menu, press the COUNTERS + MEASURES buttons at the same time for at least 2 sec.



#### Figure 37

In programming mode, the meaning of the 4 buttons changes as follows:

- COUNTERS/LOW SPEED speed become "INCREASE and DECREASE" and make it possible to select the next or previous value of a parameter (in the case of compulsory parameters) or to increase/decrease the individual digit of a parameter (in the case of numeric parameters)
- The "MEASURES and START/STOP" buttons become "NEXT and PREVIOUS" and make it possible to select the next parameter (or next digit of a numeric parameter) or previous parameter.

Switching from one parameter to the next (using the "NEXT" key) indicates confirmation of any changes made to the specific parameter. If the changes cannot be accepted by the controller, the "Data out of limits" error message is displayed, the changes are cancelled and the value of the parameter prior to the modification is reproposed.

Switching from a parameter to the previous parameter (using the "**PREVIOUS**" key) indicates the intention to abort any changes made to the specific parameter. Abort is indicated by the caption "**Changes aborted**" that is displayed for approx. 1 second before moving to the previous parameter.

The configuration environment has a tree-like structure and permits "circular" navigation; on reaching the end of a branch, the user is returned automatically to the start of this. Navigation can proceed in a forwards (**NEXT** button) or backwards (**PREVIOUS** button) direction

It is possible to enter a sub-branch by pressing the "**INCREASE**" button. If no buttons are pressed for more than 1 minute, the controller automatically quits the programming environment canceling any modifications made to the current parameter.

The figure below shows the first level of the configuration menu and the links to the respective second level menus (indicated below).

Programming





## Mode Menu

- **MODE**: permits selection (see Flow 1/6) of the operating mode of the controller from those indicated below:
  - FRONT: accepts commands from the front panel
  - REMOTE: accepts commands from the remote input connector
  - SERIAL: accepts commands from the serial interface (or Profibus interface if present)
  - PROFIBUS: this operating mode is present only if the Profibus interface is installed on the controller

# **Pump Setting Menu**





This menu contains all the parameters that have a direct effect on driving of the pump.

- **HIGH SPEED**: Sets (in Hz) the speed of rotation of the pump when the low-speed function is not active.
- **LOW SPEED**: Sets (in Hz) the speed of rotation of the pump when the low-speed function is active.
- SOFT START: enables (YES) or disables (NO) the soft start function. This parameter is visible only if the controller is configured in FRONT mode.
- **EXTERNAL FAN CNF**: Makes it possible to select driving mode of the external cooling fan. Possible options:
  - ALWAYS ON: the cooling fan is always ON
  - SERIAL: the cooling fan is controlled directly via the serial port.
- VENT VALVE MODE: makes it possible to select driving of the vent valve
  - AUTO TIME: the valve is controlled by the controller
  - MANUAL: the valve is controlled by the serial port.
  - AUTO PUMP SPEED: the valve is controlled by the controller, by taking into account the pump's deceleration.
- **VENT VALVE DELAY**: Sets the delay, expressed in seconds, between stopping of the pump and opening of the vent valve.
- VENT VALVE OPEN TIME: sets the time, expressed in seconds, of opening of the vent valve. Enter 0 if the valve is to be kept open indefinitely (until the next start).
- LOAD GAS TYPE: selects the type of gas used in the process. Therefore, the controller limits the power supplied to the pump according to the setting of this parameter, combined with the pump body temperature. Please always set up the LOAD GAS TYPE in accordance to the gas type used in the process. An improper selection of this setting could result in the damage of the pump.

- RUN UP TIME: it sets the maximum amount of time for which the pump is allowed to spin at a speed value less than the normal operating speed. The pump is not intended to spin for an indefinite time at a speed value lower than 700Hz; the Run Up Time value is selectable from 0 minutes to 30 minutes, default value is 15 minutes. If the pump, due to the gas flow applied to it, spins at a speed value less than 700Hz, the Run Up timer starts to count; when the counter value exceeds the Run Up Time set value, the pump will stop and the error condition "Run Up Time" will appear on the serial Win#206.
- ACTIVE STOP: enables (YES) or disables (NO) active braking.
- **STOP SPEED READING**: enables (YES) or disables (NO) the pump rotational frequency reading function also during the slowing phase that follows a stop command

8 Technical Information Programming

# Input/Output Menu

This menu contains parameters that determine the operating mode of the inputs and outputs of the controller.



### Figure 40

- **START MODE**: Permits selection of one of the three types of functioning of the START/STOP and INTERLOCK inputs:
  - START/INTERLOCK: The pump is started if the START/STOP input is activated and is stopped if the START/STOP input is deactivated. The interlock input must be constantly active (INTERLOCK TYPE parameter = continuous) or may be active only at the time of starting (INTERLOCK TYPE parameter = impulsive).

- START/STOP LEVEL The START/STOP input acts as only START command (active on the level) The INTERLOCK input acts as STOP command (active on the level). In the case of concurrent activation of the two inputs, the STOP command takes priority
- START/STOP EDGE The START/STOP input acts as START command (active on the edge)
   The INTERLOCK input acts as STOP command (active on the edge).
- INTERLOCK TYPE: This parameter is displayed only when the previous parameter (START MODE) is equal to START/INTERLOCK and permits selection of one of the following two operating modes of the INTERLOCK input:
  - CONTINUOUS: the INTERLOCK input must be active continuously so that the pump can be driven by the controller. If, with the controller in start, the input INTERLOCK is de-activated, the controller switches to WAITING INTERLOCK status and interrupts driving of the pump
  - IMPULSIVE: it is sufficient for the input to be active when the START command is sent to the pump. Subsequently, the input can also be de-activated. If the interlock is not active when the pump is started, the controller switches too WAITING INTERLOCK status.
- **ANALOG OUT TYPE**: permits selection of the type of signal to be sent to the programmable analogue output. One of the following signals can be selected:
  - FREQUENCY: the drive frequency of the pump is shown
  - POWER: the power supplied to the pump is shown
  - TEMPERATURE: the temperature of the pump is shown
  - PRESSURE: the pressure read by the gauge is shown.

**Programming** 

- **START OUT MODE**: Selects the operating mode of the START output. Possible options:
  - RUNNING: the output is active when the pump is driven
  - STARTING: the output is active only during acceleration ramp-up.
- SPEED OUT MODE (KRPM/Hz): permits selection of the unit of measurement of the speed of rotation shown on the display of the controller.

This setting acts only on the measurement shown on the display. Possible options:

- KRPM
- = Hz
- LCD CONTRAST

# **Setpoint R1 and Setpoint R2 Submenus**

This submenu contains the settings relating to the output with relay R1 and R2 (if it is connected a gauge it will present also the settings for the set point 3).



Figure 41

**Programming** 

- R1 (R2) TYPE: selects the type of reference measurement to drive the relay. Possible types:
  - Frequency: driving frequency of the pump
  - Power: power supplied to the pump
  - Time: time from start
  - Normal: achievement of normal condition
  - Pressure: pressure read by the gauge, if present
- **R1 (R2) SET VALUE**: Sets the reference value at which the relay R1 (R2) is activated. This parameter has no effect if NORMAL (previous parameter) is selected as SETPOINT TYPE.
- **R1 (R2) HISTERESYS**: Sets, in percentage, the hysteresis of the relay
- R1 (R2) MASK TIME: sets the masked time (in hh:mm:ss), measured from start, within which the SETPOINT R1 (R2) is not driven even if the threshold value has been reached. This parameter is not available if SETPOINT TYPE is set to NORMAL
- R1 (R2) OUTPUT LOGIC: Selects the control logic of the SETPOINT output.
  - positive logic (the relay is energized when the measurement exceeds the reference)
  - negative logic (the relay is energized when the measurement is below the reference)

# Gauge Menu

This menu contains the parameters relating to functioning of the active gauge.



## Figure 42

- PRESSURE UNIT: selects the unit of measurement of the pressure used to show this on the display, for display on the serial line and for setting of the setpoint and autopressure thresholds. Possible options:
  - mbar
  - Pascal
  - Torr

**GAUGE MODEL ID:** it shows the gauge model identified by the controller. If there are more model with the same identification the user can select the right gauge connected

**Programming** 

- GAS TYPE : sets the gas type:
  - 0 : not configured
  - 1 : Nitrogen
  - 2 : Argon
  - 3 : Idrogen
  - 4 : Other
- CORRECTION : if it is selected the gas type 4 (Other) you can set the correction factor of the pressure measurement for this kind of gas. The pressure indicated by the instrument is equal to:
   P indicated = P measured x Gas correction / 10

# **Serial Menu**

This menu contains the settings for management of the RS232/485 serial line.



#### Figure 43

- BAUD RATE: permits selection of the communication speed selecting this from 600, 1200, 4800, 9600 baud
- **SERIAL MODE**: permits setting of the type of interface to RS232 (point to point) or RS485 (multidrop)
- **SERIAL ADDRESS**: sets the address of the node in the case of the RS485 interface. This parameter is not visible if the RS232 is selected.

How to Use by Remote I/0

# How to Use by Remote I/0

- 1 Power ON the controller
- 2 Press the "COUNTERS" and "MEASURES" button toghether.
- **3** Select MODE = REMOTE from the "INPUT/OUTPUT" menu
- 4 Exit from configuration menu
- 5 Connection example:

## How to Use in Serial Mode

- 1 Power on the controller
- 2 Connect the serial cable
- **3** Select by front panel if you want to work in 232 or 485, and if necessary, the serial address.
- 4 Select SERIAL from the INPUT/OUTPUT menu
- **5** Open the T+ software (see orderable parts table)
- 6 Ready to operate by SERIAL connections.

How to Use in Serial Mode



Figure 44

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

# **Profibus Option**

# General

The ProfiBus option allow to communicate with the controller as ProfiBus DP slave device.

The option works as a bi-directional bridge between the ProfiBus network and the Agilent turbo controller internal link. The interface provides input data (measures) and output data (commands) to the controller, and in addiction provides standard and user related diagnostics, in order to allow the user to manage the exceptions.

## Installation

This option is factory installed.

The ProfiBus connector pin-out is reported in the following figure. Please in order to obtain best performance use ProfiBus certified cables.





# Configuration

Before power-on the controller set the ProfiBus address by the 2 rotary switches.

Up to 126 different addresses (from 0 to 125) can be selected. The address value sets by the 2 switches is expressed in hexadecimal notation, so value from 00 to 7D are permitted; this setting is read by the interface during the power-on phase, so any change of the switch position after the power-on is ignored.

# **Software Operation and State Machine**

From the software point of view, the interface can be seen as two devices (one for ProfiBus and the other for the internal link) linked together.







**Profibus Option** 

### Tab. 16Profibus state machine

Status	Meaning
POWER_ON	Interface set-up
WAIT_PRM	Wait for parameterisation from the master
WAIT_CFG	Wait for configuration from the master
DATA_EX	Regular data exchange



### Figure 47

## Tab. 17Internal link state machine

Status	Meaning
POWER_ON	Interface set-up
SRC_ADDR	Search for the controller serial address
IDENTIFY	Identify controller model and protocol
DATA_EX	Regular data exchange

The two machines continuously share I/O data with the relative bus, and interact each other only in following conditions:

- ProfiBus Data Exchange is suspended (static diagnosis activated) if the internal serial link in not established
- Internal serial link Data Exchange is suspended (only for output data) if the ProfiBus State machine is not in Data Exchange mode

As a general rule, unrecoverable communication errors make each machine to jump to the state immediately following the power-on state (WAIT\_PRM or SRC\_ADDR)

# **Message Mapping**

The communication is based on the continuous data exchange capability of the ProfiBus standard, where the master sends continuously the entire slave configuration and reads back the entire slave status. For this purpose one Input (from slave to master) and one Output (from master to slave) buffers are provided. All the needed parameters are mapped inside each buffer.

The following tables summarise the ProfiBus parameter access, related to the corresponding windows serial protocol (for this protocol please refers to the serial interface paragraph).

The interface doesn't any scaling operation on the read/written parameters. It acts only as a gateway between the ProfiBus network and the pump's controller serial interface. As a consequence of this, the scale and the meaning of some parameters depends directly to the specific model of Turbo Pump controller connected to the interface.

**Profibus Option** 

# **Parameter Buffer**

### Tab. 18 Parameter buffer

OFFSET BYTE	SIZE BYTE	UNIT RES	RANGE	DESCRIPTION	WIN SERIAL
0	1	-	0-99	Gauge gas load type. The value is divided by 10 (entering 12 the controller will apply 1.2) Enter here the correction factor for gas (necessary only if gauge is connected).	161
1	2	mA/Hz/sec	0-10000	Setpoint 1 value. Enter here the threshold value for the R1 output, valid only if $B_0$ - $B_2$ of Parameter Buffer Offset-21 is equal to 0,1,2 or 3.	102
3	2	Sec	0-30000	Setpoint 1 Mask Time. Set here the time, measured from the start pump event, while the R1 output is masked (not activated)	103
5	2	mA/Hz/sec	0-10000	Setpoint 2 value. Enter here the threshold value for the R2 output, valid only if $B_3$ - $B_5$ of Parameter Buffer Offset-21 is equal to 0,1,2 or 3.	172
7	2	Sec	0-30000	Setpoint 2 Mask Time. Set here the time, measured from the start pump event, while the R2 output is masked (not activated)	173
9	2	0.2sec/bit	0-30000	Vent Valve Opening Delay. Set the delay time between the stop command and vent opening. Valid only in "purge/vent auto mode" (Parameter Buffer, Offset 20, $B_0 = 0$ ). $0 = infinite$ (the valve will never open).	126
11	2	0.2sec/bit	0-30000	Vent Valve Open Time. Set how long the vent will remain open, then both purge and vent will be closed. Valid only in "purge/vent auto mode" (Parameter Buffer, Offset 20, $B_0 = 0$ ). $0 =$ infinite (the valve remain open till next start command).	147
13	1	%	1-99	Setpoint 1 Hysteresis. Set the Setpoint1 hysteresis around the nominal value	105
14	1	%	1-99	Setpoint 2 Hysteresis. Set the Setpoint2 hysteresis around the nominal value	175
15	1	mBar/Torr/P a	0-99	Setpoint 1 Pressure Value Mantissa. Set the mantissa of the exponential value of the R1 setpoint (format X.XE-XX) when it is used for pressure monitoring (Parameter Buffer, Offset 21, $B_{0.2} = 4$ ). The value set here is divided by 10, that means 11 = 1.1	162

**Profibus Option** 

OFFSET Byte	SIZE BYTE	UNIT RES	RANGE	DESCRIPTION	WIN SERIAL
16	1		-10 - +10	Setpoint 1 Pressure Value Exponent. Set the exponent of the exponential value of the R1 setpoint (format X.XE-XX) when it is used for pressure monitoring (Parameter Buffer, Offset 21, $B_{0.2} = 4$ ).	162
17	1	mBar/Torr/P a	0-99	Setpoint 2 Pressure Value Mantissa. Set the mantissa of the exponential value of the R2 setpoint (format X.XE-XX) when it is used for pressure monitoring (Parameter Buffer, Offset 21, $B_{3\cdot5} = 4$ ). The value set here is divided by 10, that means 11 = 1.1	176
18	1		-10 - +10	Setpoint 2 Pressure Value Exponent. Set the exponent of the exponential value of the R2 setpoint (format X.XE-XX) when it is used for pressure monitoring (Parameter Buffer, Offset 21, B <sub>3-5</sub> = 4).	176
19	1			B <sub>0</sub> = Stop Speed Reading. This function measures the pump speed after a stop command. 0 = Off 1 = On	167
				<ul> <li>B1= Active Stop.</li> <li>This function brakes the pump after a stop command, by using the motor as a generator.</li> <li>0 = Off</li> <li>1 = On</li> </ul>	107
				B <sub>2</sub> - Reserved	
				B <sub>3-4</sub> = Start/Stop/Interlock Mode. Change the logic of Start/Stop and Interlock inputs. Ask to Agilent personnel for this option	151
20	1			B <sub>0</sub> = Vent & Purge Auto/Man 0 = Auto (the controller drives purge and vent valves automatically) 1 = Manual (the user can command the valves by serial line or profibus)	125

**Profibus Option** 

OFFSET BYTE	SIZE BYTE	UNIT RES	RANGE	DESCRIPTION	WIN SERIAL
				$B_1 = Gas$ Load Type. Select here the gas load	157
				0 = Ar	
				1 = N2	
				B <sub>2</sub> = Interlock Type	110
				0 = continuos (the interlock must be always present	
				to run the pump)	
				1 = at start (the interlock must be present only at	
				start command)	
				B <sub>3</sub> = Setpoint R1 Logic	104
				0 = active close (NO)	
				1 = active open (NC)	
				B <sub>4</sub> = Setpoint R2 Logic	174
				0 = active close (N0)	
				1 = active open (NC)	
				B <sub>5-6</sub> = Pressure Unit	163
				0 = mbar	
				1 = Pascal	
				2 = Torr	
				B <sub>7</sub> = Reserved	
21	1			B <sub>0-2</sub> = Setpoint R1 Type	101
				0 = frequency	
				1 = current	
				2 = time	
				3= normal operation	
				4= pressure	
				B <sub>3-5</sub> = Setpoint R2 Type	171
				0 = frequency	
				1 = current	
				2 = time	
				3= normal operation	
				4= pressure	
				B <sub>6-7</sub> = Analog Output 1 Type	111
				0 = frequency	
				1 = power	
				2 = temperature	
				3= pressure	

Technical Information 8 Profibus Option

# **Output Buffer**

Tab. 19	Output buffer
---------	---------------

OFFSE T BYTE	SIZE BYTE	UNIT RES	RANGE	DESCRIPTION	WIN SERIAL
0	1			B7 = Start/Stop	000
				0 = Stop, 1 = Start	
				B <sub>6</sub> = Low Speed	001
				This bit set the pump target speed to "low speed	
				value" (Output Buffer, Offset 3), otherwise the	
				target speed is set to "high speed value" (Output	
				Buffer, Offset 1).	
			-	0 =0ff, 1 =0n	
				$B_5$ – Soft Start	100
				This bit activates the soft start function which run-	
				up the pump smoothly. Please activate this function	
				only if the pump has been stopped for at least3	
				months.	
				0 = 0n, 1= 0tt	
				$B_4 = Vent Valve Command$	122
				U = Close, I = Upen	
				Valid only it in Par Buff, Offset-20, Bo=1	
				$B_3 = Purge Valve Command$	145
				U = Close, I = Upen	
			-	Valid only if Par Buff, Uffset-20, Bo=1	
				B <sub>2</sub> – Not used	
				B <sub>0-1</sub> = Operating Mode	800
				These bits define from which source the controller	
				has to get commands (readings are always	
				available). In order to operate the controller by	
				Profibus these bits must be set to 3.	
				1 = Serial	
				2 - From patter	
1	2	Ц <sub>7</sub>	1100	High Spood Value	120
	2	112	1350	Set the high rotational speed value	120
2	2	Ц <sub>7</sub>	1100		117
5	2	112	1350	Set the low rotational speed value	117

**Profibus Option** 

# **Input Buffer**

### Tab. 20 Input buffer

OFFSET BYTE	SIZE BYTE	UNIT RES	RANGE	DESCRIPTION	WIN SERIAL
0	1	V	0-100	Voltage Voltage provided to the motor	201
1	1	°C	0-100	Pump Bearing Temperature Read the pump upper bearing temperature If > 60 °C the controller goes into fail status and the pump is stopped	204
2	1	°C	0-100	Controller Power Supply Temperature Read the controller power section temperature if > 75 °C the controller goes in fail status "controller over-temperature"	216
3	1	°C	0-100	Controller CPU Section Temperature Read the controller CPU section temperature if > 80 °C the controller goes in fail "controller overtemperature"	211
4	1	-	0-6	B <sub>0:3</sub> – Status         0 = Stop         1= Waiting for interlock (interlock connections on remote I/O connector missing)         2 = Ramp (the pump is increasing the speed)         3 = Auto tuning (the speed has been reduced because the gas load is higher than the Power Limit Applied)         4 = Braking (the pump is reducing the speed using the motor)         5 = Normal operation (the pump is at target speed)         6 = Fail (see error code byte Input Buffer Byte-27)	205
5	1	-	-	Error Code (bit field)	206
				B7 – Too High Load (the gas load is too high for the pump)	
				$B_{\rm 6}-$ Short Circuit (a short circuit happened between the two of the three motor phases)	
				$B_{5}-Over$ Voltage (too high bus voltage during braking)	
				B₄ – Verify Line Select Not used	
				B <sub>3</sub> – Power Fail (internal circuitry failure)	

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

**Profibus Option** 

OFFSET BYTE	SIZE BYTE	UNIT RES	RANGE	DESCRIPTION	WIN SERIAL	
				B <sub>2</sub> – Controller Over-Temperature ("Controller Power Section Temperature" or "Controller CPU Section Temperature" are over the limit)		
				B <sub>1</sub> - Pump Over-Temperature ("Pump Bearing Temperature" or "Pump Body Temperature" are over the limit)		
				$B_{0}-$ Check Connection To Pump (the connection between controller and pump missing)		
6	1	-	-	$B_0$ — Set Point R1 Status 0 = open 1 = closed	221	
				B <sub>1</sub> – Set Point R2 Status 0 = open 1 = closed	225	
				B <sub>2</sub> – Vent Valve Status 0 = closed 1 = open	122	
				B <sub>3</sub> – Purge Valve Status 0 = close 1 = open	145	
				B <sub>4</sub> – Not Used		
				B <sub>5</sub> – Not Used		
				B <sub>6</sub> – Not Used		
				B7 – Not Used		
7	2	mA	0-10000	Current Motor current consumption	200	
9	2	W	0-200	Power Motor power adsorption	202	
11	2	W	0-200	Power Limit Applied Maximum allowable power	155	
13	2	Hz	0-1500	Driving Frequency Read the rotational speed of the pump	203	
15	2	Hz	0-1500	Target Frequency Read the target rotational speed	120	

TwisTorr 305 FS Remote Controller User Manual / 87-901-059-01

175/190

**Profibus Option** 

OFFSET BYTE	SIZE BYTE	UNIT RES	RANGE	DESCRIPTION	WIN SERIAL
17	2	-	0-65536	Cycle Number Number of cycles (start and stop) done by the pump	301
19	2	min	0-65536	Last Cycle Time How long the last cycle lasted	300
21	2	h	0-65536	Pump Life Total pump running time	302
23	4	mBar/ Torr/Pa	-	Pressure Reading Reports the pressure reading in the "pressure unit" selected by Par. Buff., Offset-20, B <sub>5-6</sub>	224

# **Diagnostic Management**

In addition to the ProfiBus six byte standard diagnostic, the interface provides both user diagnostic and static diagnostics functions.

The standard diagnostic management is fully compliant with the ProfiBus specification.

During the start-up phase after power on, the first byte in the user diagnostic area, can assume values different from zero.

This byte has the following meaning:

- Bit 0 = 1: controller not responds (RS485 link broken)
- Bit 1 = 1: controller not identified (not compatible with the ProfiBus gateway)
- Bit 2 = 1: first loop of requests not ended (values in the input data are not fully coherent yet)

So, if the first byte is equal to 0, the interface is working properly, otherwise there is a problem.

Each nibble in the bytes following the interface status byte represents the status of the last attempt to write a parameter with following coding (diag status byte):

- 0 Write success
- 1 Controller response was "NACK"
- 2 Controller response was "Unknown window"
- 3 Controller response was "Bad Data Type"
- 4 Controller response was "Over range"
- 5 Controller response was "Bad operation"
- 6 Controller response was an unknown response
- F Parameter not supported by the controller

The ProfiBus external diagnosis services are used to report following unexpected situations:

- Controller fail: if the controller goes in fail mode, an external diagnostic service is required and one byte in the diagnostic buffer signals the type of failure.
- User parameter mismatch: if the user sets one or more parameters out of their allowed range, a ProfiBus external diagnostic service is required and some bits in the diagnosis frame signals which parameter is wrong (i.e. over range or under range).

**Profibus Option** 

# **Diagnostic Buffer**

100.21										
OFF SET	MEANING									
0	<ul> <li>B<sub>0</sub> station non exist (set by master)</li> <li>B<sub>1</sub> station not ready (slave not ready for data exchange)</li> <li>B<sub>2</sub> cfg fault (configuration data doesn't match)</li> <li>B<sub>3</sub> ext diag (slave has external diagnostic data)</li> <li>B<sub>4</sub> not supported (slave doesn't support requested function)</li> <li>B<sub>5</sub> invalid slave response (slave sets permanent '0')</li> <li>B<sub>6</sub> prm fault (wrong parameter assignment)</li> <li>B<sub>7</sub> master_lock (slave is parameterised by another master)</li> </ul>									
1	<ul> <li>B0 prm req (slave has to be re-parameterised)</li> <li>B1 stat diag (static diagnosis)</li> <li>B2 fixed '1'</li> <li>B3 wd_on (response monitoring active)</li> <li>B4 Freeze mode (received freeze command)</li> <li>B5 Synch mode (received synch command)</li> <li>B6 reserved</li> <li>B7 diag deactivated (slave is parameterised by another master)</li> </ul>	Standard diagnostic								
2	Reserved									
3	Master Add (master address after parameterisation. FF= without parameter)									
4	ldent number high									
5	Ident number low									
6	External diagnosis "Header" length indication including header									

**Profibus Option** 

OFF SET	MEANING									
7	Interface Status									
	B <sub>0</sub> Controller not responds									
	B1 Controller not identified									
	B <sub>2</sub> Input data not fully coherent yet									
	B <sub>3</sub> Not used									
	B <sub>4-7</sub> Not used									
8	B <sub>7-4</sub> – Start/Stop diag status									
	B <sub>3-0</sub> – Low Speed diag status									
9	B <sub>7-4</sub> – Soft Start diag status									
	B <sub>3-0</sub> – Vent Valve									
10	B7.4 – Purge Valve									
	B <sub>3-0</sub> – Mode									
11	B <sub>7-4</sub> – High speed									
	B <sub>3-0</sub> – Low Speed									

**Error Messages** 

## **Error Messages**

For a certain type of failure, the controller will self-diagnose the error and the following messages will be displayed.

#### NOTE

If the pump is not connected, the display will be as shown in the following figure.

C	Н	Ε	C	К	C	0	Ν	Ν	Ε	C	Т	I	0	Ν
			Т	0	Р	U	М	Р						

Check connection between controller and pump, then press STOP pushbutton twice to start the pump.

NOTE

If the P1 input connector is not in position with the link or the external interlock connections are open, when the START pushbutton is pressed the display will be as shown in the following figure.

			w	Α	I	Т	I	Ν	G			
		I	Ν	Т	Ε	R	L	0	C	К		

Disconnect connector P1 and check the link or the external interlock, then install the connector to start the pump.

## NOTE

If within each step of the soft start mode the rotational speed of the pump do not reach the planned value within 15 minutes the display will be as shown in the following figure.
	R	U	Ν	U	Р	Т	Ι	М	Ε		

Adjust the process gas flow as appropriate in order to allow the pump to always spin at a speed value greater than 700Hz.

NOTERun Up Time is the maximum amount of time for which the pump is allowed to<br/>spin at a speed value less than the normal operating speed.<br/>The pump is not intended to spin for an indefinite time at a speed value lower<br/>than 700Hz. If the pump, due to the gas flow applied to it, spins at a speed value<br/>less than 700Hz, the Run Up timer starts to count; when the counter value<br/>exceeds the Run Up Time set value, the pump will stop and the error condition<br/>"Run Up Time" will appear on the display.

# NOTE

If in normal operation (after the starting phase) the current drawn by the pump is higher than programmed (1.8 A), the pump and the inter-connected devices are switched off and the display will be as shown in the following figure.

Т	0	0	Н	Ι	G	Н	L	0	Α	D	

Verify that systems has no leaks than press STOP RESET pushbutton twice to start the pump.

Check that pump rotor is free to rotate then press the STOP RESET pushbutton twice to start the pump.

NOTE

If the upper bearing/pump temperature exceeds 60 °C, the pump is shut off, and the display will be as shown in the following figure.

				Р	U	М	Р				
		0	۷	E	R	Т	E	М	Ρ		

The message will stay on until the temperature decreases below threshold value. Press the STOP RESET pushbutton twice to start the pump.

# 8 Technical Information

**Error Messages** 

# NOTE

If the controller transformer temperature exceeds 90°C, the pump is shut off, and the display will be as shown in the following figure.

	C	0	Ν	т	R	0	L	L	Ε	R		
		0	۷	Ε	R	Т	E	М	Р			

# NOTE

If the pump is stopped by an emergency stop signal provided via a remote contact, the display will be as shown in the following figure.

		S	Y	S	Т	Ε	М				
	0	۷	Ε	R	R	-	D	Ε			

Remove the controller power cable and check the emergency condition.

Then reconnect the power cable and press the START pushbutton to start the pump.

	0	V	Ε	R	v	0	L	Т	Α	G	Ε		

Controller power supply circuitry is faulty, or the Controller received a spike.

Press the START push-button twice to start the pump. Should the message still be present, call the Agilent service.

S	Η	0	R	Т	C	Ι	R	C	U	I	Т	

Check connections and shortages between pump and controller, then press the STOP RESET pushbutton twice to start the pump.

# **Orderable Parts**

# Tab. 22

Description	Part number
Air Cooling Kit (0.5 m cable)	X3500-68011
Air Cooling Kit extention cable (5 m)	9699940
Vent Valve N.O. 0,5 mm orifice (0,5 m cable)	9699844
Vent Valve extention cable (5 m)	9699941
Mains cable NEMA plug (3 m)	9699958
Mains cable european plug (3 m)	9699957
RS232 Serial to B/T Adapter	X3514-68003

# 8 Technical Information

**Orderable Parts** 

Page intentionally left blank



# Vacuum Products Division

Dear Customer,

Thank you for purchasing an Agilent vacuum product. At Agilent Vacuum Products Division we make every effort to ensure that you will be satisfied with the product and/or service you have purchased.

As part of our Continuous Improvement effort, we ask that you report to us any problem you may have had with the purchase or operation of our products. On the back side you find a Corrective Action request form that you may fill out in the first part and return to us.

This form is intended to supplement normal lines of communications and to resolve problems that existing systems are not addressing in an adequate or timely manner.

Upon receipt of your Corrective Action Request we will determine the Root Cause of the problem and take the necessary actions to eliminate it. You will be contacted by one of our employees who will review the problem with you and update you, with the second part of the same form, on our actions.

Your business is very important to us. Please, take the time and let us know how we can improve.

Sincerely.

Giampaolo LEVI Vice President and General Manager Agilent Vacuum Products Division

Note: Fax or mail the Customer Request for Action (see backside page) to Agilent Vacuum Products Division (Torino) – Quality Assurance or to your nearest Agilent representative for onward transmission to the same address.

# CUSTOMER REQUEST FOR CORRECTIVE / PREVENTIVE / IMPROVEMENT ACTION

TO: AGILENT VACUUM PRODUCTS DIVISION TORINO – QUALITY ASSURANCE FAX

N°: XXXX-011-9979350

ADDRESS: AGILENT TECHNOLOGIES ITALIA S.p.A. – Vacuum Products Division –

Via F.lli Varian, 54 – 10040 Leinì (TO) – Italy

E-MAIL: vpd-qualityassurance\_pdl-ext@agilent.com

NAME	COMPANY	FUNCTION
ADDRESS:		
TEL. N° :	FAX N° :	
E-MAIL:		
PROBLEM / SUGGESTION :		
REFERENCE INFORMATION (model n	of serial n°, ordering information, time	e to failure after installation, etc.):
	Di	ATE
CORRECTIVE ACTION PLAN / ACTUAT	ΓΙΟΝ	LOG N°
(by AGILENT VPD)		

XXX = Code for dialing Italy from your country (es. 01139 from USA; 00139 from Japan, etc.)





# Vacuum Products Division Instructions for returning products

Dear Customer,

Please follow these instructions whenever one of our products needs to be returned.

Complete the attached **Request for Return form** and send it to Agilent Technologies (see below), taking particular care to include the completed **Health and Safety** declaration Section. No work can be started on your unit until we receive a completed copy of this form.

After evaluating the information, Agilent Technologies will provide you with a **Return Authorization (RA) number** via email or fax, as requested. Note: Depending on the type of return, a Purchase Order may be required at the time **the Request** for **Return is submitted**. We will quote any necessary services (evaluation, repair, special cleaning, eg).

# Product preparation

- o Remove all accessories from the core product (e.g. inlet screens, vent valves).
- Prior to shipment and if applicable for your product, drain any oils or other liquids, purge or flush all gasses, and wipe off any excess residue.
- If ordering an Advance Exchange product, please use the packaging from the Advance Exchange to return the defective product.
- Seal the product in a plastic bag, and package product carefully to avoid damage in transit. You are responsible for loss or damage in transit.
- Include a copy of the Health and Safety Declaration in the shipping documentation on the outside of the shipping box of your returning product.
- Clearly label package with RA number. Using the shipping label provided will ensure the proper address and RA number are on the package. Packages shipped to Agilent without a RA clearly written on the outside cannot be accepted and will be returned.
- Return only products for which the RA was issued.

### Shipping

- Ship to the location specified on the printable label, which will be sent, along with the RA number, as soon as we have received all of the required information. Customer is responsible for freight charges on returning product.
- Return shipments must comply with all applicable Shipping Regulations (IATA, DOT, ADR, etc.) and carrier requirements.

# RETURN THE COMPLETED REQUEST FOR RETURN FORM TO YOUR NEAREST LOCATION:

	EUROPE:		NORTH AMERICA:	PACIFIC RIM:
Fax:	00 39 011 9979 330			
Fax Free:	00 800 345 345 00	Fax:	1 781 860 9252	Please visit our website for
Toll Free:	00 800 234 234 00	Toll Free:	800 882 7426, Option 3	individual office information
vpt-custom	nercare@agilent.com	vpl-ra@agil	ent.com	http://www.agilent.com



Vacuum Products Division Terms and conditions

# **TERMS AND CONDITIONS**

Please read the terms and conditions below as they apply to all returns and are in addition to the Agilent Technologies Vacuum Product Division – Products and Services Terms of Sale.

- Unless otherwise pre-negotiated, customer is responsible for the freight charges for the returning product. Return shipments must comply with all applicable Shipping Regulations (IATA, DOT, etc.) and carrier requirements.
- Agilent Technologies is not responsible for returning customer provided packaging or containers.
- Customers receiving an Advance Exchange product agree to return the defective, rebuildable part to Agilent Technologies within 15 business days. Failure to do so, or returning a non-rebuildable part (crashed), will result in an invoice for the non-returned/non-rebuildable part.
- Returns for credit toward the purchase of new or refurbished Products are subject to prior Agilent approval and may incur a restocking fee. Please reference the original purchase order number.
- Units returned for evaluation will be evaluated, and a quote for repair will be issued. If you choose to have the unit repaired, the cost of the evaluation will be deducted from the final repair pricing. A Purchase Order for the final repair price should be issued within 3 weeks of quotation date. Units without a Purchase Order for repair will be returned to the customer, and the evaluation fee will be invoiced.
- Products returned that have not been drained from oil will be disposed.
- A Special Cleaning fee will apply to all exposed products.
- If requesting a calibration service, units must be functionally capable of being calibrated.



Customer information						
Company :		Contact Nar	me:			
Address:		Tel:			Fax:	
		Email:				
Farriannant						
Equipment	1					
Product description	Agilent PartNo	Agilent Seri	al No		Original Purchasing	g Reference
Failure description		Type of proc	cess (for whi	ch the equip	ment was used)	
Type of return						
🗌 Non Billable 🔲 Billable 페 🕨 N	ew PO # (hard copy must be	submitted with thi	is form):			
🗌 Exchange 🛛 Repair 🗌 Upg	rade 🗌 Demo 🗌	] Calibration	🗌 Evaluati	on 🗌	Return for Credit	
Health and safety		Substances	(please refe	r to MSDS	forms)	
The product has been exposed to the fo	ollowing substances:	* Agilent will not	t accept delivery	of any produc	ct that is exposed to radioad	ctive, biological,
(by selecting 'YES' you MUST complete the table to	the right)	Trade name	Cher	nical name	Chemical Symbol	CAS Number
Toxic		Trade fiame	Unici		Unennear Oymbol	
Harmful						
Corrosive	YES NO					
Reactive	YES NO					
Flammable	🗌 YES 🗌 NO					
Explosive (*)	YES NO					
Radioactive (*)	YES NO					
Biological (*)						
Oxidizing						
Sensitizer						
Uther dangerous substances	LI YES LI NO					
Goods preparation						
If you have replied YES to one of the above q	uestions. Has the product l	been purged?				)
Heathe product been drained from ail?						
I confirm to place this declaration on the out	side of the shipping box.					JI AFFLICADLE
· · · · · · · · · · · · · · · · · · ·						
I declare that the ab	ove information is true	and complete	e to the bes	t of mv kn	owledge and belief	
l understan	d and agree to the tern	ns and conditi	ons on pag	e 2 of this	document.	
Name:		Authorize	d Signature	:		
Position:						
Date:		-				
NOTE: If a product is received at Agilent w	hich is contaminated with	a toxic or hazar	rdous materia	l that was r	not disclosed, <b>the custo</b>	mer will be held
responsible for all costs incurred to ensure t	he safe handling of the pro	duct, and is liable	e for any harm	or injury to	Agilent employees as w	ell as to any third
party occurring as a result of exposure to tox	kic or hazardous materials p	resent in the pro	duct.			

# **United States**

**Agilent Technologies** 121 Hartwell Avenue Lexington, MA 02421 - USA Ph. +1 781 861 7200 Fax: +1 781 860 5437 Toll-Free: +1 800 882 7426 vpl-customercare@agilent.com

#### Netherlands

# Agilent Technologies Netherlands B.V.

**Customer Contact Center** Laan van Langerhuize 1, toren A-8 1186 DS Amstelveen Tel. +31 020 547 2600 Fax +31 020 654 5748 customercare netherlands@agilent.com

#### Belaium

# Agilent Technologies Belgium S.A./N.V.

**Customer Contact Center** Pegasus Park De Kleetlaan 12A bus 12 B-1831 Diegem Tel. +32 2 404 92 22 Fax +32 2 626 46 30 customercare belgium@agilent.com

### Brazil

#### **Agilent Technologies Brasil**

Avenida Marcos Penteado de Ulhoa Rodrigues, 939 - 6° andar Castelo Branco Office Park Torre Jacarandá - Tamboré Barueri, Sao Paulo CEP: 06460-040 Toll free: 0800 728 1405

### China

#### Agilent Technologies (China) Co. Ltd

No.3, Wang Jing Bei Lu, Chao Yang District Beijing, 100102, China Tel: +86 (0)10 64397888 Fax: +86 (0)10 64392765 Toll free: 400 8206778 (mobile) Toll free: 800 8206778 (landline) vacuum.cnmarketing@agilent.com vpc-customerservice@agilent.com

#### France

Agilent Technologies Parc Technopolis - Z.A. de Courtaboeuf 3. avenue du Canada - CS 90263 91978 Les Ulis cedex, France Tel: +33 (0) 1 64 53 61 15 Fax: +33 (0) 1 64 53 50 01 vpf.sales@agilent.com

#### Southeast Asia

Agilent Technologies Sales Sdn Bhd Unit 201. Level 2 uptown 2. 2 Jalan SS21/37, Damansara Uptown 47400 Petaling Jaya, Selangor, Malaysia Ph. +603 7712 6181 Fax: +603 7727 1239 Toll free: 1 800 880 805 vps-customerservice@agilent.com

#### Agilent Vacuum Products Division/Sales and Service Offices

#### India (Sales) Agilent Technologies India Pvt. Ltd.

Unit Nos 110- 116, & Part of 101 & 109 First Floor, Splendor Forum, Plot No.-3, District Centre, Jasola New Delhi-110025 Ph. +91 11 4623 7100 Fax: +91 4623 7105 Toll Free: 1 800 180 1517

#### Italy

#### Agilent Technologies Italia S.p.A. Via F.Ili Varian, 54

10040 Leini, (Torino) - Italy Tel: +39 011 9979 111 Fax: +39 011 9979 350 Toll free: 00 800 234 234 00 vpt-customerservice@agilent.com

### Janan

Agilent Technologies Japan, Ltd. 9-1 Takakura-cho Hachioji-city, Tokyo, Japan Tel.: +81- 3-5232-1253 Fax: +81-120-565-154 Toll-Free: +81-120-477-111 jp-vvt-sales.pdl-ext@agilent.com

#### Singapore

#### Agilent Technologies Singapore Pte. Ltd, 1 Yishun Avenue 7, Singapore 768923 Tel: (65) 6215 8045 Fax : (65) 6754 0574 Toll free: 1 800 2762622 vps-customerservice@agilent.com

# Korea

#### Agilent Technologies Korea, Ltd. Ilshin Builiding 4F Yongsan-gu Hannam-daero Seoul Korea 04418 Tel: +82 (0)2 2194 9449 Fax: +82 (0)2 2194 9853 Toll free: 080 222 2452 vpk-customerservice@agilent.com

#### UK and Ireland

Agilent Technologies LDA UK Limited Lakeside Cheadle Royal Business Park Cheadle, Cheshire SK8 3GR. United Kingdom Ph. +44 01865291570 Fax +44 01865291571 Toll free: 00 800 234 234 00 Toll free fax: 00 800 345 345 00 vpt-customercare@agilent.com

© Agilent Technologies, Inc. 2018 07/2018



# **Agilent Technologies**

#### India (Service)

Agilent Technologies India Pvt. Ltd. C-Block, BMZ Centennial Plot Number- 8A, 8B, 8C, 8D. Doddanakundi Industrial Area, ITPL Road, Mahadevapura Post, Bangalore- 560048 Ph. +91 80 40614000 Fax: +91 80 40148991

# Taiwan

#### Agilent Technologies Taiwan Limited

No. 20 Gao-shuang Road, Ping-zhen Dist Tao-Yuan City 32450 Taiwan, R.O.C. Tel: +886 3 4959004 Toll free: 0800 018 768 vpw-customerservice@agilent.com

#### Germany and Austria

**Agilent Technologies** Sales & Services GmbH & Co. KG Lyoner Str. 20 60 528 Frankfurt am Main GERMANY Tel: +49 69 6773 43 2230 Fax: +49 69 6773 43 2250

#### Mexico

#### **Agilent Technologies** Concepcion Beistegui No 109 Col Del Valle

C.P. 03100 - Mexico, D.F. Tel.: +52 5 523 9465 Fax: +52 5 523 9472

# Other Countries

Agilent Technologies Italia S.p.A. Via F.Ili Varian, 54 10040 Leini, (Torino) - Italy Tel.: +39 011 997 9111 Fax: +39 011 997 9350 Toll-Free: 00 800 234 234 00 vpt-customercare@agilent.com

# **Customer Support & Service**

NORTH AMERICA: Toll Free: 800 882 7426 vpl-ra@agilent.com Lexington-service@agilent.com

FUROPE: Toll Free: 00 800 234 234 00 vpt-customercare@agilent.com

#### PACIFIC RIM:

please visit our website for individual office information http://www.agilent.com/chem/vacuum

Worldwide Web Site, Catalog and Order Online<sup>.</sup>

www.agilent.com/chem/vacuum Representatives in most countries

