

WARNING: Do Not Operate Before Reading Manual

KD Series OPERATOR'S MANUAL

Models

KD-30

KD-50






The employees of Tuthill Vacuum & Blower Systems thank you for your purchase!

Tuthill Vacuum & Blower Systems proudly manufactures Kinney® vacuum pumps and M-D Pneumatics™ blowers and vacuum boosters in Springfield, Missouri, USA. We bring 100+ years of engineering experience and solid, hands-on care to help customers keep their processes running. Your satisfaction is important to us so please take time to provide your Tuthill sales representative with performance feedback. We love to hear from our customers!

Tuthill is a family owned business that was started by James B. Tuthill in 1892. At that time, Tuthill manufactured common brick to Chicago construction companies who were fueling the city's rapid expansion. Fast forward to today and Tuthill now serves sustaining, global markets like agriculture, chemical, construction, energy, food and beverage, pharmaceuticals and medical, transportation, and utilities. While the company has changed in what it manufactures, one thing remains throughout every Tuthill line of business – we are a company with HEART. Our slogan is “Pump Your Heart Into It” and everyday our employees do just that as they represent the Tuthill brand and dare to make better.

Thank you for making Tuthill Vacuum & Blower Systems part of your company's process!

A company with heart
right from the start.



FIND OUT MORE AT
TUTHILL.COM

Disclaimer Statement:

All information, illustrations and specifications in this manual are based on the latest information available at the time of publishing. The illustrations used in this manual are intended as representative reference views only. Products are under a continuous improvement policy. Thus, information, illustrations and/or specifications to explain and or exemplify a product, service or maintenance improvement may be changed at any time without notice.

Rights Reserved Statement:

No part of this publication may be reproduced or used in any form by any means - graphic, electronic or mechanical, including photocopying, recording, taping or information storage and retrieval systems - without the written permission of Tuthill Vacuum & Blower Systems.

Copyright © 2019 Tuthill Vacuum & Blower Systems
All rights reserved. Product information and specifications subject to change.

Table of Contents

Introduction	1
Applicable Documentation	1
Scope of Manual.....	1
Conventions, Safety and Data Plate.....	2
Graphic Conventions Used in this Manual.....	2
Safety Instruction Tags.....	2
Safety Precautions for Rotary Piston Pumps.....	3
Data Plate.....	4
Lifting	5
Description	6
General	6
Pump Components	6
Operating Cycle	8
Sealing and Lubricating.....	8
Oil Types	8
Installation	9
General	9
V-Belt Drive.....	9
Direct Drive	10
Discharge Piping	10
Inlet Piping	10
Vacuum Gauges	11
Electrical Connections	11
Operation	12
General	12
Filling Pump with Oil.....	12

Pre-Start Checks	12
Starting.....	12
Stopping.....	13
Gas Ballast.....	13
Maintenance	14
General	14
Changing Oil	14
V-Belts	14
Gear Drive Units.....	14
Draining and Refilling Oil	14
Bearing Lubrication.....	15
Cleaning.....	15
Oil Separator	15
Disassembly / Assembly	17
Disassembly.....	17
Reassembly.....	17
Troubleshooting.....	19
Starting Troubles or Stalling	19
Checking Pump Performance	19
Pump Leaks	20
Oil Contamination.....	21
Discharge Valves	21
Shaft Seal	22
Replacement Parts.....	25
General	25
Spare Parts	25
KD-30A Exploded View Drawing	26
KD-30A Parts List.....	27
KD-50B Exploded View Drawing	28
KD-50B Parts List.....	29
Declaration of Incorporation.....	30
Warranty – Vacuum Products	31
Operating Data Form / Product Registration.....	32

INTRODUCTION

CONGRATULATIONS on the purchase of a new **KINNEY® KD** Single-Stage, Duplex Rotary Piston Vacuum Pump from Tuthill Vacuum & Blower Systems. Please examine the pump for shipping damage, and if any damage is found, report it immediately to the carrier. If the pump is to be installed at a later date, make sure it is stored in a clean, dry location and rotated regularly. Make sure covers are kept on all openings. If pump is stored outdoors, be sure to protect it from weather and corrosion.

This manual applies to Kinney Vacuum models KD-30 and KD-50. Be thoroughly familiar with these instructions before attempting to install, operate, or repair this unit. Consult Tuthill Vacuum & Blower Systems when problems arise that cannot be resolved after reading this manual. Always include pump nameplate information when ordering parts or components.

KINNEY KD vacuum pumps are built to exacting standards and, if properly installed and maintained, will provide many years of reliable service. Read and follow every step of these instructions when installing and maintaining the pump.

NOTE: Record the pump model and serial numbers of the machine in the **OPERATING DATA FORM** on the inside back cover of this manual. Use this identification on any replacement part orders, or if service or application assistance is required.

APPLICABLE DOCUMENTATION

The applicable documents associated with this manual are:

- EN 1012-1:1996 - Compressors and vacuum pumps - Safety Requirements - Part 2: Vacuum Pumps

SCOPE OF MANUAL

The scope of this manual includes the following components as offered by Tuthill Vacuum & Blower Systems: Rotary Piston Pump.

CAUTION

Read manual before operation or bodily harm may result. Attention should be given to the safety related sections of this manual.

02

CONVENTIONS, SAFETY AND DATA PLATE

GRAPHIC CONVENTIONS USED IN THIS MANUAL

The following hazard levels are referenced within this manual:



DANGER

Indicates a hazardous situation that, if not avoided, will result in death or serious injury.



WARNING

Indicates a hazardous situation that, if not avoided, could result in death or serious injury.



CAUTION

Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates a situation that can cause damage to the engine, personal property, and/or the environment or cause the equipment to operate improperly.

NOTE: Indicates a procedure, practice, or condition that should be followed in order for the equipment to function in the manner intended.

SAFETY INSTRUCTION TAGS



WARNING



Do not operate without belt guard.



CAUTION

Do not valve or restrict pump discharge opening.

Use oil mist eliminator when operating pump, ensure adequate ventilation when discharging indoors.

Refer to manual safety instructions.

NOTICE

The above safety instruction tags were permanently affixed to your pump prior to shipment. Do not remove, paint over or obscure in any manner.

Failure to heed these warnings could result in serious bodily injury to the personnel operating and maintaining this equipment.

SAFETY PRECAUTIONS FOR ROTARY PISTON PUMPS

Please read the following safety information before operating the vacuum pump.

- Do not operate the pump without the beltguard properly attached.
- Disconnect the pump from the electrical supply at the main disconnect before removing the beltguard. Replace the beltguard before reconnecting the power supply. Operating the pump without the beltguard secured in place exposes people in the vicinity of the pump to risk from rotating drive parts.
- Do not operate the pump with oxygen-enriched gas in the suction line, where the proportion of oxygen exceeds 21%, unless the pump has been prepared with an inert fluid suitable for the application. Pumping oxygen-enriched gases with mineral oil or other non-inert fluids can cause an explosion in the pump, resulting in damage or injury.
- Take precautions to avoid prolonged or excessive exposure to oil mist or process materials from the discharge of the pump. Do not allow the pump to discharge into a closed room or a room without adequate ventilation. Always use a discharge oil mist eliminator unless the pump discharge is vented to the open air. Venting the outlet of the oil mist eliminator to the open air is highly recommended.
- Do not restrict the pump discharge line in any way or place any valves in the discharge line. The vacuum pump is a compressor and will generate high pressures without the motor stalling when operated at low suction pressures. Excessive pressure buildup could cause damage or injury.
- Disconnect the pump from the electrical supply at the main disconnect before dismantling or servicing the pump. Make sure the pump is completely reassembled, the beltguard is replaced, and all drain and fill valve and plugs are closed before reconnecting the power supply.
- Accidental starting or operation of the pump while maintenance is in progress may cause injury or damage.
- Lift only with the lifting eyebolts supplied with the pump. Do not lift equipment attached to the pump with the eyebolts supplied.
- Do not touch hot surfaces on the pump. In normal operation at low pressures, surface temperatures will not normally exceed 180°F (82°C). Prolonged operation at 200 Torr may cause surface temperatures up to 220°F (104°C).
- GEAR DRIVES UNITS: During operation, gear drive units may become sufficiently hot to cause skin burns. Take care to avoid accidental contact. After extended running, the lubricant in gear units and lubrication systems may reach temperature sufficient to cause burns. Allow equipment to cool before servicing or performing adjustments.

DATA PLATE



MODEL NUMBER: The specific model of the blower

SERIAL NUMBER: Unique to each blower

YEAR: Year of manufacture

This manual describes instructions and precautions to be observed in the handling and maintenance of Tuthill Vacuum & Blower Systems Kinney KD Rotary Piston Vacuum Pumps. It is strongly recommended that those who operate or maintain the pump read this manual carefully prior to pump operation, to ensure personal safety and pump life.

WARNING



Keep body & clothing away from machine.

During operation, keep body and clothing away from inlet and outlet of the pump.

WARNING



Do not operate without guard in place. Assure that the guards are in place and secure prior to operation.

CAUTION



Hearing protection is required while the pump is in operation. At ultimate pressure noise levels are 75 dBA, however due to process or installation conditions noise levels may be higher.

CAUTION



Do not touch hot surfaces. Do not touch the vacuum pump while it is in operation and assure that the pump is cool before touching, when not in operation.

LIFTING



WARNING

The vacuum pump must be handled using an appropriate device such as a fork truck or appropriate lifting device. See *Table 4-2 on page 7* for approximate weights. Care should be taken to assure pump does not overturn during handling and installation.

04

DESCRIPTION

GENERAL

The visual difference between the two pumps is in the oil separators. Internally, the pistons, cams, and slide pins of the KD-50 are treated to be able to tolerate the increased speed. Both pumps are air-cooled rotary piston type, consisting of two rotary pistons pumping in parallel. The pumps attain a low ultimate pressure of less than 10 microns (1 x 10 in. Torr McLeod gauge). The rugged, simple design ensures dependable service under the most severe applications without costly or complicated maintenance. The ruggedness of the pump is evidenced by all cast-iron rotary internals, including the cast-iron sleeve bearings. The external drive shaft bearing is a sealed grease packed bearing. The mechanical shaft seal contains viton elastomer, which is suitable for most chemical as well as high-temperature operations.

PUMP COMPONENTS

All components are easily serviced and no special tools are required. The reliable, leak-free shaft seal requires no adjustment or maintenance. The gas ballast valve regulates the vapor handling capacity of the pump, decelerates contamination buildup in the oil, and quiets the discharge valve noise of the pump. The oil separator of the KD pump is equipped with a mist eliminator to provide filtering of the exhaust, thereby resulting in a cleaner pump area. The pump specifications are shown in **Table 4-1** and **Table 4-2 on page 7**.

	KD-30	KD-50
Free Air Displacement	33 CFM (56 m ³ /h)	52 CFM (88 m ³ /h)
Inlet Connection (NPT)	1-1/2 in. (38 mm)	1-1/2 in. (38 mm)
Discharge Connection (NPT)	1-1/4 in. (32 mm)	1-1/4 in. (32 mm)
Pump Speed (RPM)	571	900
Motor Speed (RPM)	1,725	1,725
Motor Horsepower	1-1/2 in. (38 mm)	2 in. (51 mm)

Table 4-1 – Pump Specifications

	KD-30 BELT DRIVE	KD-30 DIRECT DRIVE	KD-50 BELT DRIVE	KD-50 DIRECT DRIVE
Oil Capacity (Kinney AX)	4 qt (3.8 L)	4 qt (3.8 L)	12 qt (11.4 L)	12 qt (11.4 L)
Weight Complete Pump	200 lb (91 kg)	650 lb (295 kg)	230 lb (104 kg)	650 lb (295 kg)
Height	27 in. (69 mm)	37 in. (94 mm)	32-1/2 in. (83 mm)	34-1/2 in. (88 mm)
Width	20-1/2 in. (52 mm)	18 in. (46 mm)	20-1/2 in. (52 mm)	18 in. (46 mm)
Length	27-7/8 in. (71 cm)	44-1/4 in. (112 cm)	28-5/8 in. (73 cm)	42-1/4 in. (112 cm)
Typical Noise Level @ 10 Torr	< 85 dBA	< 85 dBA	< 85 dBA	< 85 dBA

Table 4-2 – Complete System Specifications

The two rotary pistons pump in parallel and are driven by two eccentric cams keyed to a shaft. See **Figure 4-1 on page 7**.




Figure 4-1 – Operating Cycle

Each rotary piston is composed of a cylindrical element that encloses the shaft and a hollow rectangular extension that moves through a slide pin. The piston slide pin has openings that are covered and uncovered as it passes through the slide pin, allowing gas to enter the cylinder and be compressed. The ends of the cylinder are enclosed by an open head, through which the shaft extends, and a closed head. The shaft has a mechanical seal on the open head end to prevent leakage around the shaft. Spring-loaded discharge valves are located at the discharge side of the pistons. An oil separator oil mist eliminator is mounted on top of the pump and connected to the discharge of the pump. A sight gauge in the oil separator is provided for checking the oil level. When pumping at low inlet pressure, the oil level should be in the center of the sight gauge.

NOTE: The oil level will change with large changes in pump inlet pressure.

OPERATING CYCLE

The operating cycle is shown in **Figure 4-1 on page 7**. Gas from the system enters the pump through the inlet, and from there it passes through the hollow piston-slide and out the slide port into the space being created between the piston and cylinder wall. As the piston rotates, this space increases and more gas is drawn in while at the same time the gas taken in and trapped. The previous revolution is on the compression side of the piston and slide. Here, the gas is compressed and forced out through the discharge valves along with a small amount of oil and then into the oil separator, where the oil is separated from the gas. The gas is discharged to the atmosphere, and the oil drains back into the reservoir. The KD pump has a filter to remove visible fumes from the discharged gas.

SEALING AND LUBRICATING

The oil flows through the pump by means of differential pressure between atmosphere and the pump inlet, and it is drawn into the pump at each head through the shaft bearings. The cylinder walls, pistons, and slide pin are lubricated and sealed against the backflow of gas by a film of oil that fills the close running clearances. The cylindrical part of the piston almost touches the pump cylinder at a line along the length of the piston, and as the piston continues to rotate, oil builds up ahead of this line and seals the space between the piston and cylinder wall. The excess oil is discharged with the gas and is returned to the oil reservoir. At low pressures, the air becomes mixed with the oil and the solution is discharged on the compression stroke.

OIL TYPES

The ability of the KD-30 and KD-50 pumps to obtain and hold pressures in the low micron range depends on the use of the proper sealing and lubricating oil. AX Vacuum Oil is recommended as it has characteristics necessary to obtain a dry, low vapor pressure fluid with suitable viscosity. Other applications such as oxygen pumping may require changing oil to Fomblin® or other perfluoropolyether (PFPE) where low temperatures are likely to be encountered. Other special fluids used are polyglycols, fluorocarbons, and FDA-approved lubricants. Consult the factory before changing from the recommended oil to ensure that the new fluid and present seals are compatible.

INSTALLATION

GENERAL

Select a pump site with enough room for pump maintenance and service. Secure the pump to a level, rigid, support. Spring vibramounds can be used if sufficiently flexible connectors are used in the manifolding.

V-BELT DRIVE

To install the V-belts, loosen the motor mounting screws and slide the motor toward the pump. Position the V-belt on the pump with the slack side on the top of the drive. Move the motor away from the pump to tighten the drive, and refer to Step 2 to check the tension of the V-belts. Before attempting to tension any V-belt drive, it is imperative that the sheaves be properly aligned. Position the sheaves so as to allow the belt to be placed in the grooves rolling them onto the sheaves.

The following tensioning steps can be safely followed for all belt types, cross-sections, number of belts per drive, or type of construction:

1. With the belt properly in the groove, adjust the sheaves until all slack has been taken up.
2. Start the drive and continue to tension the V-belt(s) until only a slight bow on the slack side of the drive appears while operating under load conditions as shown in **Figure 5-1 on page 9**.




Figure 5-1 – V-Belt Tensioning

3. After 24 to 48 hours of operation, the belt will seat itself in the sheave grooves. Further tensioning is then necessary as described in Step 2.

Insufficient tensioning is often evidenced by slipping (squealing) at start-up. Do not use belt dressing on V-belts. Sheaves and V-belts should remain free of oil and grease.

Remove tension from the belt if the drive is to be inactive for an extended period of time. For more specific information, consult the drive manufacturer.

DIRECT DRIVE

Mounted the pump on a flat and level surface. If the pump is to be installed outdoors, ensure the motor, painting, peripheral equipment, parts, etc., are suitable for outdoor operation. Allow enough space around the pump for safe maintenance work and periodic inspections. This includes, at a minimum, the ability to access oil fill and drain locations and to view the oil level sight glass.

The KD series Drive-Drive models are direct driven by two methods:

- 8 pole (KD50) or 12 pole (KD30) motors
- Gear reducer driven by 2 or 4 pole motor

If the pump was purchased directly from Tuthill, the coupling has been factory-aligned and tested. When installing the pump alone to be direct-coupled to a motor or gear drive, ensure the coupling alignment meets the manufacturer's recommendations to avoid excessive loading of the pump or motor bearings.

DISCHARGE PIPING

It may be desirable to connect discharge piping from the oil separator to the outside to dispose of exhaust gases and vapors. **See Figure 5-2 on page 10.** When connecting discharge piping, place a dropout trap adjacent to the oil separator to trap the condensate, which would otherwise drain back into the oil. If the condensate is water, drain it as necessary to prevent it from flowing back into the reservoir. A flexible connector, such as a rubber hose, at the discharge of the pump is necessary to make the piping flexible and to provide a convenient disconnect point for servicing. Turned down the outside end of the discharge line to prevent entry of precipitation.




Figure 5-2 – Typical Manifold Arrangement

INLET PIPING

Size and design the inlet piping with three objectives in mind:

- To prevent undue gas flow restriction
- To prevent pump fluids from splashing into the process chamber
- To protect the pump from injection of particulate matter

Tuthill recommends that the vacuum piping to the pump inlet be as large in diameter and as short in length as possible and no smaller in diameter than the pump inlet. **See Figure 5-2 on page 10** for recommended arrangement of vacuum manifolding.

As with all rotary mechanical pumps, it is necessary to install a flexible member in the suction manifold of the pump to avoid alignment problems and to reduce the possibility of transmitting vibration to and from other components. Self-supporting, bellows-type, flexible connectors are recommended and are available from Tuthill Vacuum & Blower. Use a connector be flexible enough to prevent vibration transmission and yet rigid enough to prevent collapsing under high vacuum.

Before connecting the manifolding to the pump, pour 1 pint (0.5 L) of oil into the inlet connection to ensure proper lubrication at initial start-up. When all inlet connections are made, check that the pressure of the system is near the pump blank-off pressure. The demountable joints should be O-ring sealed or threaded connections made with Teflon sealing tape or other sealing compound. Loctite 567 is available from Tuthill Vacuum & Blower as a compound for thread sizes up to 1 in. (2.5 cm) in diameter or Tite seal (Radiator Specialty Company) for larger thread sizes. Install a vacuum isolation valve between the system and the pump with a means for connecting a vacuum gauge on both sides of the valve. The gauge connections should face vertically down for self-draining and should be free from the splash of the pumping action. An air admittance valve on the pump side of the isolation valve is recommended. With such an arrangement, it is possible to check either the system or the pump for leaks without disconnecting the vacuum piping. This isolation valve will also allow the system to be kept under vacuum while the pump is not running or allow the pump to continue operating while the system is open to atmospheric pressure.

VACUUM GAUGES

Two general types of vacuum gauges are used for testing vacuum equipment: total pressure reading types, such as Thermistor or Thermocouple gauges, and partial pressure reading McLeod gauges. The McLeod gauge indicates the partial pressure of a gas and does not indicate the component of pressure due to condensable vapors such as water vapor. Partial vapor pressure has little effect on the McLeod gauge readings until it becomes quite high. Therefore, a McLeod gauge is most useful in confirming pump performance and for determining the absence or presence of real leaks. Thermistor or thermocouple gauges are preferable for leak checking, and when used in conjunction with a McLeod gauge the contamination level can be determined.

A high thermistor or thermocouple gauge reading may indicate that the pump is contaminated, that it leaks, or both. A high McLeod gauge reading means that a real leak is present.

ELECTRICAL CONNECTIONS

WARNING

Disconnect pump from source of electrical power prior to making repairs or adjustments to any electric component of the unit.

Check the operating voltage of the motor by comparing the lead connections with the markings on the motor. Wire to the proper power source through necessary switching and safety equipment. Connect the solenoid valve so that it is energized when the motor is started. The valve is normally closed and will open when energized.

The motor must turn in the direction of the arrow cast on the pump. If the motor turns in the wrong direction, reverse any two of the three wires leading from the motor to the power source. Standard pumps are designed to run clockwise when facing the pump pulley.

06

OPERATION



WARNING

The belt guard must be properly secured to the pump at all times while the pump is running.

When operating the pump in an enclosed area it is necessary, for health reasons, to have the area well ventilated. If ventilation is not adequate, the pump discharge should be filtered or piped to open air.

Do not block or restrict the flow of gas from the pump discharge. Back pressure within the pump could cause severe damage.

GENERAL

Each pump has been thoroughly tested and is ready for operation as soon as it is installed and filled with oil. If the vacuum system is free of leaks, including the connections to the pump, the ultimate system pressure should be close to the pressure obtained with the pump inlet closed off.

FILLING PUMP WITH OIL

When installing the pump, pour 1 pint (0.5 L) of oil into the pump inlet before connecting the inlet piping. Thereafter, pour the total required quantity of oil into the oil separator.

PRE-START CHECKS

Performed the following pre-start checks if maximum pumping conditions are required.

1. Check that the suction lines are tight and absolutely free of all foreign matter.
2. Add oil as necessary to bring the oil level midway on the sight gauge.
3. Check that the pump can be turned over by hand without mechanical interference. With the inlet at atmospheric pressure, turn the pump and note that more turning force is required when the pump discharges. This indicates that the discharge valves are seating properly.
4. Check the V-belt tension as shown in **Figure 5-1 on page 9**.
5. Check that direction of rotation is correct.

STARTING

Perform the pre-start checks, and do not start the pump until the oil temperature is above 40°F (4°C).

1. Depress the motor start button and allow the pump 10 minutes to warm up, at blank-off, before starting process work.
2. Check that the oil solenoid valve is energized and open, allowing the oil level to drop in the sight gauge.

The oil level will change with the pumping pressure. When the pump is first started, the oil will rise. As the inlet pressure is reduced, the oil level will drop and should stabilize midway on the sight gauge when the pump pressure approximates blank-off.

STOPPING

1. If a vacuum valve is provided between the pump and the process equipment, place this valve in the CLOSED position.
2. Turn off the power to the pump motor, and vent the pump to atmosphere. The gas ballast valve can be used for this purpose if a vent valve has not been provided. Venting the pump prevents flooding, which makes starting the pump difficult. Do not use the gas ballast valve for venting connected (process) volumes. Use the gas ballast valve only for venting the pump casing and a short length of manifold.

GAS BALLAST

Gas ballast is an operating mechanism that is used to prevent the condensation of vapor in a vacuum pump. Vapor present in the gas being pumped can condense during the vacuum pump compression cycle and mix with the oil. As the oil is circulated through the pump, the condensate is carried with the oil and allowed to re-evaporate, causing poor pump performance and making frequent oil changes necessary. By using gas ballast, most vapors can be passed through a vacuum pump without condensing and then discharged with the pump exhaust. Unless the lowest possible pressure is necessary, operate the pump with gas ballast.

In addition to preventing vapor condensation, the use of gas ballast also reduces discharge valve noise to a low level. It is generally possible to eliminate valve noise with a small gas ballast flow that does not seriously increase the ultimate pressure. If the resulting pressure is tolerable, this method of operation is preferred since it also helps to keep the oil clean. The setting of the gas ballast valve is best determined by trial and error because the amount of condensable vapor as well as the system operating conditions vary with different processes. The motor power consumption and the ultimate pressure will rise in proportion to the increase in gas ballast flow.

Gas ballast can be used in the following two ways:

1. Continuous gas ballast can be regulated to flow into the pump while processing. To regulate the gas ballast valve, while dead ended, slowly open the valve until the pressure is slightly below that needed for process work. Operate the pump at this setting to keep oil contamination to a minimum.
2. Intermittent gas ballast can be used when pressure requirements do not permit the use of continuous gas ballast. Running the pump overnight with full gas ballast is recommended for cleaning the oil of contamination. The condition of the oil can be estimated by observing the pump blank-off pressure with the gas ballast valve closed. Run the pump with the gas ballast valve open for a timed period (15 to 20 minutes) and observe the blank-off pressure change. When there is no further change in pressure, the oil is clean. This pressure change vs. time can be used to estimate the required time to clean the oil.

07

MAINTENANCE

GENERAL

Check the oil level daily for the first week of operation and weekly thereafter. The oil level should be about midway on the sight gauge when operating at low inlet pressures. However, the oil level rises as the inlet pressure goes up. A good check of the oil passage circuit is to change the inlet pressure or open the gas ballast valve and watch the oil level, which should rise as the inlet pressure goes up. Check the condition of the oil periodically by draining a small quantity into a clean container and visually inspecting it for solid or liquid contaminants. Change the oil when contamination is present after making full use of gas ballast to clean the oil. Change the oil when the pump has logged 750 hours of operating time or more often if an inspection of the oil dictates.

CHANGING OIL

Run the pump until the oil is warm ($>100^{\circ}\text{F}$ [38°C]), then open the G.B. valve for a 1 – 2 minutes. Then, stop the pump and open the drains in both the pump and reservoir. Fill the pump with oil as directed under **Filling Pump with Oil on page 12**. If the pump oil is badly contaminated, additional changes may be necessary with a 10 minute operating period between changes to check the pump blank-off pressure. Several oil changes may be necessary under extreme conditions.

V-BELTS

To change the V-belt, loosen the motor mounting screws and slide the motor toward the pump until the old belt can easily be slipped from the pulleys. The motor must be close enough to the pump to enable the new belt to be slipped onto the pulleys without rolling or stretching. When the belts are in place, pull the slack of both belts to the same point and tension the belts as shown in **Figure 5-2 on page 10**. Belts should not slip under full load, that is, when starting, if the proper tension is maintained. However, too much tension will place an undue strain on the shaft bearings. Adjust the tension on new belts after 24 to 48 hours of operation.

GEAR DRIVE UNITS

NOTE: The gear drive unit comes with an initial charge of oil. Check the oil level every 3,000 hours or 6 months, whichever is sooner. Recommended oil is Grade 6E.

DRAINING AND REFILLING OIL

Prior to Any Maintenance Operations

1. De-energize the drive and secure against it unintentionally switching on.
2. Wait until the pump has cooled down. A hot pump has skin burn and pressure buildup hazards.

Oil Plugs / Ventilator

1. Prior to removing plugs, ensure that the pump has cooled sufficiently so that oil will not burn.
2. Remove ventilator plug prior to removing level and/or drain plug.



WARNING

Do not stand over ventilator plug while removing as pressure build up behind valved ventilator may cause it to eject when removed.

3. Place a container under the oil drain plug to be removed.

NOTE: It is recommended that the oil should be slightly warm (104°F – 122°F [40°C – 50°C]) when drained. Cooler oil will be more difficult to drain correctly.

4. Refill oil through the ventilator position.
5. Refit all plugs after filling.
6. Clean away oil spillage.

BEARING LUBRICATION

Where re-greasing points are provided, add 2 shots monthly of NLGI 2 grade grease.

CLEANING

1. With the drive stationary, periodically clean any dirt or dust from the gear unit and the electric motor cooling fins and fan guard to aid cooling.
2. Ensure dust buildup does not exceed 0.2 in. (5 mm).

OIL SEPARATOR

All KD-30 and KD-50 blowers built since October 1984 are fitted with oil mist eliminators in the oil separator. If the oil separator has a filter, it will be necessary to periodically replace the filter element and remove any sludge accumulation.

The frequency of this is dependent upon the following conditions:

- Visual inspection shows the element to be blocked by foreign matter. A back pressure through the filter element exceeding 6 PSIG indicates that the filter element is unduly restricting the gas flow and should be changed.
- Motor current exceeds manufacturer's specifications.
- A ruptured element or the gaskets are not sealed, allowing mist to be discharged.

The oil separator on KD-30A and KD-50B pumps is equipped with an oil drain-back device to return oil to the reservoir that has penetrated the filter element. The check-type drain-back closes to prevent the exhaust gas from bypassing the filter when the inlet pressure is high and opens to allow the oil to drain back as the inlet pressure is reduced. If the pump is operated at high inlet pressures, over 5 Torr, for time periods exceeding several hours, no drain-back can occur and filter efficiency is reduced. Under such conditions, isolate the pump from the system with the main isolation valve, and run at blank-off pressure for 15 – 30 minutes to allow the oil to drain back. If the pump is always operated with lengthy high pressure, then install an external oil return line as follows.

A return line can be installed to return oil that collects in the filter area back to the pump. The successful operation of this arrangement is dependent upon having the oil return to the pump at a point that is compatible with the pump operating pressure level. **See Figure 7-1 on page 16.** Generally, oil must be returned to a low pressure point. The oil separator has an oil return valve that allows oil flow back when operating at pressures below 5 Torr.




Figure 7-1 – Return Line

One of the following two areas can be selected for the oil to return to the pump when operating above 5 Torr:

- If the pump operating range is between 5 and 150 Torr, the returning oil should enter the pump through the gas ballast valve, in which case the valve must be left open.
- When the operating range is above 150 Torr, the returning oil should enter the pump at the suction port area.

An alternative to the above arrangements is to drain the collected oil into a container and periodically return it to the pump through the oil fill. This arrangement is preferred if the collected oil contains a substantial amount of water. In this event, leave the oil to stand until the oil and water separate, at which time the water will be decanted, before returning the oil to the pump. With this arrangement, take special care to keep the oil clean.

DISASSEMBLY / ASSEMBLY

DISASSEMBLY

Disassemble the pump only to the extent necessary to repair it. Reference is made to the open and closed head ends of the pump. The open head is on the end through which the shaft extends.

1. Drain the oil by opening the oil drain valves. Remove the belt guards and belts.
2. Disconnect the piping and electrical connections to the oil solenoid.
3. Remove the pulley and drive key.
4. Remove the gas ballast valve and oil lines.
5. Remove the oil separator tank.
6. Remove the pump from base and position it on a workbench.
7. Remove the cylinder cover, gasket, and discharge valves.
8. Unlock the bearing from the shaft by removing the locking nut. Lift the dowel pin from the shaft and tap the tapered sleeve axially to break the bond between the sleeve and the bearing. Remove the bearing housing, rotating part of the shaft seal, and the retaining ring from the shaft.
9. Unscrew the cap screws and remove the open head, piston, and slide pin. Mark the slide pin and piston so as to reassemble as before.
10. Remove the closed head, piston, slide pin, and cam. Remove the cam by tapping the shaft with a soft-faced hammer until the cam is free from the shaft. Disassemble only if cam and shaft replacement is necessary.
11. A press is necessary to remove the open head cam from the shaft.
12. Slip off the coil from the stem. Inspect the solenoid valve seat, plunger, and spring.

REASSEMBLY

Before starting to reassemble the pump, inspect all parts for wear or damage, and replace as necessary. Parts must be clean and free of old sealing compound. A recommended solvent for cleaning the parts is trichloroethylene. Other solvents such as kerosene or carbon tetrachloride can be used only if facilities are available to vapor degrease the parts after cleaning. Dry the parts and coat them with vacuum oil to aid in assembling and provide lubrication on initial start-up.

The reassembly steps are as follows:

1. Replace the bearings in the pump heads.
2. Replace the cam key and press the open head cam onto the shaft. Carefully slide the shaft through the center wall. Install the open head with two screws to position the shaft.
3. Insert the cam key and tap the closed head cam onto the shaft snug against the shaft shoulder.

4. Position the closed head piston with the inlet ports of the piston slide facing away from the discharge valve side of the pump. Place the closed head slide pin over the piston slide with the scalloped edge up. Slide the piston over the cam and the slide pin into the slide pin recess in the cylinder.
5. Apply a thin coat of Loctite 515 to the sealing faces of the cylinder and head.

**CAUTION**

Do not allow Loctite 515 to be squeezed into the pump, as it will cause working parts to stick and obstruct oil flow.

6. Position the closed head on the dowel pins of the cylinder and install the securing screws.
7. Remove the open head. Install the open head piston and slide pin as described in Step 4, and secure the head as in Steps 5 and 6. Rotate the shaft to check for binding. If binding occurs, gently tap one end and then the other of the shaft a few times to slide the cams into their proper running positions.
8. Coat the O-ring with vacuum oil, place the O-ring and cap on the closed head, and secure with screws.
9. Install the shaft seal as described in **Shaft Seal on page 22**, lubricate the bearing housing O-ring with vacuum oil, slide the housing onto the shaft, and secure with the O-ring in place. Slide the bearing onto the taper sleeve with the tapered surface of the sleeve mating with the tapered surface of the bearing. Slide the sleeve bearing onto the shaft with the slotted, threaded end of the sleeve outboard. Tap the outer race of the bearing with a soft-faced hammer until the bearing is flush with the housing. Align the slot of the sleeve with the hole in the shaft and insert the dowel pin. Install and tighten the bearing lock nut using a 6 in. spanner without benefit of a handle extension. Overtightening the lock may cause the bearing to become distorted.
10. Install the discharge valves and replace the cylinder cover and gasket.
11. Return the pump to the base and replace the pulley, belts, and belt guard.
12. Replace the oil separator and gas ballast valve, and connect the oil lines and electrical wiring.
13. Close the oil drain valves and fill the pump with oil. Test the pump per **Checking Pump Performance on page 19**.
14. Reconnect the manifolding to the pump.

TROUBLESHOOTING

STARTING TROUBLES OR STALLING

Pump starting troubles or stalling may be due to loose or broken belts, lack of lubrication, obstruction inside the pump, temperature too low, the pump flooded with oil, locked drive bearing, or lack of electrical power. If the problem is loose or broken belts, see **V-Belts on page 14**. If stalling is due to insufficient lubrication, this can be due to blocked oil lines, malfunction of the solenoid valve, or low oil level. If the oil supply is depleted, it is probably caused by a ruptured oil line. If the pump is not free to turn by hand, dismantle it to remove the obstruction. If the pump is flooded, turn the pump over by hand before energizing to force the oil out into the separator. If the pump is too cold to start, use an immersion heater in the oil, or live steam on the exterior of the pump, until the oil is warmed to a temperature of 40°F (4°C) minimum. If there is no electrical power to the motor, check the fuses or relays for signs of overloading.

CHECKING PUMP PERFORMANCE

If the processing time increases or the ultimate pressure becomes poor with no recent changes in the process or in system configuration, test the pump to determine if the trouble is in the pump or the connected process equipment. To check the condition of the pump, measure the blank-off pressure using a McLeod gauge and, if available, take a thermistor or thermocouple gauge reading. See **Table 9-1 on page 23** for a listing of common symptoms in the system.

Average blank-off readings are 5 to 25 microns with a McLeod gauge and 10 to 100 microns with a thermocouple gauge. The specification pressure is 10 microns (10 x 10⁻³ Torr) McLeod gauge reading. To obtain a blank-off reading, isolate the pump from the process equipment. Connect a vacuum gauge to the pump side of the isolation valve (see **Figure 5-2 on page 10**) and operate the pump to allow it to attain the lowest pressure.

If the McLeod gauge reading is low and the thermocouple gauge reading is high, the pump oil is contaminated. Change the oil and check the blank-off pressure again. Additional oil changes may be necessary to flush all traces of contamination from the pump. After eliminating oil contamination as a possible cause of poor pump performance, recheck the blank-off pressure. If both the McLeod and thermocouple gauge readings are high, this indicates that the pump is leaking. Proceed as directed in **Pump Leaks on page 20**.

PUMP LEAKS

If the pump is suspected of leaking after eliminating oil contamination as the cause of poor performance, use a plastic sealing compound such as Apiezon to seal suspected areas. Apply the compound while the pump is running and monitor the gauge for sudden pressure drop as the leaks are sealed temporarily. Carefully check around the head for cylinder joints, securing bolts, plugs, or any penetration into the pumping area. Loctite 515 is available from Tuthill Vacuum & Blower to permanently seal the leaks once they have been found. If leaks are still indicated, check the shaft seal for defects such as cracked carbon ring, hardened rubber components, or scratches on the face of the seat, and change the seal if it shows signs of being defective.

Process Leaks

If the blank-off test shows that the vacuum pump is functioning properly but that the process equipment is faulty, applying the following procedure to further isolate the trouble:

1. Attach a vacuum gauge on the process side of the isolation valve.
2. Clear the process chamber of all material, which could give off vapors that would change the reading.
3. Run the pump to obtain the lowest possible pressure, and close the isolation valve.
4. Observe the pressure and if pressure is greater than required or does not hold to a reasonable rise rate, find and seal the leaks. If a leak detector is not available, proceed as directed in **Leak Checking Techniques on page 20** and permanently repair the leaks found.

Leak Checking Techniques

If a leak detector is available, probe all areas of penetration into the pumping chamber while monitoring the gauge for pressure changes. If a leak detector is not available, use the following method to locate leaks:

1. Cover suspected leaks with a low vapor pressure sealing compound.
2. Detect large leaks by pressurizing the pump and painting with a soap solution. Bubbles will indicate leaks. When pressurizing the pump, keep the pressure low (1 to 2 PSIG) for easy detection of bubbles.
3. To locate small leaks, it may be necessary to use a fast-acting thermocouple or thermistor gauge in conjunction with a probing media such as acetone, alcohol, freon, or helium. Position the vacuum gauge head downstream from the suspected leak area, and reduce the pressure until the gauge registers. Apply the probing media using a brush or squirt gun and watch the gauge for sudden pressure rise or fall as the media comes in contact with the leak area. Seal the area temporarily with Ductseal, Loctite 515, or Glyptal, and continue probing until the desired pressure is obtained. Permanently repair the leak areas with Loctite 515.
4. If leak checking fails to disclose the leaks, disassemble and remake all demountable joints and connections using new gaskets and sealing compound such as Loctite 515. Re-check pressure using blank-off plate after addition of each segment of the vacuum manifold.

CAUTION

Compound applied too thick may be squeezed into the pump where it could cause damage.

OIL CONTAMINATION

When the pressure has been satisfactory for some time and then the pressure gradually increases, this indicates oil contamination. When this happens clean the oil by using gas ballast or change the oil. Discolored oil does not necessarily indicate contamination. Conversely, vapors may contaminate oil and not show any color change. Oil drying can be checked by the crackling method (few drops of oil on an aluminum household foil heated by a match). If crackling does not occur, the oil is dry to better than a few PPM of water.

DISCHARGE VALVES

When the cause of poor pump performance is not due to leaks or oil contamination, inspect the discharge valves. The discharge valves (**see Figure 9-1 on page 21**) are located at the exhaust ports and could malfunction due to foreign matter preventing them from sealing or they may be worn to the point that they no longer function correctly.




Figure 9-1 – Discharge Valve

When the pump is operating without gas ballast, a sharp clicking noise generally indicates proper valve closing. To gain access to the valves, drain the oil and remove the cylinder cover. Remove the screws from the hold-down plate and the valve can then be removed. Check each valve by lifting the disc, and check the surfaces between the disc and seat for foreign matter, which may have lodged there. Release the disc and a firm pressure should close the valve, and the two parts should mate so as to form a seal between them.

Check for guide wear by moving the disc laterally. There should be little play at any valve lift position. No burrs can be tolerated. The valve can be disassembled for cleaning if necessary. However, assembly must be done with the six springs arranged in pairs with each pair positioned 120° from the other two pairs, the spring tongues facing the stop, and the free end facing the disc. When cleaning is complete, reassemble the pump, fill with oil, and test per **Checking Pump Performance on page 19**.

SHAFT SEAL




Figure 9-2 – Shaft Seal

Under normal conditions, the shaft seal shown in **Figure 9-2 on page 22** has a long, trouble-free life. It may become worn or scratched on the sealing surfaces by contaminated oil or it may be damaged by overheating. Proceed as follows to inspect or replace the seal:

1. Rest the pump on the closed head to prevent the oil from draining out. Use blocks to prevent the oil line from supporting the pump weight.
2. Remove the belt guard, belts, sheave, and drive key from the pump.
3. Remove the bearing assembly by unscrewing the locking nut. Lift the dowel pin out of the shaft from the slot in the bearing sleeve. Tap the sleeve to break the bond between the sleeve and bearing. Remove four screws from the housing and remove the housing from the shaft. The ceramic (non-rotating) portion of the seal will remain in the housing, and the boot with the carbon ring (rotating) portion will remain on the shaft. The bearing will remain in the housing.
4. Inspect the ceramic portion in the housing for signs of trouble such as a cracked seat or deterioration of the elastomer seal between the seat and the housing. Check that the rotating portion of the carbon washer is not cracked and that the face is smooth. The boot should fit firmly to the shaft and will bond to the shaft when it has been run for a few hours. Do not break this bond unless it is necessary to replace the rotating part of the seal.
5. When replacing the shaft seal, clean the shaft and housing areas where the seal was located, and lubricate the seal, housing, and shaft with grease. Press the non-rotating part of the seal into the housing and slide the rotating part onto the shaft. Be careful when sliding the seal over the shaft that the keyway does not cut the boot. Reassemble.

SYMPTOM	PROBABLE CAUSE	REMEDIES
System ultimate pressure excessively high	System contaminated by volatile material	Clean equipment with acetone, alcohol, or ether.
Pump ultimate pressure excessively high	Oil is contaminated	Pump down using full gas ballast overnight.
	Process equipment leaks, vacuum pump leaks	Check leaks.
	Oil flow blocked	Clean oil lines.
	Discharge valve malfunctioning	See Discharge Valves on page 21.
	Shaft seal leaking	See Shaft Seal on page 22.
	Internal parts worn or damaged	Disassemble pump and inspect parts for wear or damage.
Pump noise at low pressure	Hydraulic slap	Increase gas ballast valve opening.
Pump will not start or stalls	Locked drive bearing	Replace bearing.
	Loose or broken belts	See Starting Troubles or Stalling on page 19.
	Lack of lubrication	
	Obstruction inside the pump	
	Temperature too low	
	Flooding with oil	
	Loss of electrical power	

Table 9-1 – Common Symptoms and Remedies

SYMPTOM	PROBABLE CAUSE	REMEDIES
Output shaft does not rotate, even though the motor is running or the input shaft is rotating	Drive between shafts interrupted in the gear unit	Return the gear unit/geared motor for repair.
Unusual, regular running noise	A meshing or grinding sound: damage to bearings	Check oil. See Maintenance on page 14.
	A knocking sound: irregularity in the gearing	
Unusual, irregular running noise	Foreign matter present in the oil	Stop the unit. Check the oil.
Oil leaking from the gear unit or from the output end oil seal	Defective gasket on gear unit cover	Retighten screws on gear unit cover and observe gear unit. Vent the gear unit.
	Gear unit not ventilated	
Oil leaking from the ventilator	Gear unit overfilled with oil	Correct the oil level. See Maintenance on page 14.
	Gear unit installed in an incorrect mounting position	Fit the ventilator in the correct position and check oil level.
	Frequent cold starts (oil foaming) and/or high oil level.	Correct the oil level. See Maintenance on page 14.

Table 9-2 – Troubleshooting the Gear Drive

REPLACEMENT PARTS


GENERAL

The graphics on the following pages and their parts lists cover all parts in the KD-30 and KD-50 pumps, any of which are available as spare parts. Always include the model and serial number of the pump when ordering parts.

SPARE PARTS

Recommended spare parts are indicated on the parts list by an asterisk, which include gaskets, O-rings, shaft seal, and discharge valves. The recommended spare parts are intended to support the pump until a more extensive stock of spare parts can be developed based upon usage data as parts are replaced. The number of pumps in operation plus the degree of importance of keeping the pumps in ready condition are factors to be considered when developing a stock of spare parts. Maintain an adequate supply of AX Oil and Loctite 515, and have a vacuum gauge available for checking pump performance.

KD-30A EXPLODED VIEW DRAWING




KD-30A PARTS LIST

ITEM NO.	DESCRIPTION	QTY
1	Cylinder	1
2	Head, Open & Closed End	2
3	Housing, Shaft Seal & Bearing	1
4	Cap, Closed End	1
5	Cover, Cylinder	1
6**	Gasket, Cylinder Cover	1
7	Cam, Open End (Heavy)	1
8	Cam, Closed End	1
9	Piston	2
10	Slidepin	2
11	Shaft	1
12**	Discharge Valve	2
13	Plate, Valve Hold Down	2
14	Bearing, Head	2
15	Spacer, Bearing, Open Head	1
16	Bearing Assmbly, Out.	1
16A	Ball Bearing w/ ID Taper	1
16B	Bearing Adapter	1
17**	Shaft Seal, 3/4 Viton	1
18**	Retaining Ring, .75 Ext.	1
19**	O-Ring, 2-27 Buna-N	2
20	Key, Cam, Woodruff 13	2
21	Key, Drive, 3/16 sq. x 1-1/4 lg.	1
22	Dowel Pin 1/8 dia. x 1/2 lg.	1
23	Dowel Pin 5/16 dia. x 7/8 lg.	4
24	Hex Head Cap Screw, 5/16-18 x 3/4 lg.	36
25	Hex Head Cap Screw, 5/16-18 x 7/8 lg.	10
26	Socket Head Cap Screw, 5/16-18 x 7/8 lg.	1
27	Socket Head Cap Screw, 5/16-18 x 5/8 lg.	6
28	Pipe Plug, Hex Sock, 1/8 NPT	2

ITEM NO.	DESCRIPTION	QTY
29	Gas Ballast Valve	1
30	Drain Cock, Oil, 1/4 NPT	1
31	Drain Cock, Oil, 3/8 NPT	1
32	Street Elbow, 3/8 NPT	1
33	Coupling, 3/8 NPT	1
34	Oil Mist Eliminator	1
34A	Oil Mist Filter Element	1
34B**	Gasket, OME	1
34C**	Check Disc, OME	1
34D	Sightglass	1
35*	Solenoid Valve 240/480V	1
36*	Pump Sheave, Special Unbal.	1
37*	V-Belt 3VX355 (w/ FR 56 motor)	1
37*	V-Belt 3VX450 (w/ FR145T motor)	1

* Item Not Shown
** Item included in repair/maintenance kit.

KD-50B EXPLODED VIEW DRAWING



KD-50B PARTS LIST

ITEM NO.	DESCRIPTION	QTY
1	Cylinder	1
2	Head, Open & Closed End	2
3	Housing, Shaft Seal & Bearing	1
4	Cap, Closed End	1
5	Cover, Cylinder	1
6**	Gasket, Cylinder Cover	1
7	Cam, Open End (Heavy)	1
8	Cam, Closed End	1
9	Piston	2
10	Slidepin	2
11	Shaft	1
12**	Discharge Valve	2
13	Plate, Valve Hold Down	2
14	Bearing, Head	2
15	Spacer, Bearing, Open Head	1
16	Bearing Assmby, Out.	1
16A	Ball Bearing w/ ID Taper	1
16B	Bearing Adapter	1
17**	Shaft Seal, 3/4 Viton	1
18**	Retaining Ring, .75 Ext.	1
19**	O-Ring, 2-27 Buna-N	2
20	Key, Cam, Woodruff 13	2
21	Key, Drive, 3/16 sq. x 1-1/4 lg.	1
22	Dowel Pin 1/8 dia. x 1/2 lg.	1
23	Dowel Pin 5/16 dia. x 7/8 lg.	4
24	Hex Head Cap Screw, 5/16-18 x 3/4 lg.	36
25	Hex Head Cap Screw, 5/16-18 x 7/8 lg.	10
26	Socket Head Cap Screw, 5/16-18 x 7/8 lg.	1
27	Socket Head Cap Screw, 5/16-18 x 5/8 lg.	6
28	Pipe Plug, Hex Sock, 1/8 NPT	2

ITEM NO.	DESCRIPTION	QTY
29	Gas Ballast Valve	1
30	Drain Cock, Oil, 1/4 NPT	1
31	Discharge Separator Tank Assy.	1
31A**	Flange Gasket	1
31B	Oil Mist Eliminator Element	1
31D**	Check Disc, Viton	1
31E	Dispersion Screen	1
31F	Sightglass, 2" NPT	1
31G	Oil Drain Cock, 1/2 NPT	1
31H*	Seal Nut, 1-1/2 NPT	1
31I*	Reinforcing Plate	1
32*	Solenoid Valve 240/480V	1
33*	Pump Sheave	1
34*	V-Belt 3VX375 (w/ FR 56 motor)	1
34*	V-Belt 3VX470 (w/ FR145T motor)	1
<p>* Item Not Shown. Item 31, Bolting Hardware, not shown.</p> <p>** Item included in repair/maintenance kit</p>		



4840 W. KEARNEY ST., SPRINGFIELD, MO 65803 • P (417) 865-8715 • F (417) 865-2950



DECLARATION OF INCORPORATION

Herewith we declare that the items detailed below are in conformity with the provisions of the Machinery Directive 2006/42/EC.

Information on the items detailed are compiled per the Machinery Directive 2006/42/EC, Annex VII, part A and are the responsibility of the person listed below.

The items detailed below must not be put into service until the machinery into which it is to be incorporated has been declared in conformity with the provisions of the relevant directive(s).

Other directives and standards that apply to this Declaration of Incorporation:

EN 1012-2:1996 - Compressors and vacuum pumps - Safety requirements - Part 2: Vacuum Pumps

The scope of the Declaration of Incorporation is for bare shaft Single Stage Rotary Piston Pumps.

Models KT150, KT300, KT500, KT850

KD30, KD50

KDH 130, KDH 150

David Schardt

Vice President of Engineering, Tuthill Vacuum & Blower Systems

WHEN WE COME ALIVE



THE WORLD COMES ALONG

WARRANTY – VACUUM PRODUCTS

Subject to the terms and conditions hereinafter set forth and set forth in General Terms of Sale, Tuthill Vacuum & Blower Systems (the Seller) warrants products and parts of its manufacture, when shipped, and its work (including installation and start-up) when performed, will be of good quality and will be free from defects in material and workmanship. This warranty applies only to Seller's equipment, under use and service in accordance with seller's written instructions, recommendations and ratings for installation, operating, maintenance and service of products, for a period as stated in the table below. Because of varying conditions of installation and operation, all guarantees of performance are subject to plus or minus 5% variation. (Non-standard materials are subject to a plus or minus 10% variation).

PRODUCT TYPE	TYPE OF APPLICATION
New	15 months after date of shipment or 12 months after initial startup date, whichever occurs first
Piston Pumps	30 months after date of shipment, on all units sold after June 1, 2014
Repair	6 months after date of shipment or remaining warranty period, whichever is greater
Remanufactured	9 months after date of shipment or 6 months after initial startup date, whichever occurs first

THIS WARRANTY EXTENDS ONLY TO BUYER AND/OR ORIGINAL END USER, AND IN NO EVENT SHALL THE SELLER BE LIABLE FOR PROPERTY DAMAGE SUSTAINED BY A PERSON DESIGNATED BY THE LAW OF ANY JURISDICTION AS A THIRD PARTY BENEFICIARY OF THIS WARRANTY OR ANY OTHER WARRANTY HELD TO SURVIVE SELLER'S DISCLAIMER.

All accessories furnished by Seller but manufactured by others bear only that manufacturer's standard warranty.

All claims for defective products, parts, or work under this warranty must be made in writing immediately upon discovery and, in any event within one (1) year from date of shipment of the applicable item and all claims for defective work must be made in writing immediately upon discovery and in any event within one (1) year from date of completion thereof by Seller. Unless done with prior written consent of Seller, any repairs, alterations or disassembly of Seller's equipment shall void warranty. Installation and transportation costs are not included and defective items must be held for Seller's inspection and returned to Seller's Ex-works point upon request.

THERE ARE NO WARRANTIES, EXPRESSED, IMPLIED OR STATUTORY WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF, INCLUDING WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS OF PURPOSE.

After Buyer's submission of a claim as provided above and its approval, Seller shall at its option either repair or replace its product, part, or work at the original Ex-works point of shipment, or refund an equitable portion of the purchase price.

The products and parts sold hereunder are not warranted for operation with erosive or corrosive material or those which may lead to build up of material within the product supplied, nor those which are incompatible with the materials of construction. The Buyer shall have no claim whatsoever and no product or part shall be deemed to be defective by reason of failure to resist erosive or corrosive action nor for problems resulting from build-up of material within the unit nor for problems due to incompatibility with the materials of construction.

Any improper use, operation beyond capacity, substitution of parts not approved by Seller, or any alteration or repair by others in such manner as in Seller's judgment affects the product materially and adversely shall void this warranty.

No employee or representative of Seller other than an Officer of the Company is authorized to change this warranty in any way or grant any other warranty. Any such change by an Officer of the Company must be in writing.

The foregoing is Seller's only obligation and Buyer's only remedy for breach of warranty, and except for gross negligence, willful misconduct and remedies permitted under the General Terms of Sale in the sections on **CONTRACT PERFORMANCE, INSPECTION AND ACCEPTANCE and the PATENTS Clause hereof, the foregoing is BUYER'S ONLY REMEDY HEREUNDER BY WAY OF BREACH OF CONTRACT, TORT OR OTHERWISE, WITHOUT REGARD TO WHETHER ANY DEFECT WAS DISCOVERED OR LATENT AT THE TIME OF DELIVERY OF THE PRODUCT OR WORK.** In no event shall Buyer be entitled to incidental or consequential damages. Any action for breach of this agreement must commence within one (1) year after the cause of action has occurred.

June 2014

OPERATING DATA FORM / PRODUCT REGISTRATION

It is to the user's advantage to have the requested data filled in below and available in the event a problem should develop in the blower or the system. This information is also helpful when ordering spare parts.

Model No.	_____	V-Belt Size	_____	Length	_____
Serial No.	_____	Type of Lubrication	_____		
Start-up Date	_____	_____			
Pump RPM	_____	Operating Vacuum	_____		
Pump Sheave Diameter	_____	Any Other Special Accessories Supplied or in Use:			
Motor Sheave Diameter	_____	_____			
Motor RPM	_____	HP	_____	_____	

NOTES:

IMPORTANT

All blowers manufactured by Tuthill Vacuum & Blower Systems are date-coded at time of shipment. In order to assure you of the full benefits of the product warranty, please complete, tear out and return the product registration card, or register online at **tuthillvacuumblower.com**.



Technical Support: 1-877-955-TECH (8324)

Service & Repair or Product Sales:

Tuthill Vacuum & Blower Systems
4840 West Kearney Street
Springfield, Missouri USA 65803-8702
O 417.865.8715 800.825.6937
F 417.865.2950
tuthillvacuumblower.com



Manual 1808 Rev B p/n 001808 0000