


HPS® 979 Atmosphere to Vacuum Transducer

Pin	Description
1	RS485(-)
2	RS485(+)
3	+24V
4	Power Gound
5	Analog output (+)
6	Analog output (-)
7	Relay #1 NO
8	Relay #1 Common
9	Relay #1 NC
10	Relay #2 NC
11	Relay #2 Common
12	Relay #2 NO
13	Relay #3 NC
14	Relay #3 Common
15	Relay #3 NO

Note:

This information is subject to change without notice.



Need help?

Contact MKS Instruments by [sending an email to MKS](#) or call **800-227-8766** or **978-645-5500** (outside the USA).