

About these instructions

These instructions explain how to install the Agilent MBA2 Hot Filament Gauges supplied by Granville-Phillips®. The gauge measures vacuum pressure by producing a current that is proportional to the density of the gas inside the gauge tube. Please see the XGS-600 manual part #699908410 for detailed connection instructions. The gauge connects to an Agilent XGS600 gauge controller.

WARNING

Using the gauge to measure the pressure of flammable or explosive gases can cause a fire or explosion resulting in severe property damage or personal injury.
Do not use the gauge to measure the pressure of flammable or explosive gases.

Preventing gauge contamination

To avoid contaminating the gauge, follow these guidelines while unpacking and installing the gauge:

- Wear sterile gloves and observe standard cleanroom practices.
- Connect the gauge to the vacuum system *immediately* after you've removed the gauge from its protective bag.
- Do not touch the vacuum connection port.
- Do not scratch the vacuum port seal surfaces.
- After removing the cap plug, handle the gauge carefully to avoid damaging the port screen.

Mounting and orientation

The gauge may be mounted in any orientation.

- Locate the gauge in the place within the vacuum system where pressure measurement is most important. Valves or other constrictions near the gauge may cause erroneous pressure readings.
- Locate the gauge where ambient temperature remains relatively constant.
- Do not locate the gauge near a heat source or strong magnetic field.
- Do not locate the gauge near the pump, where gauge pressure might be lower than normal vacuum pressure.
- Do not locate the gauge near a gas inlet or other source of contamination, where inflow of gas or particulates causes atmospheric pressure to be higher than system atmosphere.

Figure 1 Dimensions of MBA2 Dual Filament Gauge




Table 1 MBA2 Dual Filament Gauge Fittings


Fitting	Dim. H	
	cm	in.
KF flange	7.3	2.9
ConFlat® flange	7.3	2.9



CAUTION


Twisting the gauge to tighten the fitting to the vacuum chamber can damage the gauge's internal connections.
Do not twist the gauge to tighten the fitting.
Use appropriate tools to tighten the fitting.

KF flange



The NW mounting system requires O-rings and centering rings between mating flanges.
a. Tighten the clamp to compress the mating flanges together.
b. Seal the O-ring.

ConFlat® flange



To minimize the possibility of leaks with ConFlat flanges, use high strength stainless steel bolts and a new, clean stainless steel with OFHC copper gasket.
a. Avoid scratching the seal surfaces.
b. Finger tighten all bolts.
c. Use a wrench to continue tightening 1/8 turn at a time in crisscross order (1, 4, 2, 5, 3, 6) until flange faces make contact. Further tighten each bolt about 1/16 turn.

Connect Cable to the Agilent XGS-600 Gauge Controller

The gauge can connect to an Agilent XGS-600 gauge controller. Use the cable supplied by Agilent and listed below. Clamp all gauge cables to the vacuum station to minimize strain that will be transmitted to the gauge pins if the vacuum station and controller move relative to each other.

Gauge pins

Figure illustrates the 6-pin miniature tube pinout.

WARNING

Touching the gauge pins while the gauge is connected to a controller can cause a high-voltage electrical discharge through a gas or plasma, resulting in severe property damage or personal injury.
Do not touch the gauge pins while the gauge is connected to a controller.
Before operating the gauge, make sure the cable connector completely covers the gauge pins.

Figure 2 6-pin miniature tube pinout




Table 2 Ordering Information for the MBA2 Metal Baird Alpert Dual Hot Filament Gauges

Product Number	Product Description
X3203-60000	MBA2-200T, DUAL TUNGSTEN FILS,NW25
X3203-60001	MBA2-200T, DUAL TUNGSTEN FILS,NW40
X3203-60002	MBA2-200T, DUAL TUNGSTEN FILS,CFF2.75
X3203-60003	MBA2-200, DUAL YITTRIA-IRIDIUM FILS,NW25
X3203-60004	MBA2-200, DUAL YITTRIA-IRIDIUM FILS,NW40
X3203-60005	MBA2-200, DUAL YITTRIA-IRIDIUM FILS,2.75CFF
X3203-60006	CABLE, 10', MBA2 HFIG, XGS-600
X3203-60007	CABLE, 25', MBA2 HFIG, XGS-600
X3203-60008	CABLE, 50', MBA2 HFIG, XGS-600
X3203-60009	CABLE, 65', MBA2 HFIG, XGS-600
X3203-60010	CABLE, 75', MBA2 HFIG, XGS-600

Bakeout

To achieve an ultraclean state, you can bake the gauge at a temperature between 150° and 200° C (302° and 392° F). Disconnect gauge cable if the gauge will be baked at a temperature higher than 150° C (302° F).


Physical specifications

Mounting orientation	Any
Materials	Vacuum fired, UHV compatible
Envelope	304L stainless steel
Collector	Tungsten
Grid	Tantalum
Filaments	Tungsten or yttria-coated iridium
Weight	0.1 kg (4 oz.) with 1.33 in ConFlat flange (NW16CF)
Internal volume	10.8 cm ³ (0.66 in. ³)

Operating specifications

X ray limit	3 x 10 ⁻¹⁰ Torr (3.99 x 10 ⁻¹⁰ mbar, 3.99 x 10 ⁻⁸ Pa) maximum
Sensitivity for N ₂	20/Torr (15/mbar, 0.15/Pa)
Electron bombardment degas	3 W at 250 to 330 V
Bakeout temperature, nonoperating	200° C (392° F) maximum with cable disconnected 150° C (302° F) maximum with cable connected
Operating temperature	0 to 50° C (32 to 122° F) ambient, noncondensing
Filament emission current	4 mA maximum 15 mA for electron bombardment degas
Filament bias potential	+30 V
Filament heating voltage	1.2 V (2.3 V maximum)
Filament heating current	2.0 A (3.0 A maximum)
Collector potential	0 V
Grid potential	+180 V

Ensure proper grounding

**WARNING**

Improper grounding could cause a high-voltage electrical discharge through a gas or plasma, resulting in severe product damage or serious personal injury.

Follow ground network requirements for the facility.

- Maintain all exposed conductors at earth ground.
- Make sure the vacuum port to which the gauge is mounted is properly grounded.
- Make sure all exposed conductive parts of the gauge, controller, and vacuum chamber are properly grounded.

Make sure all exposed conductive parts of the gauge, controller, and vacuum chamber are properly grounded.


Degas

Electron bombardment degas of gauge electrodes removes gas that has been absorbed into the internal surfaces of the gauge. During degas, emission current increases to 15 mA and the grid bias increases to 250 VDC, resulting in an increased grid temperature to drive off adsorbed gases.

During degas, you must turn on the pump to remove the gases from the internal surfaces of the gauge.

The control enables pressure measurement during degas and automatically generates electron bombardment power for degas whenever emission current is 10 mA.

- You cannot degas the gauge by resistance heating the grid.
- Do not degas the gauge unless pressure is lower than 5 x 10⁻⁵ Torr (6.66 x 10⁻⁵ mbar, 6.66 x 10⁻³ Pa).

**WARNING**

Performing a degas while pressure is higher than 5 x 10⁻⁵ Torr (6.66 x 10⁻⁵ mbar, 6.66 x 10⁻³ Pa) can cause a high-voltage electrical discharge, resulting in severe product damage or personal injury.

Before performing a degas, make sure system pressure is lower than 5 x 10⁻⁵ Torr (6.66 x 10⁻⁵ mbar, 6.66 x 10⁻³ Pa).

MBA2-200

MBA2-200 Metal Bayard-Alpert Dual Filament Gauge

Agilent Technologies

MBA2-200

To obtain a copy of these instructions online, visit <http://www.chem.agilent.com/en-US/products/instruments/vacuum/pages/default.aspx>. Adobe® Reader® required.

Agilent Technologies

Installation Instructions

Instruction Manual part number 223770
Revision A May 2014

Installation Instructions

Agilent Technologies
121 Hartwell Avenue
Lexington, MA 02421 USA
Tel: +1 781 861 7200
Toll Free: +1 800 882 7426
Fax: +1 781 860 5437
vpl-customer-service@agilent.com
© 2014 Agilent, Inc.

Installation Instructions

Instruction Manual part number 223770
Revision A May 2014